



---

# **SERVICE STATION MANUAL**

---

**854251**

---



## **DORSODURO ABS**

---



# SERVICE STATION MANUAL

## DORSODURO ABS

### THE VALUE OF SERVICE

As a result of continuous updates and specific technical training programmes for Aprilia products, only **Aprilia** Official Network mechanics know this vehicle fully and have the specific tools necessary to carry out maintenance and repair operations correctly.

The reliability of the vehicle also depends on its mechanical conditions. Checking the vehicle before riding it, its regular maintenance and the use of **original Aprilia spare parts** only are essential factors!

For information on the nearest **Official Dealer and/or Service Centre** consult our website:

[www.aprilia.com](http://www.aprilia.com)

Only by requesting Aprilia original spare parts can you be sure of purchasing products that were developed and tested during the actual vehicle design stage. All Aprilia original spare parts undergo quality control procedures to guarantee reliability and durability.

The descriptions and images in this publication are given for illustrative purposes only and are not binding. While the basic characteristics as described and illustrated in this booklet remain unchanged, Piaggio & C. S.p.A. reserves the right, at any time and without being required to update this publication beforehand, to make any changes to components, parts or accessories, which it considers necessary to improve the product or which are required for manufacturing or construction reasons.

Not all versions/models shown in this publication are available in all countries. The availability of individual models should be confirmed with the official Aprilia sales network.

The Aprilia trademark is the property of Piaggio & C. S.p.A.

© Copyright 2013 - Piaggio & C. S.p.A. All rights reserved. Reproduction of this publication in whole or in part is prohibited.

Piaggio & C. S.p.A. Viale Rinaldo Piaggio, 25 - 56025 PONTEDERA (PI), Italy

[www.piaggio.com](http://www.piaggio.com)

---

---

# SERVICE STATION MANUAL

## DORSODURO ABS

This manual provides the main information to carry out regular maintenance operations on your vehicle. This manual is intended to Aprilia Dealers and their qualified mechanics; several concepts have been deliberately omitted as they are considered unnecessary. As it is not possible to include complete mechanical notions in this manual, users should have basic mechanical knowledge or minimum knowledge about the procedures involved when repairing scooters. Without this knowledge, repairing or checking the vehicle may be inefficient or even dangerous. As the vehicle repair and check procedures are not described in detail, be extremely cautious so as not to damage components or injure individuals. In order to optimise customer satisfaction when using our vehicles, **Piaggio & C. S.p.a.** commits itself to continually improve its products and the relative documentation. The main technical modifications and changes in repair procedures are communicated to all **Aprilia Sales Outlets and its International Subsidiaries**. These changes will be introduced in the subsequent editions of the manual. In case of need or further queries on repair and check procedures, consult **Aprilia CUSTOMER DEPARTMENT**, which will be prepared to provide any information on the subject and any further communications on updates and technical changes related to the vehicle.

**NOTE** Provides key information to make the procedure easier to understand and carry out.

**CAUTION** Refers to specific procedures to carry out for preventing damages to the vehicle.

**WARNING** Refers to specific procedures to carry out to prevent injuries to the repairer.



**Personal safety** Failure to completely observe these instructions will result in serious risk of personal injury.



**Safeguarding the environment** Sections marked with this symbol indicate the correct use of the vehicle to prevent damaging the environment.



**Vehicle intactness** The incomplete or non-observance of these regulations leads to the risk of serious damage to the vehicle and sometimes even the invalidity of the guarantee

---



## INDEX OF TOPICS

CHARACTERISTICS

CHAR

SPECIAL TOOLS

S-TOOLS

MAINTENANCE

MAIN

TROUBLESHOOTING

TROUBL

ELECTRICAL SYSTEM

ELE SYS

ENGINE FROM VEHICLE

ENG VE

ENGINE

ENG

POWER SUPPLY

P SUPP

SUSPENSIONS

SUSP

CHASSIS

CHAS

BRAKING SYSTEM

BRAK SYS

CLUTCH SYSTEM

CLU SYS

COOLING SYSTEM

COOL SYS

BODYWORK

BODYW

PRE-DELIVERY

PRE DE



INDEX OF TOPICS

CHARACTERISTICS

CHAR

---

## Rules

---

### Safety rules

#### Carbon monoxide

If you need to keep the engine running while working on the vehicle, please ensure that you do so in an open or very well ventilated area. Never run the engine in an enclosed area. If you do work in an enclosed area, make sure to use a fume extraction system.

#### CAUTION



**EXHAUST EMISSIONS CONTAIN CARBON MONOXIDE, A POISONOUS GAS WHICH CAN CAUSE LOSS OF CONSCIOUSNESS AND EVEN DEATH.**

#### Fuel

#### CAUTION



**THE FUEL USED TO POWER INTERNAL COMBUSTION ENGINES IS HIGHLY FLAMMABLE AND MAY BE EXPLOSIVE UNDER CERTAIN CONDITIONS. IT IS THEREFORE RECOMMENDED TO CARRY OUT REFUELLING AND MAINTENANCE PROCEDURES IN A VENTILATED AREA WITH THE ENGINE SWITCHED OFF. DO NOT SMOKE DURING REFUELLING AND NEAR FUEL VAPOURS, AVOIDING ANY CONTACT WITH NAKED FLAMES, SPARKS OR OTHER SOURCES WHICH MAY CAUSE THEM TO IGNITE OR EXPLODE.**

**DO NOT DISPERSE FUEL IN THE ENVIRONMENT.**

**KEEP OUT OF THE REACH OF CHILDREN**

#### Hot components

The engine and the exhaust system components become very hot and remain hot for some time after the engine has been switched off. When handling these components, wear insulating gloves or wait until the engine and the exhaust system have cooled down.

#### Coolant

The coolant contains ethylene glycol which, under certain conditions, can become flammable.

When it burns, ethylene glycol produces an invisible flame which however can cause burns.

#### CAUTION



**TAKE CARE NOT TO POUR COOLANT ONTO HOT ENGINE OR EXHAUST SYSTEM COMPONENTS; THE FLUID MAY CATCH FIRE AND BURN WITH INVISIBLE FLAMES. WHEN CARRYING OUT MAINTENANCE OPERATIONS, IT IS ADVISABLE TO WEAR LATEX GLOVES. EVEN THOUGH IT IS TOXIC, COOLANT HAS A SWEET FLAVOUR WHICH MAKES IT VERY ATTRACTIVE TO ANIMALS. NEVER LEAVE THE COOLANT IN OPEN CONTAINERS IN AREAS ACCESSIBLE TO ANIMALS AS THEY MAY DRINK IT.**

**KEEP OUT OF THE REACH OF CHILDREN**

**DO NOT REMOVE THE RADIATOR CAP WHEN THE ENGINE IS STILL HOT. THE COOLANT IS UNDER PRESSURE AND MAY CAUSE BURNS.**

**Used engine oil and transmission oil**

**CAUTION**



**IT IS ADVISABLE TO WEAR PROTECTIVE IMPERMEABLE GLOVES WHEN SERVICING THE VEHICLE.**

**THE ENGINE OR GEARBOX OIL MAY CAUSE SERIOUS INJURIES TO THE SKIN IF HANDLED FOR PROLONGED PERIODS OF TIME AND ON A REGULAR BASIS.**

**WASH YOUR HANDS CAREFULLY AFTER HANDLING OIL.**

**HAND THE OIL OVER TO OR HAVE IT COLLECTED BY THE NEAREST USED OIL RECYCLING COMPANY OR THE SUPPLIER.**

**DO NOT DISPOSE OF OIL IN THE ENVIRONMENT**

**KEEP OUT OF THE REACH OF CHILDREN**

**Brake and clutch fluid**



**BRAKE AND CLUTCH FLUIDS CAN DAMAGE THE PLASTIC OR RUBBER PAINTED SURFACES. WHEN SERVICING THE BRAKING SYSTEM OR THE CLUTCH SYSTEM, PROTECT THESE COMPONENTS WITH A CLEAN CLOTH. ALWAYS WEAR PROTECTIVE GOGGLES WHEN SERVICING THESE SYSTEMS. BRAKE AND CLUTCH FLUIDS ARE EXTREMELY HARMFUL FOR YOUR EYES. IN THE EVENT OF ACCIDENTAL CONTACT WITH THE EYES, RINSE THEM IMMEDIATELY WITH ABUNDANT COLD, CLEAN WATER AND SEEK MEDICAL ADVICE.**

**KEEP OUT OF THE REACH OF CHILDREN**

**Battery electrolyte and hydrogen gas**

**CAUTION**



**THE BATTERY ELECTROLYTE IS TOXIC, CORROSIVE AND AS IT CONTAINS SULPHURIC ACID, IT CAN CAUSE BURNS WHEN IN CONTACT WITH THE SKIN. WHEN HANDLING BATTERY ELECTROLYTE, WEAR TIGHT-FITTING GLOVES AND PROTECTIVE APPAREL. IN THE EVENT OF SKIN CONTACT WITH THE ELECTROLYTIC FLUID, RINSE WELL WITH PLENTY OF CLEAN WATER. IT IS PARTICULARLY IMPORTANT TO PROTECT YOUR EYES BECAUSE EVEN TINY AMOUNTS OF BATTERY ACID MAY CAUSE BLINDNESS. IF THE FLUID GETS IN CONTACT WITH YOUR EYES, WASH WITH ABUNDANT WATER FOR FIFTEEN MINUTES AND CONSULT AN EYE SPECIALIST IMMEDIATELY. THE BATTERY RELEASES EXPLOSIVE GASES; KEEP IT AWAY FROM FLAMES, SPARKS, CIGARETTES OR ANY OTHER HEAT SOURCES. ENSURE ADEQUATE VENTILATION WHEN SERVICING OR RECHARGING THE BATTERY.**

**KEEP OUT OF THE REACH OF CHILDREN**

**BATTERY LIQUID IS CORROSIVE. DO NOT POUR IT OR SPILL IT, PARTICULARLY ON PLASTIC COMPONENTS. ENSURE THAT THE ELECTROLYTIC ACID IS COMPATIBLE WITH THE BATTERY TO BE ACTIVATED.**

---

## **Maintenance rules**

### **GENERAL PRECAUTIONS AND INFORMATION**

When repairing, dismantling and reassembling the vehicle, follow the recommendations given below carefully.

**BEFORE DISASSEMBLING COMPONENTS**

- Before dismantling components, remove dirt, mud, dust and foreign bodies from the vehicle. Use the special tools designed for this bike, as required.

**COMPONENTS REMOVAL**

- Do not loosen and/or tighten screws and nuts using pliers or any other tools than the specific wrench.
- Mark positions on all connection joints (pipes, cables etc.) before separating them, and identify them with distinctive symbols.
- Each component needs to be clearly marked to enable identification during reassembly.
- Clean and wash the dismantled components carefully using a low-flammability detergent.
- Keep mated parts together since they have "adjusted" to each other due to normal wear.
- Some components must be used together or replaced completely.
- Keep away from heat sources.

**REASSEMBLING COMPONENTS****CAUTION**

**BEARINGS MUST ROTATE FREELY, WITHOUT JAMMING AND/OR NOISE, OTHERWISE, THEY NEED TO BE REPLACED.**

- Only use ORIGINAL Aprilia SPARE PARTS.
- Comply with lubricant and consumables use guidelines.
- Lubricate parts (whenever possible) before reassembling them.
- When tightening nuts and screws, start either from the components with the largest diameter or from the innermost components, proceeding diagonally. Tighten nuts and screws in successive steps before applying the tightening torque.
- Always replace self-locking nuts, washers, sealing rings, circlips, O-rings (OR), cotter pins and screws with new parts if the thread is damaged.
- When assembling the bearings, make sure to lubricate them well.
- Check that each component is assembled correctly.
- After a repair or routine maintenance, carry out pre-ride checks and test the vehicle on private grounds or in an area with low traffic.
- Clean all mating surfaces, oil seal rims and gaskets before refitting. Smear a thin layer of lithium-based grease on the oil seal rims. Reassemble oil seals and bearings with the brand or batch number facing outward (visible side).

**ELECTRICAL CONNECTORS**

Electric connectors must be disconnected as described below; failure to comply with this procedure causes irreparable damage to both the connector and the wiring harness:

Press the relative safety clips, if applicable.

- Grip the two connectors and disconnect them by pulling them in opposite directions.

- If any signs of dirt, rust, moisture, etc. are noted, clean the inside of the connector carefully with a jet of compressed air.
- Ensure that the cables are correctly fastened to the internal connector terminals.
- Then connect the two connectors, ensuring that they couple correctly (if fitted with clips, you will hear them "click" into place).

**CAUTION**

**DO NOT DISCONNECT CONNECTORS BY PULLING THE CABLES.**

**NOTE**

**THE TWO CONNECTORS CAN ONLY BE CONNECTED IN ONE DIRECTION: CONNECT THEM THE RIGHT WAY ROUND.**

**TIGHTENING TORQUES****CAUTION**

**IN THE EVENT THAT A SELFBRAKING NUT IS UNSCREWED, IT IS NECESSARY TO REPLACE IT WITH A NEW ONE.**

**CAUTION**

**REMEMBER THAT THE TIGHTENING TORQUES FOR ALL FASTENING ELEMENTS ON WHEELS, BRAKES, WHEEL AXLES AND ANY OTHER SUSPENSION COMPONENTS PLAY A KEY ROLE IN ENSURING VEHICLE SAFETY AND MUST COMPLY WITH SPECIFIED VALUES. CHECK THE TIGHTENING TORQUES OF FASTENING ELEMENTS ON A REGULAR BASIS AND ALWAYS USE A TORQUE WRENCH TO REASSEMBLE THESE COMPONENTS. FAILURE TO COMPLY WITH THESE RECOMMENDATIONS MAY CAUSE ONE OF THESE COMPONENTS TO LOOSEN OR EVEN DETACH, CAUSING A WHEEL TO LOCK OR COMPROMISING VEHICLE HANDLING. THIS MAY LEAD TO FALLS, WITH THE RISK OF SERIOUS INJURY OR DEATH.**

## Running-in

Running the engine in correctly is essential for ensuring engine longevity and functionality. Twisty roads and gradients are ideal for running in the engine, brakes and suspension effectively. Vary your riding speed during the running in period. This ensures that components operate in "loaded" conditions and then "unloaded" conditions, allowing the engine components to cool.

**CAUTION**

**THE FULL PERFORMANCE OF THE VEHICLE IS ONLY AVAILABLE AFTER THE SERVICE AT THE END OF THE RUNNING IN PERIOD.**

**Follow these guidelines:**

- Do not twist the throttle grip abruptly and completely when the engine is working at a low revs, either during or after run-in.
- During the first 100 Km (62 miles) use the brakes gently, avoiding sudden or prolonged braking. That is to permit the adequate adjustment of the pad friction material to the brake discs.



**AFTER THE SPECIFIED MILEAGE, TAKE YOUR VEHICLE TO AN Official Aprilia Dealer FOR THE CHECKS INDICATED IN THE "AFTER-RUN-IN" TABLE IN THE SCHEDULED MAINTENANCE SECTION TO AVOID INJURING YOURSELF, OTHERS AND /OR DAMAGING THE VEHICLE.**

## Vehicle identification

Write down the chassis and engine number in the specific space in this booklet. The chassis number is handy when purchasing spare parts.

### CAUTION



**THE MODIFICATION OF THE IDENTIFICATION CODES IS A SERIOUS PUNISHABLE CRIME. HOWEVER, THE LIMITED WARRANTY FOR NEW VEHICLES WILL BE VOID IF THE VEHICLE IDENTIFICATION NUMBER (VIN) HAS BEEN MODIFIED OR NOT PROMPTLY DETERMINED.**

This number consists of numbers and letters, as in the example shown below.

**ZD4SMA000YSXXXXXX**

### KEY:

**ZD4:** WMI (World manufacturer identifier) code;

**SM:** model;

**A00:** version variation

**0:** free digit

**Y** year of manufacture


**S:** production plant (S= Scorzè);

**XXXXXX:** serial number (6 digits);

### ENGINE NUMBER

The engine number is printed on the base of the engine crankcase, left hand side.

Engine No. ....



### CHASSIS NUMBER

The chassis number is stamped on the right side of the headstock.

Chassis No. ....

## Dimensions and mass

### DIMENSIONS

Specification	Desc./Quantity
Max. length	2210 mm (87.01 in)
Max. width (at hand guards)	905 mm (35.63 in)
Max. height	1185 mm (46.65 in)
Saddle height	900 mm (35.43 in)
Wheelbase	1505 mm (59.25 in)
Kerb weight	206 kg (454 lb)
Dry weight (unfuelled)	196 kg (432 lb)

## Engine

### ENGINE

Specification	Desc./Quantity
Model	M551M
Type	90° longitudinal V-twin, 4-stroke, 4 valves per cylinder, 2 over-head camshafts.
No. of cylinders	2
Total engine capacity	749.9 cm <sup>3</sup> (45.76 cu.in)
Bore / stroke	92 x 56.4 mm (3.62 x 2.22 cu.in)
Intake valve clearance	0.11 - 0.18 mm (0.0043 - 0.0071 in)
Exhaust valve clearance	0.16 - 0.23 mm (0.0063 - 0.0091 in)
Compression ratio	11.0: 1
Electric	Electric starter
Engine idle speed	1400 ± 100 rpm
Clutch	Multiple-disk, oil-bathed clutch with control on the left side of the handlebar
Lubrication system	Wet crankcase. Pressure system regulated by a trochoidal pump
Air filter	With dry cartridge filter
Cooling	Fluid

### GEARBOX

Specification	Desc./Quantity
Type	Mechanical, 6 speeds with foot lever on the left hand side of the engine

## Transmission

### GEAR RATIOS

Specification	Desc./Quantity
Gear ratio	Gear primary drive 38/71
1st gear ratio	14/36 (secondary)
2nd gear ratio	17/32 (secondary)
3rd gear ratio	20/30 (secondary)
4th gear ratio	22/28 (secondary)
5th gear ratio	23/26 (secondary)
6th gear ratio	24/25 (secondary)
Final drive gear ratio	16/46

## Capacities

### CAPACITY

Specification	Desc./Quantity
Fuel capacity (reserve included)	12 l (2.64 UKgal; 3.17 US gal)
Fuel reserve	2.8 l (0.62 UKgal; 0.74 US gal)
Engine oil	3.0 l (without oil filter change) (0.66 UKgal; 0.79 USgal) 3.2 l (with oil filter change) (0.70 UKgal; 0.85 USgal)
Fork oil (check also the correct air level in the stem) (Showa)	494 cm <sup>3</sup> (RIGHT stem) (30.14 cu.in) 498 cm <sup>3</sup> (LEFT stem) (30.38 cu.in)
Fork oil (check also the correct air level in the stem) (Sachs)	459 cm <sup>3</sup> (RIGHT stem) (28.01 cu.in) 441 cm <sup>3</sup> (LEFT stem) (26.91 cu.in)
Coolant	1.8 l (0.40 UKgal; 0.48 USgal)
Seats	2
Maximum weight limit	400 kg (882 lb)

## Drive chain

### DRIVE CHAIN

Specification	Desc./Quantity
Type	Endless (without master link) and with sealed links. No. of links 108
Model	525 ZRPK

## Electrical system

### ELECTRICAL SYSTEM

Specification	Desc./Quantity
Battery	12 V - 10 Ah or 12 V - 12 Ah
Main fuses	30A
Secondary fuses	3A, 10A, 15A, 20A
ABS fuses	20 A
Alternator (permanent magnet type)	13.5 V - 450 W at 6000 rpm

### SPARK PLUGS

Specification	Desc./Quantity
Standard spark plugs	NGK CR7EKB
Spark plug electrode gap	0.6 - 0.7 mm (0.024 - 0.028 in)
Resistance	5 kOhm

### BULBS

Specification	Desc./Quantity
High beam light	12 V - 60 W H4
Low beam light	12 V - 50 W H4
Front daylight running light	12V - 6W H6
Turn indicator light	12V - 10W
Rear daylight running light / stop light	LED
License plate light	12V - 5W
Rpm indicator lighting	LED
Multifunction display lighting	LED

### WARNING LIGHTS

Specification	Desc./Quantity
High beam light	LED
Right turn indicator	LED
Left turn indicator	LED
General warning	LED
Gear in neutral	LED
Side stand down	LED
Fuel reserve	LED
ABS	LED

## Frame and suspensions

### CHASSIS


Specification	Desc./Quantity
Type	Component chassis (bolted). Die-cast aluminium plates and high-strength steel tubular chassis.
Steering inclination angle	25.8°
Trail	108 mm (4.25 in)

**SUSPENSIONS**

Specification	Desc./Quantity
Front	Upside-down telescopic hydraulic fork. Stem diam. 43 mm (1.69 in)
Travel	160 mm (6.3 in)
Rear	Oscillating swingarm and adjustable hydraulic single shock absorber
Wheel travel	155 mm (6.1 in)

**SIZES A AND B**

Specification	Desc./Quantity
Size A	693.1 mm (27.29 in)
Size B	369.8 mm (14.56 in)

**Brakes****BRAKES**

Specification	Desc./Quantity
Front	Double floating disc, Ø 320 mm (12.60 in), radially-mounted callipers with four plungers- two of them Ø 27 mm (1.06 in), 2 diam. 32.03 mm (1.26 in) and 4 pads
Rear	240 mm diam. (9.45 in) disc brake with a single 35 mm (1.38 in) diam. piston calliper

**Wheels and tyres****WHEEL RIMS**

Specification	Desc./Quantity
Type	Light alloy rims with extractable bolt
Front	3.50 x 17"
Rear	6.00 x 17"

**TYRES**

Specification	Desc./Quantity
Tyre type (standard)	DUNLOP SPORTMAX QUALIFIER
Front tyre	120/70 ZR17"
Front tyre pressure	rider only: 2.3 bar (230 kPa) (33.36 PSI) rider + passenger: 2.4 bar (240 kPa) (34.81 PSI)
Rear tyre	180/55 ZR17"
Rear tyre pressure	rider only: 2.5 bar (250 kPa) (36.26 PSI) rider + passenger: 2.7 bar (270 kPa) (39.16 PSI)

Supply


FUEL SYSTEM

Specification	Desc./Quantity
Type	Electronic injection (Multipoint)
Throttle valve diameter	Ø 52 mm (2.05 in)
Fuel	Premium unleaded petrol, minimum octane rating 95 (NORM) and 85 (NOMM)

Tightening Torques


Chassis

Front side




COOLING SYSTEM

pos.	Description	Type	Quantity	Torque	Notes
1	Fan fastener screw	-	3	3 Nm (2.21 lbf ft)	-
2	Flanged TE screw fixing LH side radiator to trellis frame and radiator bracket to engine	M6x25	2	10 Nm (7.37 lbf ft)	-



**FORCELLA ANTERIORE - SHOWA**


Pos.	Descrizione	Tipo	Quantità	Coppia	Note
1	Screws (fasten onto fork hubs)	M8x40	4	25 Nm (18.44 lb ft)	-
2	ABS sensor fastener screw	M5	1	6 Nm (4.42 lbf ft)	-
3	ABS sensor plate fastener screw	M5x12	2	6 Nm (4.42 lbf ft)	-



**FRONT FORK - SACHS**

pos.	Description	Type	Quantity	Torque	Notes
1	Screws (fasten onto fork hubs)	M8x40	4	25 Nm (18.44 lb ft)	-

pos.	Description	Type	Quantity	Torque	Notes
2	Bottom screw	-	2	30 Nm (22.13 lb ft)	Loctite 242
3	Cap		2	20 Nm (14.75 lb ft)	-
4	Nut on pumping member pin		2	20 Nm (14.75 lb ft)	-
5	ABS sensor fastener screw	M5	1	6 Nm (4.42 lbf ft)	-
6	ABS sensor plate fastener screw	M5x12	2	6 Nm (4.42 lbf ft)	-




**OPTION 01-** Steering upper plate **without** a headstock cut.

#### STEERING - OPTION 1


pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-
2	Headstock cap	M22x1	1	100 Nm (73.75 lb ft)	-
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-
4	TCEI screw fastening U-bolt onto fork yoke	M10x60	2	50 Nm (36.88 lb ft)	-

**OPTION 02-** Steering upper plate **with** a headstock cut.




**STEERING**

pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-
2	Headstock nut - pre-tightening	M22x1	1	10 Nm (7.37 lb ft)	Loctite 243
2	Headstock nut	M22x1	1	25 Nm (18.44 lb ft)	Loctite 243
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-
4	TCEI screw fastening U-bolt onto fork yoke	M10x60	2	50 Nm (36.88 lb ft)	-
5	Steering upper plate clamp closing screw	M8x30	1	25 Nm (18.44 lb ft)	Loctite 243



**INSTRUMENT PANEL**


pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening instrument panel mounting to fork yoke	M6x20	2	10 Nm (7.37 lbf ft)	-



**FRONT MUDGUARD**


pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening fork guard to calliper mounting bracket	M5x9	6	6 Nm (4.42 lbf ft)	Loct. 243

pos.	Description	Type	Quantity	Torque	Notes
2	TBEI screw fastening mudguard to stanchions	M5x9	4	4 Nm (2.95 lbf ft)	-
3	Screw fastening number panel to headlamp	-	4	1 Nm (0.74 lbf ft)	-




**HANDLEBAR**

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening counterweight to handlebar end	M6x50	2	10 Nm (7.37 lbf ft)	-
2	Stainless steel TCC screw fastening upper U-bolt to lower clamp	M8x25	4	25 Nm (18.44 lbf ft)	-
3	Screws fastening light switch assembly	-	2 + 2	1.5 Nm (1.11 lbf ft)	-
4	Light switch locking screws (Option)	M4	2	1.5 Nm (1.11 lbf ft)	-




**CLUTCH PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch cylinder fastener	M6	2	10 Nm (7.37 lbf ft)	-
2	Pipe union with bleed outlet (Heng Tong) fastening pipe to cylinder	M10x1	1	25 Nm (18.44 lbf ft)	-
3	Fastener for clutch pump on handle-bar	-	2	10 Nm (7.37 lbf ft)	-
4	Screw fastening clutch control mounting on flywheel side crankcase half	M6	1	12 Nm (8.85 lbf ft)	-




**FRONT BRAKE PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Pipe union fastening brake pipe to pump	M10x1	1	25 Nm (18.44 lbf ft)	-
2	Fastener for front brake pump on handlebar	-	2	10 Nm (7.37 lbf ft)	-




**HEADLAMP**

pos.	Description	Type	Quantity	Torque	Notes
1	TE screw fastening headlamp to headlamp mounting and mudguard to steering base	M6x16	2	10 Nm (7.37 lbf ft)	-
2	Fastener for front turn indicators	M5	2	3 Nm (2.21 lbf ft)	-
3	TCEI screw fastening headlamp mounting to fork yoke	M6	3	10 Nm (7.37 lbf ft)	-


**FRONT BODYWORK**

pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening front side panels to tank	M5x9	6	4 Nm (2.95 lbf ft)	-
2	TBEI screw fastening front side panels and duct to radiator	M6x16	4	6 Nm (4.42 lbf ft)	-
3	TBEI screw fastening ignition block cover to spacer	M5x9	3	4 Nm (2.95 lbf ft)	-
-	Front tank fastener spacer	M6	2	10 Nm (7.37 lbf ft)	-



**FRONT WHEEL**

pos.	Description	Type	Quantity	Torque	Notes
1	Wheel axle nut	-	1	80 Nm (59 lbf ft)	-
2	TE flanged screw fastening front disc	M8x20	12	30 Nm (22.13 lbf ft)	Loctite 243




**FRONT BRAKE**

pos.	Description	Type	Quantity	Torque	Notes
1	Flanged TE screw fastening calliper	M10x1.25x55	4	50 Nm (36.88 lbf ft)	-


pos.	Description	Type	Quantity	Torque	Notes
2	Pipe union with bleed outlet (Heng Tong)	M10x1	2	25 Nm (18.44 lbf ft)	-
-	Fastener for brake pipe on steering base	M6x25	1	10 Nm (7.37 lbf ft)	-

## Central part




### FRONT CHASSIS

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening shock absorber counterplate to RH frame bracket	M10x30	1	50 Nm (36.88 lbf ft)	-
2	TC TORX screw fastening trellis frame to frame side panels	M12x53	4	80 Nm (59 lbf ft)	-
3	Screw fastening chain roller bracket to LH plate	M8x35	1	25 Nm (18.44 lbf ft)	Loctite 243
4	Screw fastening chain roller to chain roller bracket	M8x45	1	25 Nm (18.44 lbf ft)	Loctite 243
5	Screw fastening chain roller bracket to LH plate	M8x20	1	25 Nm (18.44 lbf ft)	Loctite 243




**CENTRE FRAME**

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screws fastening side panels to engine	M12x282	3	80 Nm (59 lbf ft)	-
2	TCEI screw fastening lambda probe plate to RH frame (pre-fit on RH side panel)	M4x10	2	3 Nm (2.3 lbf ft)	-
3	SWP self-tapping screw fastening demand sensor mounting to demand sensor	M5x14	4	2.6 Nm (1.92 lbf ft)	-
4	Flanged TE screw fastening demand sensor to frame	M6x20	3	10 Nm (7.37 lbf ft)	-




**FOOTPEGS**

pos.	Description	Type	Quantity	Torque	Notes
1	Upper screw fastening passenger footrests to frame side panels	M8x35	2	25 Nm (18.44 lbf ft)	Loct. 243
2	Lower TCEI screw fastening passenger footrests to rider footrest mounting	M8x35	2	25 Nm (18.44 lbf ft)	Loct. 243
3	TCEI screw fastening rider footrest mounting to frame	M8x35	4	28 Nm (20.65 lbf ft)	Loctite 243




STAND ASSEMBLY

pos.	Description	Type	Quantity	Torque	Notes
1	Stand screw	M10x1.25	1	10 Nm (7.37 lbf ft)	Loctite 243
2	Thin nut	M10x1.25	1	30 Nm (22.13 lbf ft)	Loctite 243
3	Spring fixing pin	-	1	7.5 Nm (5.53 lbf ft)	-
4	TCEI screw fastening stand switch	M5x16	2	7 Nm (5.16 lbf ft)	-




FUEL TANK

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening filler cap flange	M5x16	5	3 Nm (2.21 lbf ft)	-
2	Rear TE screw fastening tank	M6x90	1	10 Nm (7.37 lbf ft)	-



**FUEL PUMP**


pos.	Description	Type	Quantity	Torque	Notes
1	TEFL screw fastening fuel pump	M5x16	6	6 Nm (4.42 lbf ft)	-



**AIR FILTER BOX**


pos.	Description	Type	Quantity	Torque	Notes
1	Cross head self-tapping screw fastening separator / filter box	M5x20	10	3 Nm (2.21 lbf ft)	-

pos.	Description	Type	Quantity	Torque	Notes
2	SWP self-tapping screw	M2.9x12 TCCR	2	3 Nm (2.21 lbf ft)	-
3	Cross head self-tapping screw fastening cover / filter box	M5x20	8	3 Nm (2.21 lbf ft)	-
4	Cross head self-tapping screw fastening lateral cap / filter box	M5x20	3	3 Nm (2.21 lbf ft)	-
-	Cross head self-tapping screw	M5x10	2	3 Nm (2.21 lbf ft)	-




### ENGINE

pos.	Description	Type	Quantity	Torque	Notes
1	Flanged TE screw fastening pinion	M10x1.25x25	1	50 Nm (36.88 lbf ft)	Loctite 270
2	TCEI screw fastening Pin to gearbox lever and Gearbox Lever to knurled shaft	M6x16	2	10 Nm (7.37 lbf ft)	-
3	LH lock nut for ball joint	M6	1	10 Nm (7.37 lbf ft)	-
4	RH lock nut for ball joint	M6	1	10 Nm (7.37 lbf ft)	-
5	Screw fastening engine bracket / clutch side crankcase half	M6	2	12 Nm (8.85 lbf ft)	-
6	Map sensor union (brass)	-	2	2 Nm (1.48 lbf ft)	Loctite 243
6	Map sensor union (steel)	-	2	3.50 Nm (2.58 lbf ft)	Loctite 243
7	LH ball joint on gearbox control lever	-	1	10 Nm (7.37 lbf ft)	Loctite 243
8	RH ball joint on gearbox control lever	-	1	10 Nm (7.37 lbf ft)	Loctite 243
-	Fastener for positive cable on engine	-	1	10 Nm (7.37 lbf ft)	-
-	TE screw fastening negative cable to engine	M6x12	1	10 Nm (7.37 lbf ft)	-




### ELECTRICAL SYSTEM 1

pos.	Description	Type	Quantity	Torque	Notes
1	Coil fixing screw	M6	2	13 Nm (9.59 lbf ft)	-
2	TE screw fastening regulator to frame	M6x30	2	10 Nm (7.37 lbf ft)	-




ELECTRICAL SYSTEM 2

pos.	Description	Type	Quantity	Torque	Notes
1	Screw fastening ECU to filter box base	-	4	2.5 Nm (1.47 lbf ft)	-
-	Starter relay fastener	-	2	3 - 4.2 Nm (2.21 - 3.1 lbf ft)	-



LOCKS


pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw	M8x40	1	25 Nm (18.44 lbf ft)	-
2	Switch fastener	shear head screw	1	Manual	-
3	TE screw fastening saddle lock / battery compartment to saddle mounting	M6x25	2	10 Nm (7.37 lbf ft)	-



**THROTTLE BODY**


pos.	Description	Type	Quantity	Torque	Notes
1	Intake union fastener screw	M6	8	12 Nm (8.85 lb ft)	Loctite 242
2	RBW control unit fastener screw	M5	2	3.50 Nm (2.58 lbf ft)	Loctite 242
3	Injector fastener screw	M6	2	12 Nm (8.85 lb ft)	Loctite 242
4	Injection Throttle Body fastener screw	M6	8	12 Nm (8.85 lb ft)	Loctite 242

**Back side**




**SADDLE MOUNTING**

pos.	Description	Type	Quantity	Torque	Notes
1	Upper LH TCEI screw fastening saddle mounting to frame	M8x55	1	25 Nm (18.44 lbf ft)	-
2	Upper RH TCEI screw fastening saddle mounting to frame	M8x60	1	25 Nm (18.44 lbf ft)	-
3	Lower TCEI screw fastening Saddle mounting to frame	M8x40	2	25 Nm (18.44 lbf ft)	-
-	TCEI screw fastening passenger grab handles to frame	M8x80	4	30 Nm (22.13 lbf ft)	-


**SWINGARM**

pos.	Description	Type	Quantity	Torque	Notes
1	Swingarm Pin adjustment bushing	-	1	12 Nm (8.85 lb ft)	-
2	Swingarm pin ring nut	-	1	60 Nm (44.25 lb ft)	-
3	Swingarm pin nut	-	1	90 Nm (66.38 lb ft)	-
4	TPSI screw fastening rear stand bushing	M6x40	2	10 Nm (7.37 lb ft)	-
5	TBEI screw fastening chain guard to swingarm	M5x9	1	6 Nm (4.42 lbf ft)	-
6	TBEI screw fastening rear mudguard to swingarm	M5x9	2	6 Nm (4.42 lbf ft)	Loctite 243
7	TBEI screw fastening chain guard to rear mudguard	M5x9	1	4 Nm (2.95 lbf ft)	-
8	TBEI screw fastening chain guide to swingarm	M5x9	2	6 Nm (4.42 lbf ft)	-
9	Wheel axle nut	M25x1.5	1	120 Nm (88.5 lbf ft)	-
10	Flanged TBEI screw fastening chain casing	M5x9	2	4 Nm (2.95 lbf ft)	Loctite 243




**REAR SUSPENSION**

pos.	Description	Type	Quantity	Torque	Notes
1	Upper TCEI mounting screw	M10x50	1	50 Nm (36.88 lbf ft)	-
2	Lower TCEI mounting screw	M10x90	1	50 Nm (36.88 lbf ft)	-




## EXHAUST SYSTEM

pos.	Description	Type	Quantity	Torque	Notes
1	SERPRESS self-locking nut fastening flange on head	M8	4	25 Nm (18.44 lbf ft)	-
2	Primary Clamp (between front/rear manifolds and central manifold)	M6	2	7 Nm (5.16 lbf ft)	-
3	Silencer Clamp (between central manifold and silencer)	M6	1	7 Nm (5.16 lbf ft)	-
4	Self-tapping TE screw fastening silencer mounting bracket to saddle mounting	M8x20	2	25 Nm (18.44 lbf ft)	-
5	Self-tapping TE screw fastening front silencer fixture to silencer mounting bracket	M8x35	2	35 Nm (25.81 lbf ft)	-




## REAR WHEEL

pos.	Description	Type	Quantity	Torque	Notes
1	Lower self-locking nut fastening sprocket to sprocket carrier	M10	5	50 Nm (36.88 lb ft)	-
2	TCEI screw fastening flexible coupling mounting on wheel	M10x30	5	50 Nm (36.88 lb ft)	Loctite 270




**REAR BRAKE**

pos.	Description	Type	Quantity	Torque	Notes
1	Rear brake lever pin	M6	1	25 Nm (18.44 lbf ft)	-
2	Flanged TE screw fastening pump to footrest mounting	M6x20	2	10 Nm (7.37 lbf ft)	-
3	TBEI screw fastening oil pipe to swingarm and rubber pipe to footrest mounting	M5x12	4	6 Nm (4.42 lbf ft)	-
4	Flanged self-locking nut	M6	1	10 Nm (7.37 lbf ft)	-
5	Screw + nut fastening pedal to brake lever	M6	1+1	10 Nm (7.37 lbf ft)	-
6	Brake pipe union	M10x1	2	25 Nm (18.44 lbf ft)	-
1	Flanged TE screw fastening rear disc	M8x20	5	30 Nm (22.13 lbf ft)	Loctite 243
7	ABS sensor fastener screw	M5	1	6 Nm (4.42 lbf ft)	-
-	Flanged TE screw	M6x16	1	10 Nm (7.37 lbf ft)	-




TAILLIGHT

pos.	Description	Type	Quantity	Torque	Notes
1	TE screw fastening tail light to li- cense plate mounting frame	M6x45	3	10 Nm (7.37 lbf ft)	-
2	Fastener for rear turn indicators	M6	2	3 Nm (2.21 lbf ft)	-
3	Reflector fastener	M5	2	2 Nm (1.47 lbf ft)	-
4	Fastener for license plate light	M5	1	5 Nm (3.69 lbf ft)	-




**REAR BODYWORK 1**

pos.	Description	Type	Quantity	Torque	Notes
1	Screws fastening battery cover to compartment	M5	2+1	4 Nm (2.95 lbf ft)	-
2	TBEI screw fastening battery compartment to saddle mounting	M5x9	2	6 Nm (4.42 lbf ft)	-



**REAR BODYWORK 2**

pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening LH - RH covers to silencer	M6x20	4	10 Nm (7.37 lbf ft)	-
2	TBEI screw fastening tail fairing to saddle mounting	M5x9	2	6 Nm (4.42 lbf ft)	-
3	Screw fastening tail fairing to battery compartment	-	3	4 Nm (2.95 lbf ft)	-



**REAR BODYWORK 3**


pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening license plate mounting to mounting	M5x9	3	6 Nm (4.42 lbf ft)	-
2	Fastener for license plate mounting frame assembly to gusset plate - saddle lock	M6	4	10 Nm (7.37 lbf ft)	-
3	Screw fastening license plate mounting cover to license plate mounting	-	3	0.8 Nm (0.59 lbf ft)	-



**ABS SYSTEM**


pos.	Description	Type	Quantity	Torque	Notes
-	ABS ECU fastener screw	M6x25	1	10 Nm (7.37 lbf ft)	Loctite 243
-	ABS ECU fastener nut	M6	2	10 Nm (7.37 lbf ft)	-

**Engine**




**HEAD COVER**

pos.	Description	Type	Quantity	Torque	Notes
1	Special screw for fastening head cover	M6	8	9 Nm (6.64 lbf ft)	-


**HEAD**

pos.	Description	Type	Quantity	Torque	Notes
1	Water Temperature Sensor	M12x1.5	1	23 Nm (16.96 lbf ft)	-
2	Threaded plug for water sensor seat	M12x1.5	1	10 Nm (7.38 lbf ft)	Loctite Drise AL 506
3	Head stud bolt fastener nut - pre-tightening	M10x1.25	8	10 Nm (7.38 lbf ft)	Lubricate the threads before tightening
3	Head stud bolt fastener nut - tightening	M10x1.25	8	13 Nm (9.59 lbf ft) + 90° + 90°	Lubricate the threads before tightening
4	Fastener for Head / Cylinder / Outer side crankcase	M6	2	13 Nm (9.59 lbf ft)	-
5	Fastener for Head / Cylinder / Inner side crankcase	M6	4	12 Nm (8.85 lbf ft)	-
6	Nut fastening Stud Bolts / Head	M6	4	12 Nm (8.85 lbf ft)	-
7	Nut fastening Stud Bolts / Head	M8	2	26 Nm (19.18 lbf ft)	-
8	Bleed union fastener screw	M5	4	6.5 Nm (4.79 lbf ft)	-
9	Water bleed union (steel)	-	1	3.50 Nm (2.58 lbf ft)	Loctite 243
10	Water bleed union (brass)	-	2	2 Nm (1.48 lbf ft)	Loctite 243



**CYLINDER**


pos.	Description	Type	Quantity	Torque	Notes
1	Chain tensioner fastener screw	M6	4	13 Nm (9.59 lb ft)	-
2	Cylinder plate fastener screw	M6	4	7.84-9.81 Nm (5.78-7.23 lb ft)	-
3	Chain tensioner adjustment screw	M6	2	5.50 Nm (4.06 lb ft)	-




**TIMING SYSTEM**

pos.	Description	Type	Quantity	Torque	Notes
1	Camshaft gear fastener nut - pre-tightening	M15x1	4	30 Nm (22.13 lbf ft)	-
1	Camshaft gear fastener nut - tightening	M15x1	4	90 Nm (66.38 lbf ft)	-
2	Timing drive gear fastener screw	M24x1.5	2	40 Nm (29.50 lbf ft)	3M SCOTCH GRIP 2353
3	Special screw for fastening mobile / fixed shoes	M8	4	19 Nm (14.01 lbf ft)	Loctite 242

pos.	Description	Type	Quantity	Torque	Notes
4	Cam tower / head fastener screws - pre-tightening	M6	16	4.90 - 6.86 Nm (3.61 - 5.06) lbf ft	-
4	Cam tower / head fastener screws - tightening	M6	16	9.81 - 12.75 Nm (7.24 - 9.40 lbf ft)	-
4	Viti fissaggio castelletto / testa - serraggio	Torx	16	12 - 14 Nm (8.85 - 10.32 lbf ft)	-
5	Camshaft retainer plate fastener screw	torx M3	8	3 Nm (2.21 lbf ft)	Loctite 270


**CRANKSHAFT**

pos.	Description	Type	Quantity	Torque	Notes
1	Crankshaft primary gear fastener nut	M24x1.5	1	270 Nm (199.14 lbf ft)	Anticlockwise nut
2	Connecting rod screw	M10	4	15 + 30 Nm (11.06 + 22.13 lbf ft) + 50° ± 2°, final control torque 65 - 78 Nm (47.94 - 57.53 lbf ft)	Lubricate the threads before tightening




#### OIL PUMP

pos.	Description	Type	Quantity	Torque	Notes
1	Oil drainage plug	M16x1.5	1	19 Nm (14.01 lbf ft)	-
2	Fastening oil sensor on clutch side crankcase half	-	1	13 Nm (9.59 lbf ft)	-
3	Fastening oil filter union on clutch side crankcase half	-	1	20 Nm (14.75 lbf ft)	-
4	Oil filter	-	1	14 Nm (10.33 lbf ft)	-
5	Oil pressure regulator valve	3/4" Unf 16	1	43 Nm (31.72 lbf ft)	-
6	Oil pump fastener screw	M6	2	5.50 Nm (4.06 lbf ft)	Loctite 242
7	Rose pipe fastener screw	-	2	12 Nm (8.85 lbf ft)	-
8	Complete oil pump gear fastener	M5	1	10 Nm (7.37 lbf ft)	Loctite 270
9	Oil pump cover fastener screw	M3	2	0.80 Nm (0.59 lbf ft)	-
10	Complete oil pump gear fastener	-	1	9-11 Nm (6.64-8.11 lbf ft)	-




#### GEAR SELECTOR

pos.	Description	Type	Quantity	Torque	Notes
1	Gear retainer pawl fastener screw	M6	1	12 Nm (8.85 lb ft)	Loctite dry loc 2040
2	Selector plate fastener screw	M5	3	5.50 Nm (4.06 lb ft)	3M SCOTCH GRIP 2353
3	Screw fastening Desmodromic selector drum / Selector sprocket	M8	1	20 Nm (14.75 lb ft)	3M SCOTCH GRIP 2353
4	Gear sensor fastener screw	M5	2	5.50 Nm (4.06 lb ft)	Loctite 270
5	Selector pin fastener onto clutch side crankcase half	M10x1.5	1	16 Nm (11.80 lb ft)	Loctite 242
6	Gear retainer pawl fastener pin	-	1	11-13 Nm (8.11-9.59 lb ft)	-
7	Gear retainer pawl fastener flanged nut	-	1	10-12 Nm (7.38-8.85 lb ft)	-



**CLUTCH COVER**


pos.	Description	Type	Quantity	Torque	Notes
1	Fastener screw for Clutch Cover / Clutch side cover	M6	6	13 Nm (9.59 lbf ft)	-
2	Clutch fastener nut	M24x1.5	1	180 Nm (132.76 lbf ft) ± 5%	Chamfer
3	Fastening oil filler plug on Clutch cover	-	1	2 Nm (1.48 lbf ft)	-
4	Screw fastening fixing Plate / Clutch control Mounting	M5	3	5.50 Nm (4.06 lbf ft)	-
5	Screw fastening clutch control mounting on flywheel side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-



**CLUTCH**


pos.	Description	Type	Quantity	Torque	Notes
1	Clutch spring fastener screw	M6	6	12 Nm (8.85 lbf ft)	-

**OPTION 01**




**WATER PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch side cover fastener screw	M6	13	13 Nm (9.59 lbf ft)	-
2	Fastener screw for Pump Cover / Clutch side cover	M6	3	13 Nm (9.59 lbf ft)	-
3	Screw fastening Pump Cover / Clutch Cover / clutch side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-
4	Nut fastening pump drive input gear on shaft	M6	1	12 Nm (8.85 lbf ft)	Loctite 244
5	Water pump rotor	-	1	4.50 Nm (3.32 lbf ft)	-


**OPTION 02****WATER PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch side cover fastener screw	M6	11	13 Nm (9.59 lbf ft)	-
2	Fastener screw for Pump Cover / Clutch side cover	M6	3	13 Nm (9.59 lbf ft)	-
3	Screw fastening Pump Cover / Clutch Cover / clutch side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-
4	Nut fastening water pump drive gear sprocket	M6	1	12 Nm (8.85 lbf ft)	-
5	Water pump rotor	-	1	4.50 Nm (3.32 lbf ft)	-
6	Screw fastening chain tensioner slider to water pump	M6	1	8-10 Nm (5.90-7.38 lbf ft)	-
7	Water pump support fixing screw	M6	3	12 Nm (8.85 lbf ft)	-
8	Water pump support plug	M6x10	1	6.5 Nm (4.79 lbf ft)	3M SCOTCH GRIP 2353




# **IGNITION**

pos.	Description	Type	Quantity	Torque	Notes
1	Spark plug	-	2	13 Nm (9.59 lbf ft)	-
2	Freewheel Ring fastener screw	M6	6	14 Nm (10.33 lbf ft)	Loctite 242
3	Screw fixing rotor - Crankshaft - (12 mm - 0.47 in)	M12x1.25	1	130 Nm (95.88 lb ft)	-
3	Screw fixing rotor - Crankshaft - (14 mm - 0.55 in)	M12x1.25	1	190-200 Nm (140.14-147.51 lb ft)	-
4	Screw fastening Stator / Flywheel Cover	M6	3	9 Nm (6.64 lb ft)	-
5	Screw fastening pick-up / Flywheel cover	M5	2	3.50 Nm (2.58 lbf ft)	-
6	Flywheel cover fastener screw	M6	10	13 Nm (9.59 lb ft)	-
7	Screw fastening starter motor bracket to crankcase	M6	2	13 Nm (9.59 lbf ft)	-
8	Crankshaft access cap	-	1	4 Nm (2.95 lb ft)	-
9	Retainer plate fastener screw	M6	1	8 Nm (5.90 lbf ft)	-
-	Screw fastening bracket to starter motor	M6x14	2	13 Nm (9.59 lbf ft)	-
-	Pick-up cable retainer screw	M5	2	3 Nm (2.21 lbf ft)	-



**CRANKCASE 1**

pos.	Description	Type	Quantity	Torque	Notes
1	Bearing retainer fastener screw	M6	3	10 Nm (7.38 lbf ft)	Loctite 270
2	Piston oil jet fastener screw	M5	2	5.50 Nm (4.06 lbf ft)	Loctite 242
3	Tapered plug for crankshaft main bearing lubrication	M8x1	4	15 Nm (11.06 lbf ft)	-
4	Calibrated Brass dowel fixed to complete crankcase	M8	2	5.50 Nm (4.06 lbf ft)	-





**CRANKCASE 2**

pos.	Description	Type	Quantity	Torque	Notes
1	Engine speed sensor fixing screw	M6	1	13 Nm (9.59 lbf ft)	Loctite 243
2	Screw fastening flywheel side / clutch side crankcase halves	M6	8	13 Nm (9.59 lbf ft)	-
3	Screw fastening flywheel side / clutch side crankcase halves	M8	9	29 Nm (21.39 lbf ft)	-
4	Special calibrated screw for gearbox lubrication	-	1	18 Nm (13.28 lbf ft)	-

**Overhaul data****Assembly clearances****Cylinder - piston assy.**

The pistons are available in four size types (A, B, C, D) to be coupled to the four cylinder types (A, B, C, D).

Only one type of piston ring is available.


**CYLINDER - PISTON COUPLING**

Specification	Desc./Quantity
Piston - cylinder coupling Type A	Cylinder: 91.990 - 91.977 mm (3.6216 - 3.6219 in) Piston: 91.933 - 91.940 mm (3.6217 - 3.6197 in)
Piston - cylinder coupling Type B	Cylinder: 91.997 - 92.004 mm (3.6219 - 3.6222 in) Piston: 91.940 - 91.947 mm (3.6197 - 3.6199 in)
Piston - cylinder coupling Type C	Cylinder: 92.004 - 92.011 mm (3.6222 - 3.6225 in) Piston: 91.947 - 91.954 mm (3.6199 - 3.6202 in)
Piston - cylinder coupling Type D	Cylinder: 92.011 - 92.018 mm (3.6225 - 3.6227 in) Piston: 91.954 - 91.961 mm (3.6202 - 3.6205 in)
Fitting clearance	0.050 - 0.064 mm (0.00197 - 0.00252 in)

Crankcase - crankshaft - connecting rod

INTERNAL MARKING ON FIRST GENERATION CRANKCASES

Crankcases are classified in two classes (1 or 2) depending on the diameter of the main bearing seat. The class is indicated on both crankcase halves, specifically, in the rear cylinder area on flywheel side crankcase halves and in the front cylinder area on clutch side crankcase halves.




CRANKCASE CLASSES

Specification	Desc./Quantity
Crankcase class 1	Bushing seat diameter: 53.954 - 53.960 mm (2.1241 - 2.1244 in)
Crankcase class 2	Bushing seat diameter: 53.960 - 53.966 mm (2.1244 - 2.1246 in)

INTERNAL MARKING ON SECOND GENERATION CRANKCASES

Crankcases are classified in two classes (1 or 2) depending on the diameter of the main bearing seat. The class is indicated on both crankcase halves, specifically, in the starter gear area on flywheel side crankcase halves and in the gearbox control mechanism area on clutch side crankcase halves.



See also

[Removing the flywheel cover](#)


There are three crankshaft classes selectable for each bearing:

- 4 - 5 - 6 for the flywheel side;
- 7 - 8 - 9 for the clutch side;

The class is stamped on the outer face of the crankshaft counterweight.

#### NOTE

**TWO DIFFERENT CRANKSHAFT CLASSES MAY BE POSSIBLE ON THE TWO BEARINGS.**



### CRANKSHAFT CLASSES

Specification	Desc./Quantity
Crankshaft classes 4 - 7	Main journals - diameter: 49.978 - 49.984 mm (1.9676 - 1.9679 in)
Crankshaft classes 5 - 8	Main journals - diameter: 49.972 - 49.978 mm (1.9674 - 1.9676 in)
Crankshaft classes 6 - 9	Main journals - diameter: 49.990 - 49.984 mm (1.9681 - 1.9679 in)

Once the categories below are checked:

- crankcase
- flywheel side main journal
- clutch side main journal

choose the bushings used for assembly from the following table

#### See also

[Removing the flywheel cover](#)

### MAIN BUSHINGS

Main journal	Crankcase class 1	Crankcase class 2
Class 4 main journal (l.v.)	Semi-bushing type A (red)	Semi-bushing type B (blue)
Class 5 main journal (l.v.)	Semi-bushing type B (blue)	Semi-bushing type C (yellow)
Class 6 main journal (l.v.)	Semi-bushing type E (green)	Semi-bushing type A (red)
Class 7 main journal (l.f.)	Semi-bushing type A (red)	Semi-bushing type B (blue)
Class 8 main journal (l.f.)	Semi-bushing type B (blue)	Semi-bushing type C (yellow)
Class 9 main journal (l.f.)	Semi-bushing type E (green)	Semi-bushing type A (red)


#### Crankcase class (internal marking on first generation crankcases)

Two different crankcase classes (A or B) are available, selected in relation to the centre-to-centre distance between the primary reduction gears.

The class is indicated on the clutch side crankcase half near the front cylinder area.

#### NOTE

**IN THE EVENT OF CRANKCASE REPLACEMENT, THE PRIMARY REDUCTION GEAR IS SUPPLIED READY MESHED.**



**CRANKCASE CLASSES 01**

Specification	Desc./Quantity
Crankcase class A	Centre-to-centre distance: 110.50 - 110.54 mm (4.3504 - 4.3519 in)
Crankcase class B	Centre-to-centre distance: 110.46 - 110.50 mm (4.3488 - 4.3504 in)

**See also**

[Removing the flywheel cover](#)


**Crankcase class (internal marking on second generation crankcases)**

Two different crankcase classes (A or B) are available, selected in relation to the centre-to-centre distance between the primary reduction gears.

The class is indicated on the clutch side crankcase half, in the gearbox control mechanism area.

**NOTE**

IN THE EVENT OF CRANKCASE REPLACEMENT, THE PRIMARY REDUCTION GEAR IS SUPPLIED READY MESHED.


**CRANKCASE CLASSES 02**

Specification	Desc./Quantity
Crankcase class A	Centre-to-centre distance: 110.50 - 110.54 mm (4.3504 - 4.3519 in)
Crankcase class B	Centre-to-centre distance: 110.46 - 110.50 mm (4.3488 - 4.3504 in)

**Class one**

Two different pinion classes (A or B) are available, selected in relation to the centre-to-centre distance between the primary reduction gears.

On class B pinions only, the class is indicated on the pinion itself.


**See also**

[Removing the flywheel cover](#)

**Crankshaft class (crank pin)**

There are four different classes of crankshaft available (0, 1, 2, 3), selected in relation to crank pin diameter.

There are four different classes of crankshaft available (E1, E2, ...) selectable in relation to connecting rod weight.



Key:

\* Class according to connecting rod weight.

\*\* Class according to crank pin diameter.

\*\*\* Serial number for traceability and indicating date.

**SHAFT CATEGORY**

Class	Crank pin diameter (mm)
0	42.000 - 42.006 mm (1.65354 - 1.65377 in)
1	41.994 - 42.000 mm (1.65330 - 1.65354 in)
2	41.988 - 41.994 mm (1.65307 - 1.65330 in)
3	41.982 - 41.988 mm (1.65283 - 1.65307 in)

**See also**

[Removing the flywheel cover](#)

**Selecting bushings**

There is only one dimension class for the connecting rod. As a result, the bushings used must be selected in accordance with the dimension class of the crank pin.

**BUSHINGS**

Crank pin diameter	Connecting rod class 1
Crankshaft class 0	Semi-bushing type E (green)
Crankshaft class 1	Semi-bushing type A (red)
Crankshaft class 2	Semi-bushing type B (blue)
Crankshaft class 3	Semi-bushing type C (yellow)

**Selecting connecting rods**

Not all weight classes are available as spare parts. Only the two most significant weight classes are available - refer to the following table for selection:

**CONNECTING RODS**

Class according to crankshaft weight	Original connecting rod class
E1	Brown connecting rod
E2	Blue connecting rod
E3	Yellow connecting rod
E4	Green connecting rod
E5	Pink connecting rod
E6	Black connecting rod
E7	White connecting rod

**CAUTION**

**THE CONNECTING RODS INSTALLED ON THE SAME ENGINE MUST BE OF THE SAME COLOUR AND MUST USE THE SAME TYPE OF ASSEMBLY WITH THE CRANKSHAFT.**

WHEN REFITTING, ALSO ENSURE THAT THE SEMI-BUSHINGS ARE ALL OF THE SAME CLASS.

See also

[Removing the flywheel cover](#)

## Recommended products chart







### RECOMMENDED PRODUCTS TABLE







Product	Description	Specifications
ENI i-RIDE PG 15W-50	Engine oil	Use branded oils with performance equivalent to or exceeding API SJ, JASO MA - ACEA A3 - JASO MA2 specifications.
AGIP FORK 5W	Fork oil (Showa)	SAE 5W
FUCHS TITAN SAF 1091 (Sachs)	Fork oil	-
AGIP MP GREASE	Black smooth textured lithium-calcium soap based grease containing EP (extreme pressure) additives with optimal water-repellent properties	ISO L-X-BCHB 2 - DIN 51 825 KP2K-20
AGIP CHAIN LUBE SPRAY	Spray lubricating grease	-
AGIP BRAKE 4	Brake fluid	SAE J 1703 - FMVSS 116 - DOT 3/4 - ISO 4925 - CUNA NC 956 DOT 4 synthetic fluid
AGIP BRAKE 5.1	Clutch fluid	FMVSS 116 - DOT 5.1 Non-silicone synthetic fluid
AGIP PERMANENT SPECIAL	Ethylene glycol-based antifreeze fluid with organic inhibition additives. Red, ready to use.	ASTM D 3306 - ASTM D 4656 - ASTM D 4985 - CUNA NC 956-16








INDEX OF TOPICS







SPECIAL TOOLS







S-TOOLS








SPECIAL TOOLS		
Stores code	Description	
020709Y	Engine support	
020710Y	Engine plate	
AP8140187	Engine support stand	
020711Y	Engine pinion locking	
020712Y	Handle for Flywheel cover removal	
020713Y	Flywheel extractor	







Stores code	Description	
020714Y	Dial gauge mounting	
020715Y	Tone wheel removal	
9100896	Clutch housing locking tool	
020716Y	Connecting rod locking	
020470Y	Pin snap ring fitting tool	
AP8140302	tool for sealing ring fitting	







Stores code	Description	
020718Y	Camshaft gear alignment pin	
020719Y	Timing pin	
020720Y	Timing tool	
AP8140179	Valve spring compressor	
020721Y	Adaptor for valve removal	
020722Y	Guide for oil seal	
020376Y	Adapter handle	




Stores code	Description	
020629Y	8 mm (0.31 in) guide	
020412Y	15-mm Oil seal guide	
020439Y	17-mm guide for oil seal	
020263Y	Sheath for fitting the driven pulley	
020365Y	22 mm (0.87 in) guide	
020364Y	25-mm Guide	

Stores code	Description	
020483Y	30 mm guide	
020441Y	Oil seal punch	
020358Y	37 x 40-mm adaptor	
020357Y	32 x 35 mm adaptor	
020359Y	42 x 47-mm adaptor	
020360Y	52 x 55-mm adaptor	

Stores code	Description	
020723Y	Jig for timing overhead camshafts	
020724Y	Gear control rod roller cage punch	
020661Y	Water pump overall seal replacement kit	
020725Y	Punch for water pump overall sealing	
020885Y	Water pump oil seal punch	
020726Y	Extractor for bushings	
020727Y	Punch for bushings	

Stores code	Description	
020884Y	46 mm wrench for steering ring nut	
AP8140180	Extractor for bushings	
8140181	manometer for fuel - oil - compression pressure	
AP8140199	Tool panel	
8140426	Hooks for panel	
020880Y	Panel graphics	

FORKS		
Stores code	Description	
020888Y	Pliers for pre-fill pipe	
020889Y	Pumping member ring nut locking spanner	
020890Y	Pumping member stanchion support rod	
AP8140146	Weight	
AP8140147	Spacer tool	
AP8140148	Spacer-piston separating plate	

Stores code	Description	
AP8140149	Protection for fitting operations	
AP8140150	Perforated rod for piston air bleed	
AP8140189	Oil seal fitting tool for Ø 43 mm (1.69 in) orifices	

INDEX OF TOPICS

MAINTENANCE

MAIN

## Maintenance chart

Correct maintenance is fundamental for ensuring the longevity of your vehicle and maintaining optimum function and performance.

To this end, Aprilia offers a set of checks and maintenance services (at the owner's expense), that are summarised in the table shown on the following page. Any minor faults must be reported without delay to an **Authorised Aprilia Dealer or Sub-Dealer** without waiting until the next scheduled service to solve it.

All scheduled services must be carried out at the specified intervals and mileage, as soon as the pre-determined mileage is reached. Carrying out scheduled services on time is essential for the validity of your warranty. For further information regarding Warranty procedures and "Scheduled Maintenance", please refer to the "Warranty Booklet".

### NOTE

**CARRY OUT MAINTENANCE OPERATIONS AT HALF THE INTERVALS SPECIFIED IF THE VEHICLE IS USED IN PARTICULAR RAINY OR DUSTY CONDITIONS, OFF ROAD OR FOR TRACK USE.**

### NOTE

**THE TIMES LISTED ON THE SCHEDULED MAINTENANCE TABLE INCLUDE TIME DEDICATED TO MANAGEMENT ACTIVITIES.**

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN, R: REPLACE, A: ADJUST, L: LUBRICATE

(1) Check and clean and adjust or replace, if necessary, every 1.000 Km (621.37 mi)

(2) Replace every 2 years

(3) Replace every 4 years

(4) At each engine start

(5) Check every month

(6) Check each time the rear tyre is replaced

(7) Replace at whichever of the following occurs first: 40.000 km (24,854 mi) or 48 months

**ROUTINE MAINTENANCE TABLE**

km x 1,000	1	5	10	15	20	25	30	35	40
Rear shock absorber					I				I
Spark plug					R				R
Drive chain (2)	I				I				I
Transmission cables and controls	I				I				I
Steering bearings and steering clearance	I				I				I
Wheel bearings					I				I
Control unit diagnosis	I				I				I
Brake discs	I				I				I
Air filter			I		R		I		R
Engine oil filter	R				R				R
Fork					I				I
General vehicle operation	I				I				I
Valve clearance	I				A				A
Cooling system					I				I
Braking systems	I				I				I
Light circuit	I				I				I

km x 1,000	1	5	10	15	20	25	30	35	40
Safety switches									
Clutch control fluid (2)									
Brake fluid (2)									
Coolant (2)									
Fork oil (7)									R
Engine oil	R				R				R
Light aiming									
Fork oil seals									
Flexible coupling (6)									
Tyres - pressure/wear (5)									
Wheels									
Bolts and nuts tightening									
Suspension and setting									
Fault warning light on instrument panel (4)									
Fuel lines (3)									
Clutch wear									
Brake pad wear									
Labour time (minutes)	230	10	30	10	340	10	30	10	400

## Spark plug

At regular intervals, remove the spark plug and clean off any carbon deposits or replace as required.

### CAUTION



**ALWAYS REPLACE BOTH SPARK PLUGS EVEN IF ONLY ONE NEEDS REPLACING.**

- Remove the saddle.
- Remove the lower air deflector.
- Remove the side fairings.

In order to reach the spark plugs:

### CAUTION




**BEFORE CARRYING OUT THE FOLLOWING OPERATIONS AND IN ORDER TO AVOID BURNS, LEAVE ENGINE AND SILENCER TO COOL OFF TO AMBIENT TEMPERATURE.**

## FRONT SPARK PLUG

- Working on the left side of the vehicle, unscrew and remove the screw.



- Undo and remove the screw, remove the horn.



- Turn the radiator forwards and lower it to act on the coil.



- Undo and remove the screw.



- Slide off the front coil.



- Unscrew and remove the front spark plug.



### REAR SPARK PLUG

- Undo and remove the two tank front screws.



- Lift the tank.
- Unscrew and remove the rear coil fixing screw.



- Slide off the rear coil.
- Unscrew and slide off the rear spark plug.



- Check the gap between the electrodes with a feeler gauge.

### CAUTION




**DO NOT ATTEMPT TO READJUST THE ELECTRODE GAP.**

The electrode gap should be between 0.6 ÷ 0.7 mm (0.023 ÷ 0.027 in). Otherwise, replace the spark plug.

- Make sure the washer is in good conditions.

Installation:

- Once the washer is fitted, screw the spark plug carefully to avoid damaging the thread.
- Tighten it using the spanner supplied in the toolkit, make each spark plug complete 1/2 a turn to press the washer.

**CAUTION**

**TIGHTEN THE SPARK PLUG CORRECTLY, OTHERWISE THE ENGINE MAY OVERHEAT AND GET IRRETRIEVABLE DAMAGED. USE ONLY THE RECOMMENDED TYPE OF SPARK PLUG, OTHERWISE, THE ENGINE DURATION AND PERFORMANCE COULD BE COMPROMISED.**

**Locking torques (N\*m)**

**Spark plug 13 Nm (9.59 lbf ft)**

---

**Engine oil**

---

**Check**

Check the engine oil level frequently.

**NOTE**

**CARRY OUT MAINTENANCE OPERATIONS AT HALF THE INTERVALS SPECIFIED IF THE VEHICLE IS USED IN PARTICULAR RAINY OR DUSTY CONDITIONS, OFF ROAD OR FOR TRACK USE.**



**ENGINE OIL LEVEL MUST BE CHECKED WHEN THE ENGINE IS WARM. IF YOU CHECK LEVEL WHEN THE ENGINE IS COLD, OIL LEVEL COULD TEMPORARILY DROP BELOW THE "MIN" MARK. THIS SHOULD NOT BE CONSIDERED A PROBLEM PROVIDED THAT THE ALARM WARNING LIGHT AND THE ENGINE OIL PRESSURE ICON DO NOT TURN ON SIMULTANEOUSLY ON THE DISPLAY.**

**CAUTION**

**DO NOT LET THE ENGINE IDLE WITH THE VEHICLE AT STANDSTILL TO WARM UP THE ENGINE AND OBTAIN THE OPERATING TEMPERATURE OF ENGINE OIL. PREFERABLY CHECK THE OIL AFTER A JOURNEY OF AFTER TRAVELLING APPROXIMATELY 15 Km (10 miles) IN EXTRAURBAN CONDITIONS (ENOUGH TO WARM UP THE ENGINE OIL TO OPERATING TEMPERATURE).**

- Shut off the engine.
- Keep the vehicle upright with both wheels on the ground.
- Check the correct oil level through the appropriate sight glass on the engine crankcase.

**MAX** = maximum level.

**MIN** = minimum level

- The oil level is correct when it is close to the "MAX" reference.



## Replacement

Check the engine oil level frequently.

**To change the oil:**


### CAUTION

**HOT OIL IS MORE FLUID AND WILL DRAIN OUT MORE EASILY AND COMPLETELY; IDEAL TEMPERATURE IS REACHED AFTER THE ENGINE HAS RUN FOR ABOUT TWENTY MINUTES.**



**OIL BECOMES VERY HOT WHEN THE ENGINE IS HOT; BE CAREFUL NOT TO GET BURNED WHEN CARRYING OUT THE OPERATIONS DESCRIBED BELOW.**

- Use a cloth to wipe off any mud deposit on the area next to the filler plug (1).
- Place a container with + 4000 cm<sup>3</sup> (244 cu.in) capacity under the drainage plug (2).
- Unscrew and remove the drainage plug (2).
- Unscrew and remove the filler plug (1).
- Drain the oil into the container; allow several minutes for oil to drain out completely.
- Replace the sealing washer of the drainage plug (2).
- Remove any metal scrap attached to the drainage plug (2) magnet.
- Screw and tighten the drainage plug (2).



**Locking torques (N\*m)****Oil drainage plug - M16x1.5 19 Nm (14.01 lbf ft)**

- Replace the oil filter.
- Fill up to the right engine oil level by adding recommended engine oil.

**See also**[Engine](#)[oil filter](#)[Check](#)**Engine oil filter**

- Drain the engine oil.
- Remove the oil filter.
- Fit a new engine oil filter.
- Add engine oil up to the correct level.

**CAUTION****NEVER REUSE AN OLD FILTER.****See also**[Replacement](#)**Air filter**

- Remove the fuel tank.
- Disconnect the air temperature sensor.



- Undo and remove the nine screws.




- Remove the clamp and slide off the blow-by tube.



- Remove the filter box cover.



- Working on both ducts, turn the upper part of the intake ducts anticlockwise and remove it.



- Remove the filtering element.



COVER THE INTAKE DUCTS WITH A CLEAN CLOTH SO THAT FOREIGN BODIES DO NOT GET INTO THE INLET DUCTS. UPON REFITTING AND BEFORE PLACING THE FILTER BOX COVER, MAKE SURE NEITHER THE CLOTH NOR ANY OTHER OBJECT HAS BEEN LEFT INSIDE THE FILTER BOX. MAKE SURE THE FILTERING ELEMENT IS CORRECTLY PLACED SO THAT UNFILTERED AIR DOES NOT FLOW IN. DO NOT FORGET THAT EARLY WEAR OF THE PISTON RINGS AND THE CYLINDER CAN BE CAUSED BY A MALFUNCTIONING OR MISPLACED FILTERING ELEMENT.



## REFITTING

- Upon refitting, pay attention when inserting intake ducts and check that the bayonet joint is released once every duct has been inserted and rotated.

## Checking the valve clearance

The following operation can be carried out also with the engine fitted on the vehicle.

- Remove both head covers.

### CAUTION

**WHENEVER THE HEAD COVER IS REMOVED, ALL FOUR RUBBER RINGS AND THE GASKET SHOULD BE REPLACED.**

- Using a thickness gauge, measure the distance between the tip of the crankshaft and the valve bowl.
- Take note of the measurement.

If valve clearance is not within the tolerance range, adjust as follows:

- Take the engine to the TDC.
- Lock the camshafts by using the corresponding timing pins.



### Specific tooling

020719Y Timing pin

### Characteristic

#### Intake valve clearance

0.11 - 0.18 mm (0.0043 - 0.0071 in)

#### Exhaust valve clearance

0.16 - 0.23 mm (0.0063 - 0.0091 in)

- Remove one camshaft at a time
- Leave the other camshaft assembled and blocked by means of the timing pin.

### CAUTION

**IF BOTH CAMSHAFTS ARE REMOVED, THE ENGINE SPINS MAKING TIMING NECESSARY.**

- Remove the bowl tappets and the adjustment shims using a magnet.

### NOTE

**GREASE THE BOWL TAPPETS AND THE ADJUSTMENT SHIMS PROPERLY EACH TIME THEY ARE REMOVED.**



- Replace calibrated pads with a pad thick enough to correct the valve clearance previously detected.
- List of calibrated break pads:

1. Calibrated pad 2.60
2. Calibrated pad 2.65
3. Calibrated pad 2.70
4. Calibrated pad 2.75
5. Calibrated pad 2.80
6. Calibrated pad 2.85
7. Calibrated pad 2.90
8. Calibrated pad 2.95
9. Calibrated pad 3.00
10. Calibrated pad 3.05
11. Calibrated pad 3.10
12. Calibrated pad 3.15
13. Calibrated pad 3.20
14. Calibrated pad 3.25
15. Calibrated pad 3.30
16. Calibrated pad 3.35
17. Calibrated pad 3.40
18. Calibrated pad 2.55
19. Calibrated pad 2.50
20. Calibrated pad 2.45
21. Calibrated pad 2.40


**CAUTION**

**BEFORE REFITTING HEAD COVERS, CLEAN HEAD AND COVER SURFACES CAREFULLY.**

- Apply THREEBOND on the head cover perimeter along the gasket housing.



- Apply THREEBOND on the head in the areas indicated in the figure.



### See also

[Removing the head cover](#)

INDEX OF TOPICS

TROUBLESHOOTING

TROUBL

**TROUBLESHOOTING PROCEDURE IF THE EFI WARNING LIGHT ON THE INSTRUMENT PANEL TURNS ON OR IF THERE IS ABNORMAL ENGINE PERFORMANCE****CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

- 1 - THE "EFI" WARNING LIGHT IS ON AND THE WORD "SERVICE" IS SHOWN or THE "EFI" WARNING LIGHT IS FLASHING AND THE WORDS "URGENT SERVICE" ARE SHOWN or ONE OF THE TWO SITUATIONS TAKES PLACE AND IS SUDDENLY OUT or THERE IS ABNORMAL ENGINE PERFORMANCE
- 2 - CONNECT TO THE CONTROL UNIT THROUGH NAVIGATOR BY SELECTING "SELF-DIAGNOSIS, APRILIA, DORSODURO, 750 i.e."
- 3 - ARE CURRENT- "ATT"- or STORED- "MEM"- ERRORS SHOWN IN THE "ERRORS DISPLAY" SCREEN PAGE?

**YES, go to 4; NO, go to 12.**

- 4 - IF THE ERROR IN THE CENTRAL WINDOW IS SELECTED AND "?" IS DISPLAYED, PRESS THE KEY "?" TO OBTAIN FURTHER INFORMATION ABOUT THE ERROR. THEN GO TO THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS" CHAPTER AND READ THE INFORMATION CONCERNING THE DEFECTIVE COMPONENT
- 5 - ACCORDING TO WHAT IS INDICATED ABOUT THE ERROR/S, PROCEED AS SUGGESTED AND SOLVE THE PROBLEM
- 6 - WAS THE PROBLEM SOLVED BY REPLACING THE MARELLI CONTROL UNIT?

**YES, go to 7; NO, go to 8.**

- 7 - READ THE ACTIVATION PROCEDURE FOR A NEW CONTROL UNIT ON THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ECU/MARELLI CONTROL UNIT" CHAPTER - END
- 8 - SELECT "ERROR CLEARING" FROM THE "DEVICES ACTIVATION (INJECTOR)" SCREEN PAGE
- 9 - WAS THE PROBLEM SOLVED BY REPLACING THE THROTTLE GRIP SENSOR (DEMAND) OR THE THROTTLE BODY?

**NO, END; YES, go to 10**

- 10 - READ THE RESET PROCEDURE ON THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/THROTTLE GRIP POSITION SENSOR OR THROTTLE BODY" CHAPTER - END
- 11 - CHECK IF THERE ARE CURRENT OR STORED ERRORS DETECTED BY THE INSTRUMENT PANEL REFERRING TO THE "DIAGNOSIS" CHAPTER, "INSTRUMENT

PANEL ERRORS" SECTION. IF THERE ARE ERRORS PRESENT, SOLVE THE FAULT AND SELECT "CLEAR ERRORS"; IF THERE ARE NO ERRORS PRESENT, go to 12

- 12 - IN THE "ENGINE PARAMETER READING" SCREEN PAGE, DOES THE "AIR TEMPERATURE" PARAMETER INDICATE A VALUE EQUIVALENT TO ROOM TEMPERATURE?

**YES, go to 13; NO, note A**

- 13 - IN THE "ENGINE PARAMETER READING" SCREEN PAGE, DOES THE ENGINE TEMPERATURE PARAMETER WITH COLD ENGINE INDICATE A VALUE SIMILAR TO THAT OF THE AIR TEMPERATURE PARAMETER? AFTER STARTING THE ENGINE, DOES THE PARAMETER INCREASE GRADUALLY INDICATING A CORRECT VALUE?

**YES, go to 14; NO, note B**

- 14 - IN THE "ENGINE PARAMETER READING" AND THE "LAMBDA SENSOR CORRECTION" SCREEN PAGES, WITH ENGINE AT IDLE AND ENGINE TEMPERATURE AT  $> 90^{\circ}\text{C}$ , DOES THE VALUE VARY WITHIN THE 0.9 - 1.1 RANGE?

**YES, go to 15; NO, note C**

- 15 - IN THE "ENGINE PARAMETER READING" SCREEN PAGE AND WITH ENGINE AT IDLE, ARE "FRONT THROTTLE CORRECTION PARAMETERS" OR "REAR THROTTLE CORRECTION" WITHIN THE  $(-0.4^{\circ} - +0.4^{\circ})$  RANGE? AND IN THE SAME SCREEN PAGE, ARE THE "FRONT THROT., POT. 1 (DEGREES)" AND "REAR THROT., POT. 1 (DEGREES)", WITH ENGINE AT IDLE,  $> \text{OR} = 0.5^{\circ}$ ? CAUTION: THE DIFFERENCE OF THE THROTTLE CORRECTION VALUES BETWEEN THE REAR AND FRONT CYLINDER MUST NOT BE  $> 0.4^{\circ}$

**YES, go to 16; NO, note D**

- 16 - CHECK: ENGINE SPEED SENSOR, FUEL PRESSURE, INJECTORS (MECHANICAL OPERATION), COILS (SPARK), ENGINE MECHANICS - END

**Note A: SEE THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/AIR TEMPERATURE SENSOR" CHAPTER.**

**Note B: SEE THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ENGINE TEMPERATURE SENSOR" CHAPTER.**

**Note C: SEE THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/LAMBDA PROBE" CHAPTER.**

**Note D: SEE THE "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/THROTTLE BODY" CHAPTER.**

**See also**

[Checks and inspections](#)

---

## Engine

---

### The engine does not start

#### THE ENGINE DOES NOT START

##### CAUTION

NAVIGATOR SHOULD BE WORKING PROPERLY AND UPGRADED.

##### CAUTION

BEFORE ANY TROUBLESHOOTING, MAKE SURE THAT:

- 1) BATTERY VOLTAGE IS ABOVE 12V;
- 2) THE MAIN 30A FUSE IS NOT DAMAGED AND IS ADEQUATELY FITTED;
- 3) SECONDARY FUSES ARE NOT DAMAGED AND ARE ADEQUATELY FITTED.

##### NOTE

THE RELAY NUMBER SPECIFIED REFERS TO THE WIRING DIAGRAM. THE POSITION OF THE RELAY ON THE VEHICLE IS INDICATED IN THE "ELECTRICAL SYSTEM/COMPONENT LAYOUT/ RELAY LAYOUT" CHAPTER.

#### UP TO CHASSIS NUMBER ZD4SMA002AS000983

- 1 - WITH THE KEY TURNED TO "ON", THE INSTRUMENT PANEL LIGHTS UP BUT NO FAILURE INDICATION IS SHOWN. IS THE FUEL PUMP ACTIVATED?

**YES, go to 27; NO, go to 2**

- 2 - DOES NAVIGATOR COMMUNICATE WITH THE CONTROL UNIT?

**YES, go to 3; NO, go to 4**

- 3 - ACTIVATE ONE INJECTOR BY MEANS OF NAVIGATOR ("DEVICES ACTIVATION" SCREEN PAGE, INJECTOR ICON): IS THE INJECTOR ACTIVATED?

**YES, go to 17; NO, go to 12**

- 4 - WITH THE IGNITION OFF, CHECK FOR VOLTAGE ON THE ORANGE/RED WIRE OF THE MAIN INJECTION RELAY (POLARISED) 39.

**YES, go to 6; NO, go to 5**

- 5 - LOCATE THE INTERRUPTION IN THE ORANGE/RED WIRE FROM THE MAIN INJECTION RELAY (POLARISED) 39 TO BATTERY POSITIVE.

- 6 - WITH THE IGNITION ON, CHECK FOR VOLTAGE ON THE GREEN/BLACK WIRE OF THE MAIN INJECTION RELAY (POLARISED) 39.

**OK, go to 8; NOT OK, go to 7**

- 7 - LOCATE THE GREEN/BLACK WIRE FROM THE MAIN INJECTION RELAY (POLARISED) 39 TO THE IGNITION SWITCH - END

- 8 - IS THE BLUE CABLE GROUNDED?

**YES, go to 10; NO, go to 9**

- 9 - RESTORE THE CABLE HARNESS.
- 10 - CHECK IF THERE IS VOLTAGE ON THE RED/BLACK CABLE.

**NOT OK, go to 11; OK, go to 12**

- 11 - REPLACE THE MAIN INJECTION RELAY (POLARISED) 39 - END
- 12 - CHECK FOR VOLTAGE ON THE ORANGE/RED WIRE OF THE AUXILIARY INJECTION RELAY 40.

**YES, go to 13; NOT OK, go to 14**

- 13 - CHECK IF THERE IS VOLTAGE ON THE YELLOW/PURPLE CABLE.

**OK, go to 15; NOT OK, go to 16**

- 14 - RESTORE THE CABLE HARNESS - END
- 15 - SET THE KEY TO "OFF" AND THEN "ON": DOES THE VOLTAGE ON THE YELLOW/PURPLE CABLE REACH APPROX. 1-2V FOR 2 SECONDS?

**YES, go to 17; NO, go to 18**

- 16 - REPLACE THE AUXILIARY INJECTION RELAY 40- END
- 17 - WITH THE IGNITION OFF, CHECK THE RED/BROWN WIRE FROM THE AUXILIARY INJECTION RELAY 40 TO THE FUEL PUMP CONNECTOR FOR CONTINUITY AND GROUND INSULATION.

**YES, go to 20; NO, go to 19**

- 18 - WHEN THE KEY IS TURNED TO "OFF", CHECK CONTINUITY AND GROUND INSULATION OF THE YELLOW/PURPLE CABLE FROM THE RELAY TO PIN 62, VEHICLE CONNECTOR.

**YES, go to 22; NO, go to 21**

- 19 - RESTORE THE CABLE HARNESS.
- 20 - CHECK THERE IS GROUND INSULATION FOR THE BLUE CABLE OF THE PUMP CONNECTOR.

**OK, go to 24; NOT OK, go to 23**

- 21 - RESTORE THE CABLE HARNESS - END
- 22 - CHECK THE VEHICLE CONNECTOR.

**OK, go to 25; NOT OK, go to 26**

- 23 - RESTORE THE CABLE HARNESS - END
- 24 - CHECK THAT THE RESISTANCE OF THE PUMP IS APPROX. 1 OHM. IF THE RESISTANCE IS INCORRECT, REPLACE THE PUMP - END
- 25 - REPLACE THE CONTROL UNIT - END
- 26 - RESTORE THE CABLE HARNESS - END
- 27 - DOES THE MOTOR TURN WHEN THE STARTER BUTTON IS PRESSED?

**YES, go to 29; NO, go to 28**

- 28 - WHAT DOES THE "START-UP ENABLING SWITCH" STATUS ON NAVIGATOR (DEVICE STATUS/ICON "0/1" SCREEN PAGE) MEAN?

**YES, go to 43; NO, go to 64**

- 29 - VOLTAGE ON YELLOW/PINK WIRE OF BISTABLE RELAY (START LOGIC) 37

**OK, go to 30; NOT OK, go to 31**

- 30 - WITH THE BISTABLE RELAY (START LOGIC) 37 DISCONNECTED, KEEP THE STARTER BUTTON PRESSED AND CHECK THAT A VOLTAGE OF APPROX. 1-2V IS MEASURED ON THE YELLOW/RED WIRE

**OK, go to 32; NOT OK, go to 33**

- 31 - RESTORE THE CABLE HARNESS
- 32 - CHECK GROUND CONNECTION OF THE BLUE CABLE OF THE BISTABLE RELAY (START LOGIC) 37

**OK, go to 34; NOT OK, go to 35**

- 33 - RESTORE THE CABLE HARNESS
- 34 - CHECK THAT THE BISTABLE RELAY (START LOGIC) 37 WORKS CORRECTLY

**OK, go to 36; NOT OK, go to 37**

- 35 - RESTORE THE CABLE HARNESS
- 36 - CHECK CONTINUITY OF PINK/BLACK CABLE FROM BISTABLE RELAY (START LOGIC) 37 TO PIN 14 ON VEHICLE CONNECTOR

**OK, go to 38; NOT OK, go to 39**

- 37 - REPLACE THE BISTABLE RELAY (START LOGIC) 37
- 38 - CHECK THE VEHICLE CONNECTOR (PIN 14)

**OK, go to 40; NOT OK, go to 41**

- 39 - RESTORE THE CABLE HARNESS
- 40 - REFER TO THE CHAPTER ON "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ ENGINE REVOLUTION SENSOR"; FOLLOW THE TROUBLESHOOTING STEPS IN THE SECTION REFERRING TO "NAVIGATOR: ELECTRICAL ERRORS".

**CAUTION: failure NOT identified, go to 42; failure identified, END**

- 41 - RESTORE THE CABLE HARNESS
- 42 - CHECK INJECTORS AND ENGINE FOR CORRECT MECHANICAL OPERATION, CHECK FUEL CIRCUIT PRESSURE.
- 43 - WHEN THE STARTER BUTTON IS PRESSED, DOES THE VOLTAGE TO THE YELLOW/PINK WIRE OF THE CONTROL RELAY (START LOGIC) 38 CHANGE TO APPROX. ZERO?

**YES, go to 44; NO, go to 45**

- 44 - CHECK FOR VOLTAGE ON THE RED/BLACK WIRES OF THE COMMAND RELAY (START LOGIC) 38

**YES, go to 50; NO, go to 51**

- 45 - CHECK CONTINUITY AND GROUND INSULATION OF THE YELLOW/PINK CABLE FROM THE RELAY TO THE ENGINE CONNECTOR (PIN 2)

**OK, go to 47; NOT OK, go to 46**

- 46- RESTORE THE CABLE HARNESS - END
- 47 - CHECK THE CONTROL UNIT CONNECTOR

**OK, go to 49; NOT OK, go to 48**

- 48 - RESTORE THE CABLE HARNESS - END
- 49 - REPLACE THE CONTROL UNIT - END
- 50 - WHILE PRESSING THE STARTER BUTTON, DISCONNECT THE CONNECTOR FOR THE WHITE/SKY BLUE AND WHITE/RED WIRES OF THE STARTER RELAY 34 AND CHECK FOR VOLTAGE ON YELLOW/RED WIRE OF THE START LOGIC CONTROL RELAY 38

**OK, go to 52; NOT OK, go to 53**

- 51 - REPLACE THE RELAY - END
- 52 - WHILE PRESSING THE STARTER BUTTON, CHECK FOR VOLTAGE ON YELLOW/RED WIRE OF STARTER RELAY 34

**OK, go to 54; NOT OK, go to 55**

- 53 - REPLACE THE RELAY - END
- 54 - CHECK IF THE BLUE WIRE OF THE STARTER RELAY 34 IS GROUNDED

**OK, go to 56; NOT OK, go to 57**

- 55 - RESTORE THE CABLE HARNESS -END
- 56 - WITH THE IGNITION OFF, CHECK FOR VOLTAGE ON THE REAR RED WIRE (WITH CAP) OF THE STARTER RELAY 34

**OK, go to 58; NOT OK, go to 59**

- 57 - RESTORE THE CABLE HARNESS -END
- 58 - WITH THE STARTER BUTTON PRESSED, CHECK FOR VOLTAGE ON THE FRONT RED WIRE OF THE STARTER RELAY 34

**OK, go to 60; NOT OK, go to 61**

- 59 - RESTORE THE CABLE HARNESS
- 60 - CHECK FOR CONTINUITY ON THE RED WIRE BETWEEN THE STARTER RELAY 34 AND THE STARTER MOTOR

**YES, go to 62; NO, go to 63**

- 61 - REPLACE THE STARTER RELAY 34 - END
- 62 - REPLACE THE STARTER MOTOR - END
- 63 - RESTORE THE CABLE HARNESS - END

- 64 - WHAT DOES THE "FALL SENSOR" STATUS ON NAVIGATOR (DEVICE STATUS/ICON "0/1" SCREEN PAGE) MEAN?

**If "NORMAL" is shown, go to 65; If "TIP OVER" is shown, go to 68**

- 65 - WITH THE SWITCH SET TO "RUN", WHAT DOES THE "RUN-STOP SWITCH" STATUS ON NAVIGATOR ("DEVICE STATUS/ICON "0/1" SCREEN PAGE) MEAN?

**If "RUN" is shown, go to 66; If "STOP" is shown, go to 67**

- 66 - USING NAVIGATOR CHECK THAT THE SIDE STAND, NEUTRAL SENSOR AND CLUTCH SENSOR FUNCTION CORRECTLY; OPERATE ANY DEVICE AND CHECK THE SUITABLE INDICATION ON THE "DEVICE STATUS/ICON "0/1" SCREEN PAGE

**If "MALFUNCTION" is shown, go to 71; If "CORRECT OPERATION" is shown, go to 72**

- 67 - REFER TO THE CHAPTER ON "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ FALL SENSOR; INDICATION ON NAVIGATOR ALWAYS STOP- END
- 68 - IS THE SENSOR VERTICAL?

**YES, go to 69; NO, go to 70**

- 69 - REFER TO THE CHAPTER ON "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ FALL SENSOR, INDICATION ON NAVIGATOR ALWAYS TIP OVER - END
- 70 - SET THE SENSOR TO THE CORRECT POSITION - END
- 71 - ACCORDING TO THE FAILURE, REFER TO CHAPTER ON "ELECTRICAL SYSTEM/ CHECKS AND CONTROLS/GEAR IN NEUTRAL SENSOR", or "CLUTCH LEVER SENSOR" or "SIDE STAND SENSOR" - END
- 72 - REPLACE THE CONTROL UNIT - END

---

#### **FROM CHASSIS NUMBER ZD4SMA002AS000984**

- 1 - WITH THE KEY TURNED TO "ON", THE INSTRUMENT PANEL LIGHTS UP BUT NO FAILURE INDICATION IS SHOWN. IS THE FUEL PUMP ACTIVATED?

**YES, go to 27; NO, go to 2**

- 2 - DOES NAVIGATOR COMMUNICATE WITH THE CONTROL UNIT?

**YES, go to 3; NO, go to 4**

- 3 - ACTIVATE ONE INJECTOR BY MEANS OF NAVIGATOR ("DEVICES ACTIVATION" SCREEN PAGE, INJECTOR ICON): IS THE INJECTOR ACTIVATED?

**YES, go to 17; NO, go to 12**

- 4 - WITH THE IGNITION OFF, CHECK FOR VOLTAGE ON THE ORANGE/RED WIRE OF THE MAIN INJECTION RELAY (POLARISED) 39.

**YES, go to 6; NO, go to 5**

- 5 - LOCATE THE INTERRUPTION IN THE ORANGE/RED WIRE FROM THE MAIN INJECTION RELAY (POLARISED) 39 TO BATTERY POSITIVE.
- 6 - WITH THE IGNITION ON, CHECK FOR VOLTAGE ON THE GREEN/BLACK WIRE OF THE MAIN INJECTION RELAY (POLARISED) 39.

**YES, go to 8; NO, go to 7**

- 7 - LOCATE THE GREEN/BLACK WIRE FROM THE MAIN INJECTION RELAY (POLARISED) 39 TO THE IGNITION SWITCH - END
- 8 - IS THE BLUE CABLE GROUNDED?

**YES, go to 10; NO, go to 9**

- 9 - RESTORE THE CABLE HARNESS.
- 10 - CHECK IF THERE IS VOLTAGE ON THE RED/BLACK CABLE.

**NOT OK, go to 11; OK, go to 12**

- 11 - REPLACE THE MAIN INJECTION RELAY (POLARISED) 39 - END
- 12 - CHECK FOR VOLTAGE ON THE ORANGE/RED WIRE OF THE AUXILIARY INJECTION RELAY 40.

**YES, go to 13; NOT OK, go to 14**

- 13 - CHECK IF THERE IS VOLTAGE ON THE YELLOW/PURPLE CABLE.

**OK, go to 15; NOT OK, go to 16**

- 14 - RESTORE THE CABLE HARNESS - END
- 15 - SET THE KEY TO "OFF" AND THEN "ON": DOES THE VOLTAGE ON THE YELLOW/PURPLE CABLE REACH APPROX. 1-2V FOR 2 SECONDS?

**YES, go to 17; NO, go to 18**

- 16 - REPLACE THE AUXILIARY INJECTION RELAY 40- END
- 17 - WITH THE IGNITION OFF, CHECK THE RED/BROWN WIRE FROM THE AUXILIARY INJECTION RELAY 40 TO THE FUEL PUMP CONNECTOR FOR CONTINUITY AND GROUND INSULATION.

**YES, go to 20; NO, go to 19**

- 18 - WHEN THE KEY IS TURNED TO "OFF", CHECK CONTINUITY AND GROUND INSULATION OF THE YELLOW/PURPLE CABLE FROM THE RELAY TO PIN 62, VEHICLE CONNECTOR.

**YES, go to 22; NO, go to 21**

- 19 - RESTORE THE CABLE HARNESS.
- 20 - CHECK THERE IS GROUND INSULATION FOR THE BLUE CABLE OF THE PUMP CONNECTOR.

**OK, go to 24; NOT OK, go to 23**

- 21 - RESTORE THE CABLE HARNESS - END
- 22 - CHECK THE VEHICLE CONNECTOR.

**OK, go to 25; NOT OK, go to 26**

- 23 - RESTORE THE CABLE HARNESS - END
- 24 - CHECK THAT THE RESISTANCE OF THE PUMP IS APPROX. 1 OHM. IF THE RESISTANCE IS INCORRECT, REPLACE THE PUMP - END
- 25 - REPLACE THE CONTROL UNIT - END
- 26 - RESTORE THE CABLE HARNESS - END
- 27 - DOES THE MOTOR TURN WHEN THE STARTER BUTTON IS PRESSED?

**YES, go to 29; NO, go to 28**

- 28 - WHAT DOES THE "START-UP ENABLING SWITCH" STATUS ON NAVIGATOR (DEVICE STATUS/ICON "0/1" SCREEN PAGE) MEAN?

**YES, go to 43; NO, go to 64**

- 29 - CHECK FOR VOLTAGE ON THE BROWN/WHITE WIRE OF BISTABLE RELAY (START LOGIC) 37

**OK, go to 30; NOT OK, go to 31**

- 30 - WITH THE BISTABLE RELAY (START LOGIC) 37 DISCONNECTED, KEEP THE STARTER BUTTON PRESSED AND CHECK THAT A VOLTAGE OF APPROX. 1-2V IS MEASURED ON THE YELLOW/RED WIRES

**OK, go to 32; NOT OK, go to 33**

- 31 - CHECK FOR CONTINUITY ON THE BROWN/WHITE CABLE

**OK, go to 31a; NOT OK, go to 31b**

**31a** - WITH THE LIGHT LOGIC RELAY 7 DISCONNECTED, CHECK THE CONTINUITY BETWEEN  
PIN 87 AND PIN 30

**OK, go to 31c; NOT OK, go to 31d**

**31b** - RESTORE THE CABLE HARNESS

**31c** - CHECK CONTINUITY ON GREEN/WHITE CABLE FROM THE LIGHT LOGIC RELAY 7 TO  
SECONDARY FUSE B

**OK, go to 31e; NOT OK, go to 31f**

**31d** - REPLACE THE RELAY - END

**31e** - CHECK CONTINUITY ON RED/BLACK CABLE FROM SECONDARY FUSE B THE TO MAIN  
INJECTION RELAY 39

**OK, go to 4; NOT OK, go to 31g**

**31f** - RESTORE THE CABLE HARNESS

**31g** - RESTORE THE CABLE HARNESS

- 32 - CHECK CONTINUITY OF PINK/BLACK CABLE FROM BISTABLE RELAY (START LOGIC) 37 TO START BUTTON CONNECTOR

**OK, go to 34; NOT OK, go to 35**

- 33 - RESTORE THE CABLE HARNESS
- 34 - CHECK THAT THE BISTABLE RELAY (START LOGIC) 37 WORKS CORRECTLY

**OK, go to 36; NOT OK, go to 37**

- 35 - RESTORE THE CABLE HARNESS
- 36 - CHECK CONTINUITY OF PINK/BLACK CABLE FROM BISTABLE RELAY (START LOGIC) 37 TO PIN 14 ON VEHICLE CONNECTOR

**OK, go to 38; NOT OK, go to 39**

- 37 - REPLACE THE BISTABLE RELAY (START LOGIC) 37
- 38 - CHECK THE VEHICLE CONNECTOR (PIN 14)

**OK, go to 40; NOT OK, go to 41**

- 39 - RESTORE THE CABLE HARNESS
- 40 - REFER TO THE CHAPTER ON "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ ENGINE REVOLUTION SENSOR"; FOLLOW THE TROUBLESHOOTING STEPS IN THE SECTION REFERRING TO "NAVIGATOR: ELECTRICAL ERRORS".

**CAUTION: failure NOT identified, go to 42; failure identified, END**

- 41 - RESTORE THE CABLE HARNESS
- 42 - CHECK INJECTORS AND ENGINE FOR CORRECT MECHANICAL OPERATION, CHECK FUEL CIRCUIT PRESSURE.
- 43 - WHEN THE STARTER BUTTON IS PRESSED, DOES THE VOLTAGE TO THE YELLOW/PINK WIRE OF THE CONTROL RELAY (START LOGIC) 38 CHANGE TO APPROX. ZERO?

**YES, go to 44; NO, go to 45**

- 44 - CHECK FOR VOLTAGE ON THE RED/BLACK WIRES OF THE COMMAND RELAY (START LOGIC) 38

**YES, go to 50; NO, go to 51**

- 45 - CHECK CONTINUITY AND GROUND INSULATION OF THE YELLOW/PINK CABLE FROM THE RELAY TO THE ENGINE CONNECTOR (PIN 2)

**OK, go to 47; NOT OK, go to 46**

- 46- RESTORE THE CABLE HARNESS - END
- 47 - CHECK THE CONTROL UNIT CONNECTOR

**OK, go to 49; NOT OK, go to 48**

- 48 - RESTORE THE CABLE HARNESS - END

- 49 - REPLACE THE CONTROL UNIT - END
- 50 - WHILE PRESSING THE STARTER BUTTON, DISCONNECT THE CONNECTOR FOR THE WHITE/SKY BLUE AND WHITE/RED WIRES OF THE STARTER RELAY 34 AND CHECK FOR VOLTAGE ON YELLOW/RED WIRE OF THE (START LOGIC) CONTROL RELAY 38

**OK, go to 52; NOT OK, go to 53**

- 51 - REPLACE THE RELAY - END
- 52 - PRESSING THE STARTER BUTTON, CHECK IF THERE IS VOLTAGE TO THE YELLOW/RED CABLE OF THE START-UP RELAY

**OK, go to 54; NOT OK, go to 55**

- 53 - REPLACE THE RELAY - END
- 54 - CHECK IF THE BLUE WIRE OF THE STARTER RELAY 34 IS GROUNDED

**OK, go to 56; NOT OK, go to 57**

- 55 - RESTORE THE CABLE HARNESS -END
- 56 - WITH THE IGNITION OFF, CHECK FOR VOLTAGE ON THE REAR RED WIRE (WITH CAP) OF THE STARTER RELAY 34

**OK, go to 58; NOT OK, go to 59**

- 57 - RESTORE THE CABLE HARNESS -END
- 58 - WITH THE STARTER BUTTON PRESSED, CHECK FOR VOLTAGE ON THE FRONT RED WIRE OF THE STARTER RELAY 34

**OK, go to 60; NOT OK, go to 61**

- 59 - RESTORE THE CABLE HARNESS
- 60 - CHECK FOR CONTINUITY ON THE RED WIRE BETWEEN THE STARTER RELAY 34 AND THE STARTER MOTOR

**YES, go to 62; NO, go to 63**

- 61 - REPLACE THE STARTER RELAY 34 - END
- 62 - REPLACE THE STARTER MOTOR - END
- 63 - RESTORE THE CABLE HARNESS - END
- 64 - WHAT DOES THE "FALL SENSOR" STATUS ON NAVIGATOR (DEVICE STATUS/ICON "0/1" SCREEN PAGE) MEAN?

**If "NORMAL" is shown, go to 65; If "TIP OVER" is shown, go to 68**

- 65 - WITH THE SWITCH SET TO "RUN", WHAT DOES THE "RUN-STOP SWITCH" STATUS ON NAVIGATOR ("DEVICE STATUS/ICON "0/1" SCREEN PAGE) MEAN?

**If "RUN" is shown, go to 66; If "STOP" is shown, go to 67**

- 66 - USING NAVIGATOR CHECK THAT THE SIDE STAND, NEUTRAL SENSOR AND CLUTCH SENSOR FUNCTION CORRECTLY; OPERATE ANY DEVICE AND CHECK THE SUITABLE INDICATION ON THE "DEVICE STATUS/ICON "0/1" SCREEN PAGE

**If "MALFUNCTION" is shown, go to 71; If "CORRECT OPERATION" is shown, go to 72**

- 67 - REFER TO THE CHAPTER ON "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ FALL SENSOR; INDICATION ON NAVIGATOR ALWAYS STOP- END
- 68 - IS THE SENSOR VERTICAL?


**YES, go to 69; NO, go to 70**

- 69 - REFER TO THE CHAPTER ON "ELECTRICAL SYSTEM/CHECKS AND CONTROLS/ FALL SENSOR, INDICATION ON NAVIGATOR ALWAYS TIP OVER - END
  - 70 - SET THE SENSOR TO THE CORRECT POSITION - END
  - 71 - ACCORDING TO THE FAILURE, REFER TO CHAPTER ON "ELECTRICAL SYSTEM/ CHECKS AND CONTROLS/GEAR IN NEUTRAL SENSOR", or "CLUTCH LEVER SENSOR" or "SIDE STAND SENSOR" - END
  - 72 - REPLACE THE CONTROL UNIT - END
-


## INDEX OF TOPICS

ELECTRICAL SYSTEM

ELE SYS

**ELECTRICAL SYSTEM 1**


pos.	Description	Type	Quantity	Torque	Notes
1	Coil fixing screw	M6	2	13 Nm (9.59 lbf ft)	-
2	TE screw fastening regulator to frame	M6x30	2	10 Nm (7.37 lbf ft)	-



ELECTRICAL SYSTEM 2

pos.	Description	Type	Quantity	Torque	Notes
1	Screw fastening ECU to filter box base	-	4	2.5 Nm (1.47 lbf ft)	-
-	Starter relay fastener	-	2	3 - 4.2 Nm (2.21 - 3.1 lbf ft)	-

Components arrangement



Key

1. fall sensor
2. Intake air pressure sensor
3. Intake air temperature sensor
4. Instrument panel
5. Engine control unit
6. Headlamp
7. Start-up relay
8. Front ABS sensor
9. Starter motor
10. Engine revolution sensor
11. Lambda probe
12. Rear ABS sensor
13. Coils
14. Main fuses
15. Hand grip position sensor
16. Main injection relay
17. Throttle control unit
18. Spark plugs
19. Taillight
20. Engine revolution sensor - pick up
21. Gear in neutral sensor
22. ABS control unit (modulator)
23. Engine temperature sensor
24. Secondary fuses

**CAUTION**

**A RELAY CANNOT BE IDENTIFIED BASED ONLY ON THE FOLLOWING INDICATIONS: THIS SHOULD BE DONE ALSO IDENTIFYING THE COLOUR OF THE RELAY CABLES.**

**RELAY LAYOUT ON THE WIRING DIAGRAM AND ON THE VEHICLE**

**LOW BEAM LOGIC RELAY****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 7
- Location on the vehicle: under the fuel tank, left hand side of filter box, second relay from the front.

**LIGHT LOGIC RELAY****FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 7
- Location on the vehicle: under the fuel tank, right hand side of filter box, second relay from the rear.

**START-UP RELAY**

**UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 34
- Location on the vehicle: under saddle near battery.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 34
- Location on the vehicle: under saddle near battery.

**BISTABLE RELAY (START LOGIC)****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 37
- Location on the vehicle: not present on motorcycle (wiring harness exists)

**START-UP MAINTENANCE RELAY****FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 37
- Location on the vehicle: under the fuel tank, left hand side of filter box, second relay from the front.

**CONTROL RELAY (START-UP LOGIC)****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 38
- Location on the vehicle: under the fuel tank, right hand side of filter box, first relay from the front.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 38
- Location on the vehicle: under the fuel tank, right hand side of filter box, first relay from the front.

**MAIN INJECTION RELAY****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 39
- Location on the vehicle: under the fuel tank, left hand side of filter box, second relay from the rear.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 39
- Location on the vehicle: under the fuel tank, left hand side of filter box, second relay from the rear.

**AUXILIARY INJECTION RELAY****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 40
- Location on the vehicle: under the fuel tank, right hand side of filter box, second relay from the rear.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 40
- Location on the vehicle: under the fuel tank, right hand side of filter box, second relay from the rear.

**FAN CONTROL RELAY****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 42
- Location on the vehicle: under the fuel tank, left hand side of filter box, first relay from the front.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 42
- Location on the vehicle: under the fuel tank, left hand side of filter box, first relay from the front.

**HIGH BEAM LIGHTS RELAY****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 64
- Location on the vehicle: behind the instrument panel.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 64
- Location on the vehicle: under the fuel tank, right hand side of filter box, second relay from the front.

**RECOVERY LOGIC RELAY****UP TO CHASSIS NUMBER ZD4SMA002AS000983**

- Location on the wiring diagram: 65
- Location on the vehicle: under the fuel tank, right hand side of filter box, first relay from the rear.

**FROM CHASSIS NUMBER ZD4SMA002AS000984**

- Location on the wiring diagram: 65
- Location on the vehicle: behind the instrument panel.

---

**Electrical system installation****INTRODUCTION****Scope and applicability**

The position of the cable harnesses, how they are fixed to the motorcycle and potential problems are defined on the following sections in order to reach the objectives of vehicle reliability.

**Materials used and corresponding quantities**

The electrical system consists of the following cable harnesses and parts:

- 1 ABS Main Cable Harness
- 1 Filter Casing Cable Harness
- 1 Rear Light Cable Harness
- 1 Batt.-Engine Ground Cable
- 1 License Plate Light Cable Harness
- 2 Caps for Magura switches
- 1 Main injection relay
- 7 12V / 30A relay
- 1 Start-up relay
- 1 Resistance module
- 3 Small black clamps 2.5x98 (0.098x3.858)
- 12 Small black clamps 2.5x160 (0.098x6.299)
- 8 Medium black clamps 4.5x180 (0.177x7.086)
- 4 Medium black clamps 4.5x290 (0.177x11.417)
- 2 Plastic cable guides - Ø 12 mm (Ø 0.47 in)
- 2 Metallic cable guides for filter housing cable harness
- 1 Rubber ring to support the filter housing 12-way connector
- 2 Clamps fixing to chassis
- 4 Flexible rubber clamps
- 1 Flexible rubber clamp
- 2 Plastic cable guides
- 1 Black pigtail wire L=10 cm (3.94 in)
- 1 Plastic cable guide
- 1 Screw

**Motorcycle division**

The wiring timing is subdivided in three essential sections, as indicated in the figure.

1. Front section
2. Central section
3. Rear part



### SPECIAL CHECKS FOR THE CORRECT CONNECTION AND LAYING OF CABLES

Carry out the checks described below once the electrical system is refitted, connectors reconnected and clamps and retainers restored.

- Check the connector block for connections and correct tightening in the following connectors.
  1. Instrument panel connector: FRONT SECTION.
  2. Demand Master and Slave connectors: CENTRAL SECTION.
  3. Handgrip sensor connectors: CENTRAL SECTION, TABLE G
  4. Pick Up Connector: CENTRAL SECTION.
  5. Side Stand Switch Connector: CENTRAL SECTION, TABLE C.
  6. Regulator Connector: CENTRAL SECTION, TABLE O.
  7. Front cylinder coil and rear cylinder coil connectors.
  8. Filter Housing Connectors.
  9. ECU and Ground Lead Connectors for the filter casing: CENTRAL SECTION, TABLE C.
  10. Fuel Pump Connector.
  11. Key Connector - Right Light Switch Connectors - Left Light Switch Connectors: Connectors inside the housing behind the radiator: FRONT SECTION, TABLE B.
  12. ABS connector.
  13. Rear and front speed sensors connector.
  14. Auxiliary fuses (rubber housing correct positioning and closing).
    - Check filter housing cable harness connectors.
    - Undoubtedly the connection of the rest of connectors is also important and essential for the correct operation of the vehicle.

### Front side

#### CAUTION

**ONCE THE ELECTRICAL SYSTEM IS REFITTED, THE CONNECTORS RECONNECTED AND CLAMPS AND RETAINERS RESTORED, CARRY OUT THE CHECKS INDICATED UNDER "SPECIAL CHECKS FOR THE CORRECT CONNECTION AND LAYING OF CABLES" IN THE "ELECTRICAL SYSTEM INSTALLATION" SECTION.**


**TABLE A - FRONT HEADLAMP****UP TO CHASSIS NUMBER****ZD4SMA002AS000983**

1. High beam relay

**FROM CHASSIS NUMBER****ZD4SMA002AS000984**

2. Recovery relay

- Fasten cable harness with retaining straps as shown in the figure.

**TABLE B**

3. Rubber clamp.

4. Rubber clamp.


**TABLE C**

5. 2.5x160 Clamp


6. 2.5x160 Clamp

7. 2.5x160 Clamp

8. Cable guide + screw



**TABLE D** - Lay the cable as shown and fasten it with a 2.5x160 clamp



**TABLE E** - Fasten with a 2.5x160 clamp



## Central part

**CAUTION**

ONCE THE ELECTRICAL SYSTEM IS REFITTED, THE CONNECTORS RECONNECTED AND CLAMPS AND RETAINERS RESTORED, CARRY OUT THE CHECKS INDICATED UNDER "SPECIAL CHECKS FOR THE CORRECT CONNECTION AND LAYING OF CABLES" IN THE "ELECTRICAL SYSTEM INSTALLATION" SECTION.

**TABLE A - COILS**

1. Part for fitting ground terminals on coil assembly.
2. Cable guide.



**TABLE B - CABLE HARNESS FOR RELAY UNIT**


The shortest cables must be connected to the three closest relays



**TABLE C**


To lay the auxiliary fuses box under the airbox:

- slide off the protection cap.
  - reinsert it observing the correct poles
1. Side stand switch
  2. Neutral switch
  3. Horn
  4. Control unit connectors



**TABLE D**

The generator output cable must be laid behind the thermostatic valve, under the airbox.

**TABLE E**

- 5. Cable guide already fitted on engine
- 6. Rubber cap

**TABLE F**

4.5x180 (0.18x7.08) Clamps




**TABLE G**

Plastic cable guide holding the auxiliary fuses branch and the cylinder coil cable 1 (horizontal).

**TABLE H**

4.5x290 (0.18x11.42) Clamp



UP TO CHASSIS NUMBER ZD4SMA002AS000983

**TABLE I - FILTER BOX ELECTRICAL COMPONENTS**

1. Resistance module
2. Main injection relay
3. Low beam relay
4. Fan relay
5. Control relay
6. Bistable relay (not present)
7. Auxiliary injection relay
8. Recovery relay



FROM CHASSIS NUMBER ZD4SMA002AS000984

**TABLE I1 - FILTER BOX ELECTRICAL COMPONENTS**

1. Resistance module
2. Start-up maintenance relay
3. Main injection relay
4. Fan relay
5. Control relay
6. High- and low-beam lights relay
7. Light logic relay
8. Auxiliary injection relay

**TABLE J**

4.5x290 (0.18x11.42) Clamp



TABLE K

Plastic cable guide that holds the lambda probe branch, the rear stop switch branch and the rear wheel speed sensor.



TABLE L

First of all connect the light switches connectors and the key switch inside the rubber cap and position the latter as in the figure, then the Demand Master (BLUE tape) connector and then the "regulator" connector.

9. Regulator connector

10. Rubber cap that hosts light switch and key switch connectors.

11. Demand 1 Master Connector




TABLE M

The clamp holds the cables going out from the light switches and the immobilizer aerial cable going out from the key switch.

4.5x180 (0.18x7.08) Clamp




TABLE N

2.5x160 (0.10x6.30) Clamp




**TABLE O**

- 12. Cable grommet
- 13. 2.5x98 (0.10x3.86) Clamps
- 14. 4.5x290 (0.18x11.42) Clamps

**TABLE P**

Engine attachment clamps that coil the main cable harness and the engine - battery ground connection cable harness.

**TABLE Q**

Rubber clamp

**TABLE R**

Metallic cable guide




TABLE S

- 15. Side stand switch output sheath
- 16. Battery compartment bleed pipe
- 17. Cable grommet




TABLE T

- The cables fastened to the engine ground must face downwards.
- 18. Main cable harness engine earthing on the left
  - 19. Battery ground lead on the right





TABLE U


- 2 4.5x180 (0.18x7.08) Clamps



UP TO CHASSIS NUMBER ZD4SMA002AS000983

TABLE V (OPT.A)

- Cable grommet not foreseen.



FROM CHASSIS NUMBER ZD4SMA002AS000984

TABLE V1 (OPT.B)

- Place the cable harness of the lambda probe in the cable grommet on the clutch crankcase.
- 20. Fasten the cable harness to the chassis with the clamp.

21. Place the cable harness of the lambda probe in the cable grommet on the clutch crankcase.




TABLE Z

Connector insertion on Demand and secondary lock closing



TABLE ZA-ZB

Tables with tips on filter box cable harness fitting.



**TABLE ZC-ZD****Tables with tips for fitting ground lead and start-up cable**

22. Cable grommet


23. ABS cable harness connecting cable

24. Starter motor cable coiled with pigtail wire L=10 cm (3.93 in)


25. 4.5x290 (0.18x11.42) Clamp

26. 2.5x160 (0.10x6.30) Clamp


ZD - engine- battery ground connection cable path

**TABLE ZE****Procedure for the correct insertion of the ABS control unit connector**

The initial position of the lever that couples the connector must be as shown in figures 1 and 2

**TABLE ZF**

Place the connector on the opposite side of the control unit and lower the driving lever until the "click" that signals the end of the stroke is heard



**TABLE ZG**

When the connector is fully inserted, the distance between the connector and the ABS control unit must be 7.5 mm (0.29 in).

If the initial position of the connector and the driving lever is not as shown in figure ZE, the connector will not get properly coupled and the distance measured will be longer (12 mm approx. (0.47 in)).

In this case, repeat the operation as described in the ZF-ZG picture.

**It is advisable to create a template to check the correct connector insertion.**



**TABLE ZH**

Insert the cap as shown in the figure



## Back side


### CAUTION

ONCE THE ELECTRICAL SYSTEM IS REFITTED, THE CONNECTORS RECONNECTED AND CLAMPS AND RETAINERS RESTORED, CARRY OUT THE CHECKS INDICATED UNDER "SPECIAL CHECKS FOR THE CORRECT CONNECTION AND LAYING OF CABLES" IN THE "ELECTRICAL SYSTEM INSTALLATION" SECTION.

UP TO CHASSIS NUMBER ZD4SMA002AS000983

**TABLE A - LAMBDA PROBE / REAR STOP  
SWITCH CABLE HARNESS**

1. Plastic cable grommet that clasps the lambda probe branch and the rear stop switch branch.
2. Clamp



**TABLE B - REAR STOP SWITCH CABLE HARNESS**


Retaining strap that clasps the rear stop switch cable harness to the brake pipe.

**TABLE C - BREATHER TUBES FASTENING**

Two cable grommets and a clamp that fasten the breather pipe.

**TABLE C - LICENSE PLATE HOLDER CABLE HARNESS**

Retaining strap that fastens the cable harness.




**TAVOLE E - MONTAGGIO SENSORI VELOCITA' / ABS RUOTA ANTERIORE E POSTERIORE****TAVOLA E**

3. Fascette 2,5x160 mm (0.01x6.30 in)

**TAVOLA E1**

Fascette 2,5x160 mm (0.01x6.30 in)

**TAVOLA E2**


4. Fascette 2,5x160 mm (0.01x6.30 in)

5. Fascette 4,5x180 mm (0.18x7.08 in)

6. Passacavo


**TAVOLA E2/A**

Spirale lunghezza 110 mm (4.33 in)




**TAVOLA E3**

Fascette 2,5x160 mm (0.1x6.30 in)

**General wiring diagram**

UP TO CHASSIS NUMBER ZD4SMA002AS000983



**key:**

1. MULTIPLE CONNECTORS
2. FRONT RIGHT TURN INDICATOR
3. COMPLETE HEADLAMP
4. TAIL LIGHT BULB
5. TWIN HIGH-/LOW BEAM BULB
6. FRONT LEFT TURN INDICATOR
7. LIGHT LOGIC RELAY
8. CLUTCH SWITCH
9. HORN
10. Left light switch
11. INSTRUMENT PANEL
12. Right light switch
13. OIL PRESSURE SENSOR

- 14. INSTRUMENT PANEL DIAGNOSIS
- 15. SIDE STAND SWITCH
- 16. ECU DIAGNOSIS
- 17. IMMOBILIZER AERIAL
- 18. IGNITION SWITCH
- 19. REAR LEFT TURN INDICATOR
- 20. Rear right turn indicator
- 21. LICENSE PLATE LIGHT BULB
- 22. REAR TWIN LIGHT / STOP LIGHT BULB
- 23. TAILLIGHT ASSEMBLY
- 24. REAR STOP SWITCH
- 25. FRONT STOP SWITCH
- 26. SPEED SENSOR
- 27. FALL SENSOR
- 28. NEUTRAL SENSOR
- 29. TIMING SENSOR (OPTIONAL)
- 30. SECONDARY FUSES
- 31. Flywheel
- 32. Voltage regulator
- 33. STARTER MOTOR
- 34. START-UP RELAY
- 35. MAIN FUSE
- 36. BATTERY
- 37. BISTABLE RELAY (START LOGIC)
- 38. CONTROL RELAY (START-UP LOGIC)
- 39. MAIN INJECTION RELAY (POLARISED)
- 40. AUXILIARY INJECTION RELAY
- 41. FAN
- 42. FAN CONTROL RELAY
- 43. FUEL LEVEL SENSOR
- 44. FUEL PUMP
- 45. REAR CYLINDER COIL
- 46. FRONT CYLINDER COIL
- 47. REAR CYLINDER SPARK PLUG
- 48. FRONT CYLINDER SPARK PLUG
- 49. INTAKE AIR TEMPERATURE SENSOR
- 50. Engine temperature sensor
- 51. LAMBDA PROBE


- 52.PURGE VALVE (OPTIONAL)
- 53.REAR CYLINDER PRESSURE SENSOR
- 54.FRONT CYLINDER PRESSURE SENSOR
- 55.REAR CYLINDER INJECTOR
- 56.FRONT CYLINDER INJECTOR
- 57.EFG 1X THROTTLE CONTROL UNIT
- 58.REAR CYLINDER THROTTLE
- 59.FRONT CYLINDER THROTTLE
- 60.THROTTLE GRIP SENSOR POSITION
- 61.PICK-UP
- 62.ECU
- 63.HAZARD BUTTON LIGHTING
- 64.HIGH BEAM LIGHT RELAY
- 65.RECOVERY LOGIC RELAY
- 66.RESISTANCE MODULE
- 67.ABS CONTROL UNIT
- 68.FRONT ABS SENSOR
- 69.REAR ABS SENSOR
- 70.ABS CONTROL UNIT FUSE

**Colour key:**

Ar Orange  
Az Sky blue  
B Blue  
Bi White  
G Yellow  
Gr Grey  
M Brown  
N Black  
R Red  
Ro Pink  
V Green  
Vi Purple

---

**FROM CHASSIS NUMBER ZD4SMA002AS000984**



**key:**

1. MULTIPLE CONNECTORS
2. FRONT RIGHT TURN INDICATOR
3. COMPLETE HEADLAMP
4. TAIL LIGHT BULB
5. TWIN HIGH-/LOW BEAM BULB
6. FRONT LEFT TURN INDICATOR
7. LOGIC RELAY WITH N.C. MATING
8. CLUTCH SWITCH
9. HORN
10. Left light switch
11. INSTRUMENT PANEL
12. Right light switch
13. OIL PRESSURE SENSOR

- 14.INSTRUMENT PANEL DIAGNOSIS
- 15.SIDE STAND SWITCH
- 16.ECU AND ABS DIAGNOSIS
- 17.IMMOBILIZER AERIAL
- 18.IGNITION SWITCH
- 19.REAR LEFT TURN INDICATOR
- 20.Rear right turn indicator
- 21.LICENSE PLATE LIGHT BULB
- 22.-
- 23.COMPLETE TAILLIGHT (WITH LED)
- 24.REAR STOP SWITCH
- 25.FRONT STOP SWITCH
- 26.SPEED SENSOR
- 27.FALL SENSOR
- 28.NEUTRAL SENSOR
- 29.TIMING SENSOR (OPTIONAL)
- 30.SECONDARY FUSES
- 31.Flywheel
- 32.Voltage regulator
- 33.STARTER MOTOR
- 34.START-UP RELAY
- 35.MAIN FUSE
- 36.BATTERY
- 37.START-UP MAINTENANCE RELAY
- 38.CONTROL RELAY (START-UP LOGIC)
- 39.MAIN INJECTION RELAY (POLARISED)
- 40.AUXILIARY INJECTION RELAY
- 41.FAN
- 42.FAN CONTROL RELAY
- 43.FUEL LEVEL SENSOR
- 44.FUEL PUMP
- 45.REAR CYLINDER COIL
- 46.FRONT CYLINDER COIL
- 47.REAR CYLINDER SPARK PLUG
- 48.FRONT CYLINDER SPARK PLUG
- 49.INTAKE AIR TEMPERATURE SENSOR
- 50.Water Temperature Sensor
- 51.LAMBDA PROBE

- 52.PURGE VALVE (OPTIONAL)
- 53.REAR CYLINDER PRESSURE SENSOR
- 54.FRONT CYLINDER PRESSURE SENSOR
- 55.REAR CYLINDER INJECTOR
- 56.FRONT CYLINDER INJECTOR
- 57.EFG 1X THROTTLE CONTROL UNIT
- 58.REAR CYLINDER THROTTLE
- 59.FRONT CYLINDER THROTTLE
- 60.DEMAND CONTROL UNIT
- 61.PICK-UP
- 62.ECU
- 63.HAZARD BUTTON LIGHTING
- 64.LOW-/HIGH- BEAM / PASSING LIGHT RELAY WITH N.C. MATTING
- 65.RECOVERY LOGIC RELAY (URGENT SERVICE)
- 66.PROTECTION RESISTANCES
- 67.ABS CONTROL UNIT
- 68.FRONT ABS SENSOR
- 69.REAR ABS SENSOR
- 70.ABS CONTROL UNIT FUSE

**Colour key:**

- Ar Orange
- Az Sky blue
- B Blue
- Bi White
- G Yellow
- Gr Grey
- M Brown
- N Black
- R Red
- Ro Pink
- V Green
- Vi Purple

---

**Conceptual diagrams**

---

---

**Checks and inspections**

---

**GENERAL CONCEPTS OF ELECTRICAL TROUBLESHOOTING**

---

THE CONNECTION DIAGRAMS ARE IN THE ELECTRICAL SYSTEM SECTIONS; PAY ATTENTION TO THESE DIAGRAMS AS THEY SHOW THE CONNECTOR/COMPONENT AS VIEWED FROM THE CABLE HARNESS SIDE, THAT IS LOOKING AT THE CABLES WHEN GOING OUT OF THE "MAIN" CABLE HARNESS AND INTO THE CONNECTOR/COMPONENT.


**CAUTION**

BEFORE CARRYING OUT ANY TROUBLESHOOTING PROCEDURE ON THE VEHICLE, CHECK THAT THE BATTERY VOLTAGE IS ABOVE 12V.

**CONNECTOR CHECK PROCEDURE**

The procedure includes the following checks:

1. Observation and check of the connector correct position on the component or on the coupling connector, making sure that the locking catch is released.
2. Observation of the terminals on the connector: no rust marks or dirt should be present and it is important to check terminal correct positioning on the connector (i.e., all terminals aligned at the same depth) and terminal integrity (i.e., that terminals are not loose, open/bent, etc.). For connectors whose terminals are not visible (e.g. Marelli control unit) use a metal cable of suitable diameter and introduce it carefully in the connector slot at the same depth as for the other terminals of the connector.

**CAUTION**

IN CASE OF TEMPORAL MALFUNCTIONING, CARRY OUT ALL DUE CHECKS LOOKING FOR FAULT BY MOVING SLIGHTLY THE CABLE HARNESS BEING INSPECTED.

3. Pulling the cables slightly from the back of the connector in order to check the correct position of terminals on the connector and of the cable on the terminal.

**CONTINUITY check**

**Check goal:** this control is to check that there are not any circuit interruptions nor excessive resistance, for instance caused by rust, on the two terminals being inspected.

**Tester:** set the tester on the "continuity" symbol and place the tester probes on the two circuit ends: the tester emits a sound signal only if there is continuity; the tester can also be set to the Ohm symbol to check that the circuit resistance is null or a few tenths of an Ohm.

**CAUTION: THE CIRCUIT SHOULD NOT BE ENERGISED, OTHERWISE THE TEST IS IRRELEVANT.**

**GROUND CONNECTION check**

**Check goal:** this control is to check if a cable or a circuit is in contact with the vehicle ground (-) connection.

**Tester:** set the tester on the "continuity" symbol and place one tester probe on the vehicle ground connection (or on the battery - terminal) and the other probe on the cable being inspected: the tester sends out a sound signal only if there is continuity. The tester can also be set to the Ohm symbol to check that the circuit resistance is null or a few tenths of an Ohm.

**CAUTION! IF THERE IS A GROUND CONNECTION COMING FROM THE CONTROL UNIT, MAKE SURE THAT DURING THE TEST THE CONTROL UNIT IS GROUND CONNECTED TO THE CIRCUIT.**

#### **VOLTAGE check**

**Check goal:** this control is to check if a cable is energised, i.e. if it receives power supply from the battery or the control unit.

**Tester:** set the tester on the direct current symbol and place the tester red probe on the cable being inspected and the black probe on the vehicle ground connection (or on the battery - terminal).

#### **CAUTION**

**IN CASE OF TEMPORAL MALFUNCTIONING, CARRY OUT ALL DUE CHECKS LOOKING FOR FAULT BY MOVING SLIGHTLY THE CABLE HARNESS BEING INSPECTED.**

---

## **Dashboard**

In case the EFI warning light turns on and the words SERVICE or URGENT SERVICE are shown on the display, due to an error detected in the injection ECU, the malfunction indication will be deactivated only after the vehicle has been used for a pre-set number of minutes of operation. However, even though the malfunction is no longer present and the control unit considers the error no longer current but memorised (MEM error indication on Navigator), the instrument panel may keep showing there is an error present.

---

## **Diagnosis**

An access code is required to enter this menu which controls the diagnosis function:

- ENTER SERVICE CODE

This is a 5-digit code, fixed for each vehicle. For these vehicles, the code is:

98789

If the code is incorrect, the following message is displayed:

- INCORRECT CODE

and the instrument panel goes back to the main menu. Otherwise, the following menu is displayed:

- Exit
  - ECU diagnosis
  - INSTRUMENT PANEL ERRORS
-

- Error Clearing
- VEHICLE SERVICING RESET
- Update
- CHANGE KEYS
- KM / MILES

**ECU diagnosis**

In this mode a chart is displayed showing potential errors in the control unit.

**IT IS NECESSARY TO REFER TO THE ERROR INDICATIONS GIVEN BY NAVIGATOR FOR THIS VEHICLE.**

ERRORI ECU		
ACTIVE		
ECU 11	0	
ECU 12	0	
ECU 13	X	
ECU 14	0	
ECU 15	0	
ECU 16	0	

The instrument panel does not keep all previous errors stored in its memory.

**INSTRUMENT PANEL ERRORS**

In this mode, a chart is displayed showing potential errors in the immobilizer and the sensors connected to it.

ERRORI CRUSCOTTO			
		ACTIVE	MEMO
DSB 01	0	0	0
DSB 02	0	0	X
DSB 03	X	X	X
DSB 04	0	0	X
DSB 05	0	0	0
DSB 06	0	0	0

**Instrument panel errors**

In this mode, a chart is displayed showing potential errors in the immobilizer and the sensors connected to it.

**DSB 01** - Immobilizer fault: key code read but not recognised.

**DSB 02** - Immobilizer fault: key code not read (key not present or transponder not working)

**DSB 03** - Immobilizer fault: aerial not working (open or short-circuited)

**DSB 04** - Internal controller fault

**DSB 05** - -

**DSB 06** - -

Error cause

- An oil sensor fault is signalled when it is detected that the sensor circuit is open or shorted to positive.

**DSB 07** - Oil pressure sensor

Error cause

An oil sensor fault is signalled when, with engine off, it is detected that the sensor circuit is open.

Troubleshooting

The test is performed only once when the key is set to ON. This error is signalled by the bulb icon, and the general warning light turns on as well.

**DSB 08** - Oil pressure sensorError cause

An oil sensor fault is signalled when, with engine running, it is detected that the sensor circuit is closed. There is an error when the general warning light turns on.

Troubleshooting

This error is signalled by the bulb icon, and the general warning light turns on as well.

The instrument panel must keep all previous errors stored in its memory.

**DELETE ERRORS**

This option deletes all instrument panel errors; a further confirmation is requested. Use Navigator to reset ECU errors.

**VEHICLE SERVICING RESET**

This function is used to reset vehicle servicing. Using this function, the odometer can be reset only once within the first 200 km (124 mi) of the vehicle, provided this has not been done by the Quality Check.

**UPDATE**

This function is used to program the instrument panel again. This screen page shows the software version currently loaded; the LCD reads:

- INSTRUMENT PANEL DISCONNECTED. NOW CONNECT THE DIAGNOSIS INSTRUMENT.

The instrument panel will restart to work normally after the key is inserted-extracted.

**Modify Keys**

With this function the instrument panel can update the keys. Up to 4 keys can be stored.

The user code is first requested to be entered:

- ENTER THE CODE

After entering the correct code, the following message should be shown on the display:

- INSERT THE X KEY
- INSERT THE X+1 KEY

At least one key must be programmed for the next start-ups. If no other key is inserted within 20 seconds or if there is no power or after the fourth key is programmed, the procedure finishes and all the functions of the vehicle and the instrument panel must be enabled (even if only one key has been programmed).

**KM / MILES**

This menu selects the unit of measurement, either for the speed or the total or partial odometers.

- KM
- MILES

**LANGUAGES**

Select the user interface language from this menu.

- ITALIANO
- ENGLISH
- FRANCAIS
- DEUTSCH
- ESPAÑOL

---

## Service warning light reset

### VEHICLE SERVICING RESET

This function is used to reset vehicle servicing. Using this function, the odometer can be reset only once within the first 200 km (124 mi) of the vehicle, provided this has not been done by the Quality Check. In order to activate this function follow the instructions in the DIAGNOSIS section.

### See also

[Diagnosis](#)

---

## Battery recharge circuit

### RECHARGING SYSTEM

- Remove the tank and the filter casing;
- Disconnect the three-way connector (1) (white).


#### NOTE

THE ENGINE SIDE IS IDENTIFIED WITH THE LETTER "A"



### Measurement of resistance (with engine off)

- For a correct detection of the alternator resistance, an ambient temperature measurement must be carried out and afterwards a heat stabilisation (after turning fan on) by using a tester, using alternatively the 3 connector pins: stage "1" (pin 1-2), stage "2" (pin 1-3), stage "3" (pin 2-3).







- Take the measurement; The correct value is determined by the value measured for each stage in which from time to time the resistance of the tester wires is subtracted, obtained by touching the two lugs.

Example:

- Resistance of stage 1 read on the display = 0.65 Ohm



- Resistance of the wires read on the display = 0.47 Ohm



- Effective resistance stage 1 =  $0.65 - 0.47 = 0.18$  Ohm
- If there is a significant difference between one stage and another (other than 0.15 Ohm), this means that the alternator is defective and must be replaced.

**RESISTANCE MEASUREMENT**

Winding stage	Ambient temperature (ohm)	Afterwards heat stabilisation (ohm)
Stage 1	0.15 - 0.20	0.18 - 0.23
Stage 2	0.15 - 0.20	0.18 - 0.23
Stage 3	0.15 - 0.20	0.18 - 0.23

**Empty voltage**

- Disconnect the three-way connector (1);
- For a correct detection of the alternator voltage, a measurement must be carried out using alternatively the 3 engine side connector pins: stage "1" (pin 1-2), stage "2" (pin 1-3), stage "3" (pin 2-3).
- Take the measurements;
- If there is a significant difference between one stage and another (other than 15 V), this means that the alternator is defective and must be replaced.

**CAUTION**

WITH THE ENGINE HOT THE VALUES RECORDED ARE ON AVERAGE 4-5 V LESS THAN THOSE DETECTED WITH THE ENGINE COLD.

**EMPTY VOLTAGE**

rpm	2000	6000	8000
Vm linked voltage Reference values (V rms)	20 - 30	75 - 85	95 - 105

**Short circuit current**

- For a correct detection of the short circuit current, a connector must be prepared that generates a downstream short circuit between the three alternator cables;
- Start the engine and with an ammeter clamp measure each single cable.
- If there is a significant difference between the measure of the single cables (other than 10 A), this means that the alternator is defective and must be replaced.

**CAUTION**

WITH THE ENGINE HOT THE VALUES RECORDED ARE ON AVERAGE 2-3 A LESS THAN THOSE DETECTED WITH THE ENGINE COLD.

**WARNING**

NEVER KEEP THE ENGINE RUNNING FOR MORE THAN ONE MINUTE; FAILURE TO DO SO COULD CAUSE SERIOUS OVERHEATING DAMAGES TO THE MOTORCYCLE CIRCUITS.

**COLD SHORT CIRCUIT CURRENT**

RPM	2000	4000	6000	8000
RMS DC current (Arms) (average of the 3 stage currents)	26 - 31	26 - 31	26 - 31	26 - 31

**Voltage on battery poles with engine speed always between 3000 - 5000 RPM**

- Start the engine, after about one minute of operating bring the speed to 3000-5000 RPM, then measure with a tester the voltage at the battery poles that must always be between 13V and 15V. Otherwise, if the correct operation of the alternator has already been checked, replace the regulator.

**CAUTION**

**PERFORM THE CHECK DESCRIBED ABOVE WITH A BATTERY IN GOOD CONDITION (START VOLTAGE ABOUT 13V) MAKING SURE THAT THERE ARE NO ELEMENTS IN THE SHORT CIRCUIT.**

**level indicators****Fuel reserve sensor**

Check proper operation of the sensor by adding a 2W bulb in series to the sensor.

Place a bulb between the battery power supply cable and the connector terminal and connect the negative terminal to the ground connection:

- if the sensor is submerged in petrol (sensor high electrical resistance, approx. 5-7 kOhm), the bulb should remain off.
- if the sensor is not submerged in petrol, the bulb should turn on.

**Lights list****Front headlamp****Characteristic****Front daylight running light**


12V - 6W H6

**Low beam light**

12 V - 50 W H4


**High beam light**

12 V - 60 W H4



**Taillight****Characteristic****Rear daylight running light / stop light**

LED

**Fuses****AUXILIARY FUSES**

A - Coil, Light logic relay, Recovery logic relay, Stop, Horn, Tail lights, License plate light (10A).

B - Low-beam / high-beam lights (15A).

C - Live positive lead to EFG-1x control unit and to instrument panel, Instrument panel diagnosis (10 A).

D - Instrument battery positive and EFG-1x control unit (15 A).

E - Permanent positive, ECU power supply (3A).

F - Oxygen sensor heater, Coils, Start-up logic, Fan and injection relay, Fuel pump, Purge valve, Injectors, ECU, Start-up logic (20A).



G - Spare fuses (10 - 15 - 20 A)

**MAIN FUSES**

H - Spare fuses (30 A - 20 A)

I - Battery recharge, fan relay, live positive (30 A)

J - ABS fuse (20 A)



## Control unit


### MARELLI CONTROL UNIT

#### Function

It controls the Ride by wire system, the injection/ignition, the system safety checks and the self-diagnosis function.

#### Location:

- left side, next to the engine



#### Connector location:

- ENGINE connector: upper connector with control unit on the vehicle; a letter E is stamped on the control unit, to the right of the connector.
- VEHICLE connector: lower connector with control unit on the vehicle; a letter V is stamped on the control unit, to the right of the connector.

**Pin-out:** see the CONNECTORS section

### NAVIGATOR: STATUSES

#### Engine status

**Example value:** Indefinite\_Key ON\_Running engine\_Stopped\_Power latch\_Power latch 2\_Power latch finished

#### Engine mode

**Example value:** Indefinite\_Start-up\_Stable\_Idle\_Acceleration\_Deceleration\_Enters Cut Off\_Cut Off\_Exits Cut Off

#### Immobilizer signal

**Example value:** yes/no

Indicates whether the control unit has received the consent by the instrument panel regarding the immobilizer: coded key or user code entered manually. Potential errors will be shown on the Instrument Panel Errors screen page, on the DIAGNOSIS section of the instrument panel.

#### Start-up signal

**Example value:** yes/no

Indicates whether the control unit will enable start-up when requested: in case the safety measures are not respected (side stand, neutral sensor and clutch in correct position) or if the immobilizer does not send the start-up consent to the control unit, the status is NO.

### NAVIGATOR: FUEL INJECTION SYSTEM

#### PARAMETERS

**Target idle rpm**

**NAVIGATOR: ELECTRICAL ERRORS**

**EEPROM Error P0601** - circuit not operational.

Error cause

- Replace injection ECU. The instrument panel does not indicate the presence of this error even in the ATT status.

**RAM Error P0604** - circuit not operational.

Error cause

- Replace injection ECU. The instrument panel does not indicate the presence of this error even in the ATT status.

**ROM Error P0605** - circuit not operational.

Error cause

- Replace injection ECU. The instrument panel does not indicate the presence of this error even in the ATT status.

**A/D converter P0607-** circuit not operational.

Error cause

- Replace injection ECU.

**Level 2 safety reset P0608**

Error cause

- As the level 2 safety system (comparison between requested torque and calculated torque) has detected a fault, the control unit has reset engine (C gravity).

Troubleshooting

- Continue fault search for the other errors detected.

**Safety Engine Stop P0609**

Error cause

- As the level 3 safety system (control EEPROM) has detected a fault, the control unit has shut off the engine (D gravity).

Troubleshooting

- Replace Marelli control unit.

**Reset lines error P0610-** circuit not operational

Error cause

- Problems on the reset lines (PINS 55 and 56 of the VEHICLE connector) of the throttle motors: lines used to interrupt motor functioning for safety reasons.

Troubleshooting

- Check the VEHICLE connector of the Marelli control unit, the filter box large connector and the throttle control unit connector: if not OK, restore. If OK, check continuity between the Marelli control unit and the throttle control unit connector from VEHICLE PIN 55 to PIN B7 and from PIN 56 to PIN A7: if not OK, restore. If OK, check that with throttle control unit connector disconnected and with key set to ON, there is no voltage on PINS A7 and B7: if there is voltage, replace the cable harness. If there is no voltage, check that PINS A7 and B7 are insulated from ground connection: if they are not insulated from the ground connection, replace the cable harness. If they are insulated, replace the throttle control unit or the Marelli control unit.

### NAVIGATOR: NOTES

After installing the control unit and setting the key to ON, wait for 3 seconds, time during which the control unit detects the throttle valve position.

Connect to Navigator and check that the status for **Throttle self-learning is carried out** and the status for **Handle self-learning is not carried out** (this last status entails Urgent service being displayed on the instrument panel).

If Throttle Self-learning shows **Not carried out**, go to stage 1. If it shows **Carried out**, go to stage 2.

**Stage 1:** current errors have probably been detected by the control unit: solve these malfunctions and check the Throttle Self-learning status again. Throttle Self-learning can also be checked from the Parameter adjustment (screwdriver and hammer) screen page.

**Stage 2:** Carry out the Handle Self-learning from the Parameter adjustment (screwdriver and hammer) screen page and check that Handle Self-learning status is Carried out. If it is not correct or the voltage detected on the throttle is out of scale (check with Navigator) or if current errors are probably detected by the control unit: solve these malfunctions and repeat the procedure.

---


## Battery

---

### Characteristic

#### Battery

12 V - 10 Ah or 12 V - 12 Ah



---

## Battery installation

### NOTE

THE FIRST TIME THE ENGINE IS STARTED AFTER RECONNECTING THE BATTERY LEADS, WAIT 20 SECONDS BETWEEN THE MOMENT THE KEY IS SET TO "KEY ON" AND THE MOMENT THE STARTER BUTTON CAN BE PUSHED.

THE ENGINE WILL NOT START IF START-UP IS ATTEMPTED BEFORE THE PRE-SET 20 SECONDS ELAPSE.

## Speed sensor

### VEHICLE FRONT SPEED SENSOR

**FUNCTION:** To indicate the vehicle speed by reading the front wheel turning speed.

**OPERATION / OPERATING PRINCIPLE:** Magnetoresistive sensor: a square-wave pulse is generated with voltage approx. between 11.55 V and 11.25 V

**WIRING DIAGRAM** Level in wiring diagram: ABS.


### REMOVAL

**LOCATION ON THE VEHICLE:** on the fork, right stem, next to the brake calliper support.

**CONNECTOR LOCATION (if available):** under the helmet compartment.

### PINS

- PIN 1 - Ground connection (white)
- PIN 2 - Power supply voltage/Output signal (white/brown)



### NAVIGATOR

**Parameters:** Speed (km/h) - Vehicle speed.

### ELECTRICAL ERRORS

#### Speed sensor

**5D90 electric malfunction:** Electrical fault in sensor or cable harness.

**Troubleshooting:** Check the sensor connector and the ABS control unit connector. If they are not OK, restore the connectors. If they are OK, check continuity of the white/brown cable between PIN 2 of the sensor on the cable harness side and PIN 14 of the ABS control unit connector. If there is no continuity, restore them. If there is, PIN 2 of the sensor on the cable harness side, with the sensor disconnected and key set to ON, must have 12V voltage approximately: if there is no voltage, check PIN 2 for continuity with the vehicle ground connection: if it is grounded, restore the cable harness. If OK, replace the control unit. If PIN 2 has approx. 12 V, check the continuity of the white cable between PIN 1 of the sensor on the cable harness side and PIN 13 of the ABS control unit connector. If there is no continuity, restore the cable harness. If there is, replace the logic errors sensor.

### LOGIC ERRORS

**Speed sensor**

**5D91 the signal works irregularly:** faulty sensor or signal interference.

**Troubleshooting:** Check speed sensor retainer. If it is not OK, restore it. If it is OK, check if the tone wheel is dirty, deformed or wrongly fixed. If any of this happens, replace the tone wheel. Otherwise, replace the speed sensor.

**5D92 the signal decreases periodically:** Possible tone wheel fault due to deformations or dirt; possible alterations on the wheel bearing surface. In very rare cases, abnormal tone wheel vibrations.

**Troubleshooting:** Check if the tone wheel is dirty, deformed or wrongly fixed. If the tone wheel is not OK, replace it. If it is OK, check for possible faults in the wheel bearings and if it is not OK, replace the bearings.

**5D93 missing signal or speed measured too low in relation to the rear wheel:** faulty sensor or missing sensor/tone wheel. Or excessive distance between the sensor and the tone wheel or tone wheel with wrong number of teeth.

**Troubleshooting:** Check that the speed sensor and the tone wheel are installed. If they are not, install them. If they are, check the speed sensor retainer. If it is not OK, restore it. If it is, check if the tone wheel has the correct number of teeth or if it is dirty, deformed or wrongly fixed. If it is not OK, replace the tone wheel and if it is OK, replace the speed sensor.

**5D94 no acceleration after pressure reduction:** Faulty sensor or missing sensor/tone wheel or excessive distance between the sensor and the tone wheel.

**Troubleshooting:** Check that the speed sensor and the tone wheel are installed. If they are not, install them. If they are, check the speed sensor retainer. If it is not OK, restore it. If it is, check if the tone wheel has the correct number of teeth or if it is dirty, deformed or wrongly fixed. If it is not OK, replace the tone wheel and if it is OK, replace the speed sensor.

**5D95 excessive speed measured:** Faulty sensor or tone wheel, or tone wheel with wrong number of teeth or wrong tyre size.

**Troubleshooting:** Check that the speed sensor and the tone wheel are installed. If they are not, install them. If they are, check the speed sensor retainer. If it is not OK, restore it. If it is, check if the tone wheel has the correct number of teeth or if it is dirty, deformed or wrongly fixed. If it is not OK, replace the tone wheel and if it is OK, check that the tyre size is the correct one. If it is not OK, replace it. If it is OK, check that the tyre pressure is the correct one. If it is not OK, restore it; if it is OK, replace the speed sensor.

---

**VEHICLE REAR SPEED SENSOR**

**FUNCTION:** To indicate the vehicle speed by reading the rear wheel turning speed.

**OPERATION / OPERATING PRINCIPLE:** Magnetoresistive sensor: a square-wave pulse is generated with voltage approx. between 11.55 V and 11.25 V

**WIRING DIAGRAM** Level in wiring diagram: ABS.


**REMOVAL**

**LOCATION ON THE VEHICLE:** on the swingarm, right side, under the chain tension screw.

**CONNECTOR LOCATION (if available):** under the saddle, right side.

**PINS**

- PIN 1 - Ground connection (yellow)
- PIN 2 - Power supply voltage/Output signal (yellow/brown)

**NAVIGATOR**

**Parameters:** Speed (km/h) - Vehicle speed.

**ELECTRICAL ERRORS****Speed sensor**

**5DA0 electric malfunction:** Electrical fault in sensor or cable harness.

**Troubleshooting:** Check the sensor connector and the ABS control unit connector. If they are not OK, restore the connectors. If they are OK, check continuity of the yellow/brown cable between PIN 2 of the sensor on the cable harness side and PIN 11 of the ABS control unit connector. If there is no continuity, restore them. If there is, PIN 2 of the sensor on the cable harness side, with the sensor disconnected and key set to ON, must have 12V voltage approximately: if there is no voltage, check PIN 2 for continuity with the vehicle ground connection: if it is grounded, restore the cable harness. If OK, replace the control unit. If PIN 2 has approx. 12 V, check continuity of the yellow cable between PIN 1 of the sensor on the cable harness side and PIN 12 of the ABS control unit connector. If this is not OK, restore the cable harness. If it is OK, replace the sensor.

**LOGIC ERRORS****Speed sensor**

**5DA1 the signal works irregularly:** faulty sensor or signal interference.

**Troubleshooting:** Check speed sensor retainer. If it is not OK, restore it. If it is OK, check if the tone wheel is dirty, deformed or wrongly fixed. If any of this happens, replace the tone wheel. Otherwise, replace the speed sensor.

**5DA2 the signal decreases periodically:** Possible tone wheel fault due to deformations or dirt; possible alterations on the wheel bearing surface. In very rare cases, abnormal tone wheel vibrations.

**Troubleshooting:** Check if the tone wheel is dirty, deformed or wrongly fixed. If the tone wheel is not OK, replace it. If it is OK, check for possible faults in the wheel bearings and if it is not OK, replace the bearings.

**5DA3 no signal or speed measured too low in relation to the front wheel:** Faulty sensor or missing sensor/tone wheel. Or excessive distance between the sensor and the tone wheel or tone wheel with wrong number of teeth.

**Troubleshooting:** Check that the speed sensor and the tone wheel are installed. If they are not, install them. If they are, check the speed sensor retainer. If it is not OK, restore it. If it is, check if the tone wheel has the correct number of teeth or if it is dirty, deformed or wrongly fixed. If it is not OK, replace the tone wheel and if it is OK, replace the speed sensor.

**5DA4 missing acceleration after pressure reduction:** Faulty sensor or missing sensor/tone wheel or excessive distance between the sensor and the tone wheel.

**Troubleshooting:** Check that the speed sensor and the tone wheel are installed. If they are not, install them. If they are, check the speed sensor retainer. If it is not OK, restore it. If it is, check if the tone wheel has the correct number of teeth or if it is dirty, deformed or wrongly fixed. If it is not OK, replace the tone wheel and if it is OK, replace the speed sensor.

**5DA5 excessive measured speed:** Faulty sensor or tone wheel, or tone wheel with wrong number of teeth or wrong tyre size.

**Troubleshooting:** Check that the speed sensor and the tone wheel are installed. If they are not, install them. If they are, check the speed sensor retainer. If it is not OK, restore it. If it is, check if the tone wheel has the correct number of teeth or if it is dirty, deformed or wrongly fixed. If it is not OK, replace the tone wheel and if it is OK, check that the tyre size is the correct one. If it is not OK, replace it. If it is OK, check that the tyre pressure is the correct one. If it is not OK, restore it; if it is OK, replace the speed sensor.

---

## Engine rpm sensor

### ENGINE SPEED SENSOR

#### Function

It informs crankshaft position and speed to the Marelli control unit.

#### Operation / Operating principle


Inductive sensor: sinusoidal-type generated voltage; two teeth are missing on the flywheel for the reference position.



**Level in electrical circuit diagram:** engine speed sensor

**Location:**

- on the vehicle: inside the flywheel cover
- connector (if available): near the Marelli control unit



**Electrical characteristics:**

- Resistance at ambient temperature:  
130 +/- 20 Ohm

**Pin-out:**

1. Negative signal
2. Positive signal

**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: PARAMETERS**

Engine rpm

**NAVIGATOR: STATUSES**

**Synchronised panel**

**Example value:**Start-up\_Lean\_Rich\_Fault due to rich value\_Fault due to lean value

If the probe connector is removed (voltage almost equal to zero), the status is Fault due to lean value

**Example value:**No\_under analysis\_standby\_Yes

The parameter refers to the engine revs signal: in case the signal has not been correctly identified yet, the under analysis or standby statuses may be displayed.

**NAVIGATOR: ACTIVATION**

-

**NAVIGATOR: ELECTRICAL ERRORS**

-

**CAUTION**

**IF THE ELECTRIC CIRCUIT IS INTERRUPTED OR SHORT-CIRCUITED OR NO ERROR IS DISPLAYED, CHECK THE ENGINE SPEED SENSOR CONNECTOR AND THE MARELLI CONTROL UNIT CONNECTOR: IF NOT OK, RESTORE; IF OK, CHECK THE SENSOR ELECTRIC CHARACTERISTIC IS THE CORRECT ONE: IF IT IS NOT, REPLACE THE SENSOR. IF IT IS THE CORRECT ONE, CHECK THAT THERE IS CONTINUITY ON BOTH CABLES, SUPPLY INSULATION AND GROUND CONNECTION INSULATION. CARRY OUT THE TESTS FROM THE SENSOR CONNECTOR TO THE SENSOR. IF NOT OK, RESTORE THE CABLE HARNESS/REPLACE THE SENSOR. IF OK, PERFORM THE TEST FROM PINS 9 AND 23 OF THE MARELLI CONTROL UNIT ENGINE CONNECTOR.**

**NAVIGATOR: LOGIC ERRORS**

**Engine speed sensor P0336 - Synchronism lost**Error cause

- Displayed if the signal is not as the control unit expects, for example due to voltage fluctuations not correctly repeated.

Troubleshooting

- Check that the flywheel teeth are clean and the sensor is adequately placed in its fitting: if not OK, restore; if OK, replace the sensor.

---

**Twistgrip position sensor****THROTTLE GRIP POSITION SENSOR****Function**

The throttle grip is the part to which the throttle control cables arrive; its task is to translate the rider's power request (Demand) into an electrical signal to be sent to the electronic control unit.

**Operation / Operating principle**

The two throttle cables (opening and closing) actuate on a scroll mounted on a shaft which is sent back to its home position by a return spring. On the shaft covers there are 2 double track potentiometers (4 control tracks) by means of which the torque demand is read (and checked). The 4 potentiometers are tinned and magnetically controlled (contactless); they cannot be overhauled nor replaced

**Level in electrical circuit diagram:** Throttle grip position sensor.

**Location:**

- on the vehicle: under the fuel tank
- connector: direct to the Marelli control unit

**Electrical characteristics:**


- Not detected by a multimeter as they are contactless: read voltage on the 4 tracks through Navigator.


**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**CAUTION**

THE TWO CONNECTORS WHICH GET TO THE THROTTLE GRIP SENSOR ARE ALIKE BUT THEY SHOULD NEVER BE INVERTED. MARK OR CHECK THE CONNECTOR MARKING BEFORE REMOVING THEM (BLUE STAMP + BLUE BAND). THE CONNECTOR AND THE BLUE BAND SHOULD BE PLACED TO THE LEFT. THE CONNECTOR AND THE WHITE BAND SHOULD BE PLACED TO THE RIGHT.





### NAVIGATOR: PARAMETERS

#### Left side throttle grip position sensor - track A

example value: 1107 mV

Voltage value of the left potentiometer track A

#### Left side throttle grip position sensor - track B

example value: 1107 mV

Voltage value times 2 of the left potentiometer track B

#### Right side throttle grip position sensor - track C

3560 mV

Voltage value of the left potentiometer track C

#### Right side throttle grip position sensor - track D

3555 mV

Voltage value times 2 of the left potentiometer track D

#### Throttle grip position sensor

1107 mV

Voltage corresponding to the potentiometer track A

#### Throttle grip opening percentage

0 %

With a released throttle grip, the value read should be 0%, whereas 100 % should be read with throttle grip fully twisted.

### NAVIGATOR: STATUSES

#### Throttle grip

**Example value:** Slightly twisted\_choked\_fully twisted

#### Handle self-learning

**Example value:** carried out/not carried out

### NAVIGATOR: PARAMETER ADJUSTMENT

#### Handle self-learning

### NAVIGATOR: ELECTRICAL ERRORS

**Left side throttle grip position sensor track A P0150-** short circuit to positive / open circuit, short circuit to negative

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 42 of the VEHICLE connector. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 42 of the VEHICLE connector.

Troubleshooting

- shorted to positive: check the value shown by the parameter of the left Throttle Grip Position Sensor - track A: disconnect the left connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle grip sensor if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle grip sensor connector and the Marelli control unit connector. If not OK, restore. If OK, check circuit continuity between the two cable terminals. If not OK, restore; if OK, check the cable ground insulation (from the throttle grip sensor connector or the control unit connector): if the cable is not ground insulated, restore the wiring. If it is ground insulated, and with the key set to ON, check that there is power supply for the potentiometer PIN A and that PIN C is connected to ground. If both are correct, replace the throttle grip sensor; if not, check the continuity of the cable that is not functioning properly: if there is continuity, replace the control unit; if not, restore the wiring

**Left side Throttle Grip Position sensor - track B P0151-** short circuit to positive / open circuit, short circuit to negative

Error cause

- Voltage that is excessive / equal to zero has been detected at PIN 40 of the VEHICLE connector.

Troubleshooting

- short circuit to positive: check the value shown by the parameter of the left Throttle Grip position Sensor track B: disconnect the left connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle grip sensor if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle grip sensor connector and the Marelli control unit connector. If not OK, restore. If OK, check circuit continuity between the two cable terminals. If not OK, restore; if OK, check the cable ground insulation (from the throttle grip sensor connector or the control unit connector): if the cable is not ground insulated, restore the wiring. If it is ground insulated, and with the switch key set to ON, check that there is power supply for the potentiometer PIN D and that PIN F is connected to ground. If both are correct, replace the throttle grip sensor; if not, check the continuity of the cable that is not functioning properly: if there is continuity, replace the control unit; if not, restore the wiring.

**Right side Throttle Grip Position sensor - track C P0152**- short circuit to positive / open circuit, short circuit to negative.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 30 of the ENGINE connector. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 30 of the ENGINE connector.

Troubleshooting

- shorted to positive: check the value shown by the parameter of the right Throttle Grip position Sensor - track C: disconnect the right connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle grip sensor if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle grip sensor connector and the Marelli control unit connector. If not OK, restore. If OK, check circuit continuity between the two cable terminals. If not OK, restore; if OK, check the cable ground insulation (from the throttle grip sensor connector or the control unit connector): if the cable is not ground insulated, restore the wiring. If it is ground insulated, and with the key set to ON, check that there is power supply for the potentiometer PIN A and that PIN C is connected to ground. If both are correct, replace the throttle grip sensor; if not, check the continuity of the cable that is not functioning properly: if there is continuity, replace the control unit; if not, restore the wiring

**Right side Throttle Grip Position sensor - track D P0153** - short circuit to positive / open circuit, short circuit to negative.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 44 of the ENGINE connector. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 44 of the ENGINE connector.

Troubleshooting

- shorted to positive: check the value shown by the parameter of the right Throttle Grip Position Sensor - track D: disconnect the right connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle grip sensor if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle grip sensor connector and the Marelli control unit connector. If not OK, restore. If OK, check circuit continuity between the two cable terminals. If not OK, restore; if OK, check the cable ground insulation (from the throttle grip sensor connector or the control unit connector): if the cable is not ground insulated, restore the wiring. If it is ground insulated, and with the switch key set to ON, check that there is power supply for the potentiometer PIN D and that PIN F is connected to ground. If both are correct, replace the throttle grip sensor; if not, check the continuity of the cable

that is not functioning properly: if there is continuity, replace the control unit; if not, restore the wiring.

### NAVIGATOR: LOGIC ERRORS

**Left side Throttle Grip Position (tracks A-B) P0154** - illogical signals.

#### Error cause

- Two illogical voltage signals have been detected at PINS 42 and 40 of the VEHICLE connector (tracks A-B)

#### Troubleshooting

- Check the parameters of the left Throttle Grip Position Sensor - tracks A and B: if one of the two values clearly deviates from 600-1400 mV, it means that this potentiometer is defective. Check the throttle grip sensor connector and the control unit connector: if not OK, restore. If OK, check that cable resistance between the throttle grip sensor connector and the control unit is a few tenths of Ohm: if this is not the case, restore wiring. If the value is correct, replace the complete throttle grip sensor.

**Right side Throttle Grip Position (tracks C-D) P0155** - illogical signal.

#### Error cause

- Two illogical voltage signals have been detected at PINS 30 and 44 of the ENGINE connector (tracks A-B)

#### Troubleshooting

- Check the parameters of the left Throttle Grip Position Sensor - tracks C and D: if one of the two values clearly deviates from 600-1400 mV, it means that this potentiometer is defective. Check the throttle grip sensor connector and the control unit connector: if not OK, restore. If OK, check that cable resistance between the throttle grip sensor connector and the control unit is a few tenths of Ohm: if this is not the case, restore wiring. If the value is correct, replace the complete throttle grip sensor

**Throttle Grip position P0156** - illogical signal.

#### Error cause

- The value of the left side sensor (tracks A-B) does not coincide with the value of the right side sensor (tracks C-D).

#### Troubleshooting

- Replace the throttle grip sensor

### RESET PROCEDURE

If the Marelli control unit or the throttle grip sensor is replaced, check the Handle self-learning with the diagnosis instrument: once the check is completed, make sure that the Handle self-learning status indicates: carried out.

#### CAUTION

**THE TWO CONNECTORS WHICH GET TO THE THROTTLE GRIP SENSOR ARE ALIKE BUT THEY SHOULD NEVER BE INVERTED. MARK OR CHECK THE CONNECTOR MARKING BEFORE RE-**

**MOVING THEM (BLUE STAMP + BLUE BAND). THE CONNECTOR AND THE BLUE BAND SHOULD BE PLACED TO THE LEFT. THE CONNECTOR AND THE WHITE BAND SHOULD BE PLACED TO THE RIGHT.**

**NOTES** The two connectors which get to the throttle grip sensor are the same but they should NEVER be inverted. Mark or check the connector marking before removing them (blue stamp+blue band).

#### Removal

- When required, disconnect the corresponding connectors, undo and remove the two screws and remove the throttle grip position sensor.



## Intake pressure sensor

### INTAKE AIR PRESSURE SENSOR

#### Function

The pressure sensors (one per cylinder) are fundamental not only for the injection configuration at low and stabilised speeds, but also for checking the Ride by wire system: their signal is connected to a TORQUE CHAIN for checking the correct opening of the throttle valves.

#### Operation / Operating principle

Diaphragm sensor which translates the diaphragm position into electrical voltage when in contact with the intake air.



**Level in electrical circuit diagram:** intake air pressure sensor


#### Location:

- on the vehicle: inside the filter box
- connector: on the sensor

#### Pin-out:

- Fuel system
- Ground connection
- Output signal



**NAVIGATOR: PARAMETERS****Front Cylinder Intake Pressure**

example value: 1003 mbar

Pressure read by the front sensor.

**Rear Cylinder Intake Pressure**

example value: 1004 mbar

Pressure read by the rear sensor.

**Front Cylinder estimated Intake Pressure**

example value: 1003 mbar

Pressure estimated by the control unit according to the throttle position.

**Rear Cylinder estimated Intake Pressure**

example value: 1004 mbar

Pressure estimated by the control unit according to the throttle position.

**NAVIGATOR: ELECTRICAL ERRORS**

**Front cylinder air pressure sensor P0105** - short circuit to positive / open circuit, short circuit to negative.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 34 of the VEHICLE connector.
- If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 34 of the VEHICLE connector.

Troubleshooting

- If short circuit to positive, see that the parameter of the front Cylinder Intake Pressure on the diagnosis instrument reads approx. 1200 mbar; disconnect the large connector from the filter box: if the value does not vary, it means that the cable is shorted between the filter box connector and the control unit connector; restore the cable harness. If the value varies, reconnect the filter box connector and disconnect the sensor connector: if the value does not vary, it means that the cable is shorted between the filter box connector and the sensor connector; restore the cable harness. Replace the sensor if the value varies.

- If the circuit is open, short circuit to negative, check filter box large connector, the Marelli control unit connector and the sensor connector. If not OK, restore. If everything is OK, and with key set to OFF, check if there is continuity between the VEHICLE PIN 34 of the Marelli control unit and the sensor connector PIN 3: if there is no continuity, restore the cable harness. If there is continuity, check the cable ground insulation: if there is continuity to ground, restore the cable harness; if not, with key set to ON check that the voltage on sensor connector PIN 1 is approx. 5 V: if this is not correct, set the key to OFF and check continuity between the ENGINE connector PIN 15 and the sensor connector PIN 1: If not OK, restore the cable harness; if it is OK, replace the control unit. If there is 5V voltage at PIN 1, and with key set to ON, check the continuity to ground of the sensor connector PIN 3: if not OK, restore the cable harness; if OK, replace the sensor.

**Rear cylinder air pressure sensor P0106** -short circuit to positive / open circuit, short circuit to negative.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 5 of the VEHICLE connector.
- If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 5 of the VEHICLE connector.

Troubleshooting

- If short circuit to positive, see that the parameter of the front Cylinder Intake Pressure on the diagnosis instrument reads approx. 1200 mbar; disconnect the large connector from the filter box: if the value does not vary, it means that the cable is short circuited between the filter box connector and the control unit connector; restore the cable harness. If the value varies, reconnect the filter box connector and disconnect the sensor connector: if the value does not vary, it means that the cable is short circuited between the filter box connector and the sensor connector; restore the cable harness. Replace the sensor if the value varies.
- If the circuit is open, short circuit to negative, check the filter box large connector, the Marelli control unit connector and the sensor connector; If not OK, restore. If everything is OK, and with key set to OFF, check if there is continuity between the VEHICLE PIN 5 of the Marelli control unit and the sensor connector PIN 3: if there is no continuity, restore the cable harness. If there is continuity, check the cable ground insulation: if there is continuity to ground, restore the cable harness; if not, with key set to ON check that the voltage on sensor connector PIN 1 is approx. 5 V: if this is not correct, set the key to OFF and check continuity between the ENGINE connector PIN 15 and the sensor connector PIN 1: If not OK, restore the cable harness; if it is OK, replace the control unit. If there is 5V voltage at PIN 1, and with key set to ON, check the continuity to ground of the sensor connector PIN 3: if not OK, restore the cable harness; if OK, replace the sensor.

**NAVIGATOR: LOGIC ERRORS**

**front cylinder air pressure sensor P0107** - signal not valid.Error cause

- According to the engine operation data (rpm, throttle, etc.) an average value for the intake pressure is estimated: if the value read deviates by a given percentage, this error is activated. The most frequent causes can be: abnormal resistance in the sensor circuit (for example, rusted terminals) or sensor with poor performance.

Troubleshooting

- Check the filter box large connector, the Marelli control unit connector and the sensor connector; if not OK, restore. If everything is OK, check that cable resistance between VEHICLE connector PIN 34 and sensor connector PIN 3 is a few tenths of an Ohm. If it is above that value, restore cable harness. Replace the sensor if it is correct.

**rear cylinder air pressure sensor P0108** - signal not valid.Error cause

- According to the engine operation data (rpm, throttle, etc.) an average value for the intake pressure is estimated: if the value read deviates by a given percentage, this error is activated. The most frequent causes can be: abnormal resistance in the sensor circuit (for example, rusted terminals) or sensor with poor performance.

Troubleshooting

- Check the filter box large connector, the Marelli control unit connector and the sensor connector; if not OK, restore. If everything is OK, check that resistance between VEHICLE connector PIN 5 and sensor connector PIN 3 is a few tenths of an Ohm. If it is above that value, restore cable harness. Replace the sensor if it is correct.

**Error for unexpected intake air in the front cylinder manifold P0210** - signal not valid.Error cause

- A small difference between the estimated pressure and the measured pressure has been detected: the measured pressure is higher than the estimated one (for example, cut or wrongly connected pipe between sensor and throttle body or a hole in the intake manifold).

Troubleshooting

- Check the pneumatic system between the pressure sensor and the socket to read pressure on the throttle body; check that the intake manifold is in good conditions and the pressure reading hole is clean.

**Error for unexpected intake air in the rear cylinder manifold P0211** - signal not valid.Error cause

- A small difference between the estimated pressure and the measured pressure has been detected: the measured pressure is higher than the estimated one (for example, cut or wrongly connected pipe between sensor and throttle body or a hole in the intake manifold).

Troubleshooting

- Check the pneumatic system between the pressure sensor and the socket to read pressure on the throttle body; check that the intake manifold is in good conditions and the pressure reading hole is clean.

**Estimation error for front cylinder intake manifold pressure P0215** - pressure too high/pressure too low.

Error cause

- A substantial difference between the estimated pressure and the measured pressure has been detected (for example, the pipe between sensor and throttle body is fully detached/clogged or squashed).

Troubleshooting

- Check the pneumatic system between the pressure sensor and the socket to read pressure on the throttle body; check that the intake manifold is in good conditions and the pressure reading hole is clean: there is an evident defect in the intake and pressure reading systems.

**Estimation error for rear cylinder intake manifold pressure P0216** - pressure too high/pressure too low.

Error cause

- A substantial difference between the estimated pressure and the measured pressure has been detected (for example, the pipe between sensor and throttle body is fully detached/clogged or squashed).

Troubleshooting

- Check the pneumatic system between the pressure sensor and the socket to read pressure on the throttle body; check that the intake manifold is in good conditions and the pressure reading hole is clean: there is an evident defect in the intake and pressure reading systems.

**Pressure too low at front cylinder manifold error P0217** - signal not valid.

- A small difference between the estimated pressure and the measured pressure has been detected: the measured pressure is below the estimated one (for example, smeared throttle body).

Troubleshooting

- Check the pneumatic system between the pressure sensor and the socket to read pressure on the throttle body; check that the intake manifold is in good conditions and the pressure reading hole is clean.

**Pressure too low at rear cylinder manifold error P0218** - signal not valid.

Error cause

- A small difference between the estimated pressure and the measured pressure has been detected: the measured pressure is below the estimated one (for example, smeared throttle body).

#### Troubleshooting

- Check the pneumatic system between the pressure sensor and the socket to read pressure on the throttle body; check that the intake manifold is in good conditions and the pressure reading hole is clean.

## Engine temperature sensor

### ENGINE TEMPERATURE SENSOR

#### Function

tells the engine temperature to the control unit so as to optimise its operation.

#### Operation / Operating principle

NTC type sensor (resistance sensor, inversely variable with temperature).

**Level in electrical circuit diagram:** Temperature sensors

#### Location:



- on the vehicle: on the front cylinder on the internal side facing the rear cylinder
- connector: on the sensor

#### Electrical characteristics:

- Resistance at 25°: 2.05 kOhm +/- 100 Ohm
- Resistance at 60°: 575 Ohm +/- 15 Ohm
- Resistance at 90°: 230 Ohm +/- 5 Ohm

#### Pin-out:

1. Yellow brown: 0-5 V signal: PIN B1
2. Brown: PIN B2 ground connection



#### CAUTION

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

#### NAVIGATOR: PARAMETERS

#### Engine temperature

example value: 75° C

In case of recovery, this value is set by the control unit.

#### **Engine Temp. before Recovery**

example value: -40° C

Value drawn from the signal read without taking into account any recovery: the value in the example refers to an open circuit.

### **NAVIGATOR: ELECTRICAL ERRORS**

**engine temperature sensor P0115** - open circuit, shorted to positive / shorted to negative.

#### Error cause

- If the circuit is open, shorted to positive: excessive voltage has been detected at PIN 45 of the ENGINE connector. If shorted to negative: voltage equal to zero has been detected at PIN 45 of the ENGINE connector.
- If the circuit is open, shorted to positive: check the sensor connector and the Marelli control unit connector. If they are OK, check sensor continuity: replace the sensor if not OK; if it is OK, check the continuity between the ENGINE connector PIN 45 and the sensor PIN 1: restore cable harness if there is not continuity; if it is OK, reconnect the control unit connector and, with key set to key ON, check the continuity between the sensor connector PIN 2 and the vehicle ground connection: if it is correct, it means that the error cause is that the cable is short circuit to positive and it is necessary to restore the cable harness between the ENGINE PIN 45 and the sensor PIN 1; if there is no continuity with the ground connection, check the sensor connector and the Marelli control unit connector. If not OK, restore the cable harness. If OK, check continuity between the ENGINE connector PIN 35 and the sensor connector PIN 2: restore the cable harness if there is not continuity. If there is, it means that the control unit does not supply the ground connection and therefore should be replaced.

#### Troubleshooting

- If shorted to negative, check sensor correct resistance: if resistance is null, replace the sensor; if resistance is correct, it means that the cable has ground connection: restore the cable harness.

### **NAVIGATOR: LOGIC ERRORS**

**engine temperature sensor P0116** - signal not valid.

#### Error cause

- An excessive temperature variation has been detected: for example, the cause may be a contact resistance between the terminals.

#### Troubleshooting

- Check the sensor connector and the ENGINE connector of the Marelli control unit.

**NOTES** No error is detected if the sensor does not work correctly or the control unit connector or sensor terminals are rusty: then check through Navigator if the temperature indicated is the

same as the engine temperature. Check also that the sensor electrical characteristics are observed: replace the sensor if not OK; if it is OK, check the sensor connector and the Marelli control unit connector

## Air temperature sensor

### INTAKE AIR TEMPERATURE SENSOR

#### Function

It tells the control unit the intake air temperature in order to calculate oxygen presence so as to optimise the petrol quantity necessary for correct combustion.

#### Operation / Operating principle

NTC type sensor (resistance sensor, inversely variable with temperature).

**Level in electrical circuit diagram:** Temperature sensors

#### Location:


- on the vehicle: on filter box
- on connector sensor: near the probes

#### Electrical characteristics:

- Resistance at 0°: 32.5 k $\Omega$  +/- 5%
- Resistance at 25°: 10.0 k $\Omega$  +/- 5%

#### Pin-out:

1. 0-5 V signal: PIN 1
2. Ground connection: PIN 2



#### CAUTION

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

#### NAVIGATOR: PARAMETERS

##### Air temperature

**Example value:** 26° C

In case of recovery, this value is set by the control unit.

##### Air Temp. before Recovery

**Example value:** -40° C

Value drawn from the signal read without taking into account any recovery: the value in the example refers to an open circuit.

#### NAVIGATOR: ELECTRICAL ERRORS

**air temperature sensor P0110** - open circuit, shorted to positive / shorted to negative.

Error cause

- If the circuit is open, shorted to positive: excessive voltage has been detected at PIN 63 of the ENGINE connector. If shorted to negative: voltage equal to zero has been detected at PIN 63 of the ENGINE connector.

Troubleshooting

- If the circuit is open, shorted to positive: check the sensor connector and the Marelli control unit connector. If they are OK, check sensor continuity: replace the sensor if not OK; if it is OK, check continuity between the ENGINE connector PIN 63 and the sensor PIN 1: restore cable harness if there is not continuity; if it is OK, reconnect the control unit connector and, with key set to key ON, check the continuity between the sensor connector PIN 2 and the vehicle ground connection: if it is OK, it means that the error cause is that the cable is short circuit to positive and it is necessary to restore the cable harness between the ENGINE PIN 63 and the sensor PIN 1; check the sensor connector and the Marelli control unit connector. If not OK, restore the cable harness. If OK, check continuity between the ENGINE connector PIN 35 and the sensor connector PIN 2: restore the cable harness if there is not continuity. If there is, it means that the control unit does not supply the ground connection and therefore should be replaced.
- If shorted to negative, check sensor correct resistance: if resistance = 0, replace the sensor; if resistance is correct, it means that the cable has ground connection: restore the cable harness.

**NOTES** No error is detected if the sensor does not work correctly or the control unit connector or sensor terminals are rusty: then check through Navigator if the temperature indicated is plausible in relation to the ambient temperature. Check also that the sensor electrical characteristics are observed: replace the sensor if not OK; if it is OK, check the sensor connector and the Marelli control unit connector.

---

## Lambda sensor

---


### LAMBDA PROBE

#### Function

In charge of telling the control unit whether the mixture is lean or rich.

#### Operation / Operating principle

The Marelli injection control unit reads and interprets a voltage generated by the difference in oxygen content between the exhaust fumes and the



ambient. It does not require an external supply source but, in order to work properly, it should reach a high operating temperature: that is why there is a heating circuit inside.

**Level in electrical circuit diagram:** Lambda probe

**Location:**

- on the vehicle: exhaust pipe

**UP TO CHASSIS NUMBER**

**ZD4SMA002AS000983**

- connector: on the inner side of the frame, on the right hand side.

**FROM CHASSIS NUMBER**

**ZD4SMA002AS000984**


- connector: above the clutch side housing.

**Electrical characteristics:**

- Oxygen probe with preheating circuit (power 7W)
- It generates voltage within: 0 - 1000 mV
- Heater circuit: continuity (7 - 9 Ohm at ambient temperature)

**Pin-out:**

1. Sensor signal + (black wire)
2. Sensor signal - (grey wire)
3. Heater ground connection (white)
4. Heater power supply (white)



**THE CONNECTION DIAGRAMS ARE IN THE ELECTRICAL SYSTEM SECTIONS; PAY ATTENTION TO THESE DIAGRAMS AS THEY SHOW THE CONNECTOR/COMPONENT AS VIEWED FROM THE CABLE HARNESS SIDE, THAT IS LOOKING AT THE CABLES WHEN GOING OUT OF THE "MAIN" CABLE HARNESS AND INTO THE CONNECTOR/COMPONENT.**

**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: PARAMETERS**

**Lambda probe**

example value: 0 - 1000 mV

If there is a short circuit at + 5 V or above, the lambda probe parameter is not equal to the value read by the control unit; a recovery value is displayed instead.

#### **Lambda sensor correction**

example value: 1.00

In closed loop, the value must be close to 1.00 (values not within the 0.90 - 1.10 interval indicate a fault): for example, value 0.75 corresponds to +25% with respect to the reference injection time; 1.25 corresponds to -25%. In an open circuit, the lambda probe signal is too low. Therefore, the control unit takes it as a lean combustion condition and will try to enrich it. The value read will be 0.75: once this correction has been tried, the value shifts to 1.00 fixed and the Lambda probe error is signalled.

### **NAVIGATOR: STATUSES**

#### **Lambda**

**Example value:** Start-up\_Lean\_Rich\_Fault due to rich value\_Fault due to lean value

If the probe connector is removed (voltage almost equal to zero), the status is Fault due to lean value

#### **Lambda check**

**Example value:** Open loop/Closed loop/Rich in closed loop/Lean in closed loop/enriched

Closed loop indicates that the control unit is using the lambda probe signal to keep the combustion as close as possible to the stoichiometric value.

### **NAVIGATOR: ACTIVATION**

#### **Lambda probe heating**

The auxiliary injection relay (No. 40 in the wiring diagram, placed under the fuel tank, right side, second relay starting from the front; CHECK, however, the identification of the relay with the colour of the cables) is energised and the heating circuit is closed to ground 5 times (pin 3 of the lambda probe connector). The continuity of the wiring is necessary for correct activation: no error indications are displayed in case of lack of activation.

### **NAVIGATOR: ELECTRICAL ERRORS**

**Lambda probe P0130** - Shorted to positive.

#### Error cause

- Excessive voltage (battery voltage) has been detected at PIN 43 of the ENGINE connector.  
Caution: the 'lambda probe' parameter is not the real value that is read; a recovery value is displayed instead.

#### Troubleshooting

- Shorted to positive: with key set to ON, disconnect the sensor connector and measure PIN 1 voltage on the cable harness side (grey cable): if there is voltage (5 or 12 V), restore the cable harness; if there is not, replace the lambda probe.

**Lambda probe heating P0135** - shorted to positive / open circuit, shorted to negative.

#### Error cause

- Shorted to positive: excessive voltage has been detected at PIN 32 of the ENGINE connector.
- If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 32 of the ENGINE connector.

#### Troubleshooting

- Shorted to positive: disconnect the probe connector and check the sensor correct resistance: replace the sensor if not OK; if it is OK, restore the cable harness.
- circuit is open, shorted to negative: check the continuity from probe connector (PIN 3 and 4) towards the probe: if not OK, replace the probe; if it is correct, check the sensor connector and the Marelli control unit connector. If not OK, restore. If OK, and with key set to ON and sensor connector disconnected, check if there is battery voltage at PIN 4: if not ok, check the red/black cable between the probe connector and the auxiliary injection relay (No. 40 in the wiring diagram, located under the fuel tank, right side, second relay starting from the front; CHECK, however, the identification of the relay with the colour of the cables). If there are also coil and injector errors, check the relay and its excitation and power line; if there is voltage at PIN 4, check the grey/blue cable ground insulation (PIN 3): if not OK, restore the cable harness. If it is OK, check the continuity of the grey/blue cable (between the sensor connector PIN 3 and the ENGINE PIN 32) and restore the cable harness.

### NAVIGATOR: LOGIC ERRORS

**Lambda probe P0134** - voltage without variation.

#### Error cause

- An abnormal behaviour of the voltage at PIN 43 of the ENGINE connector has been detected: the voltage, that should vary over time, keeps a constant value.

#### Troubleshooting

- Check circuit continuity from probe connector (PIN 1 and PIN 2) toward the probe: replace the lambda probe if there is no continuity; if there is continuity, check the sensor connector and the Marelli control unit connector: If not OK, restore. If OK, check continuity between the ENGINE connector PIN 43 and PIN 60 and restore the cable harness.

#### CAUTION

**IN CASE THE Lambda sensor correction PARAMETER, WITH ENGINE AT IDLE AND H<sub>2</sub>O T >90 °C, WHICH IS NOT WITHIN THE 0.9 - 1.1 RANGE, WITHOUT ERRORS, CHECK:**

**- IF < 0.9, THE PROBE READS LEAN COMBUSTION CONDITIONS AND THE CONTROL UNIT INCREASES INJECTION TIME; CAUSES: CHECK FOR INCORRECT AIR INTAKE, LITTLE PETROL, RUSTY TERMINAL CONTACTS, DEFECTIVE PROBE.**

**- IF > 1.1, THE PROBE READS RICH COMBUSTION CONDITIONS AND THE CONTROL UNIT REDUCES INJECTION TIME; CAUSES: LITTLE AIR, EXCESSIVE PETROL, DEFECTIVE PROBE.**

## Injector

### INJECTOR

#### Function

To supply the correct amount of petrol at the right timing.

#### Operation / Operating principle

Injector coil is excited for the petrol passage to open.

**Level in electrical circuit diagram:** Coils and injectors.

#### Location:


- on the vehicle: inside the filter box
- connector: on injector

#### Electrical characteristics:

- 14.8 Ohm +/- 5% (at 20 °C (68 °F))

#### Pin-out:

1. Supply: "+"
2. Ground connection



#### CAUTION

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

#### NAVIGATOR: PARAMETERS

##### Front cylinder injection time

##### Rear cylinder injection time

#### NAVIGATOR: ACTIVATION

##### Front injector

The auxiliary injection relay (No. 40 in the wiring diagram, placed under the fuel tank, right side, second relay starting from the front; CHECK, however, the identification of the relay with the colour of the cables) is energised for 5 seconds and the grey/green cable of the injector is closed to ground for 4 ms per second. Disconnect the 4-way connector of the fuel pump to be able to hear the relay and injector activation. The continuity of the wiring is necessary for correct activation: no error indications are displayed in case of lack of activation.

##### Rear injector

The auxiliary injection relay (No. 40 in the wiring diagram, placed under the fuel tank, right side, second relay starting from the front; CHECK, however, the identification of the relay with the colour of the cables) is energised for 5 seconds and the grey/red cable of the injector is closed to ground for 4 ms per second. Disconnect the 4-way connector of the fuel pump to be able to hear the relay and injector activation.

The continuity of the wiring is necessary for correct activation: no error indications are displayed in case of lack of activation.

### **NAVIGATOR: ELECTRICAL ERRORS**

**Front cylinder injector P0201** - shorted to positive / shorted to negative / open circuit.

#### Error cause

- If shorted to positive: excessive voltage has been detected at PIN 50 of the ENGINE connector.
- If shorted to negative: no voltage has been detected.
- If the circuit is open: an interruption has been detected.

#### Troubleshooting

- shorted to positive: disconnect the injector connector, set key to ON, activate the component with Navigator and check the voltage on the grey/green cable on the filter box small connector towards the Marelli control unit: if there is voltage, restore the cable harness between the filter box connector and the Marelli control unit. If there is no voltage, reconnect the connector and check if there is voltage at PIN -: if there is voltage, restore the filter box cable harness. If there is no voltage, replace the sensor.
- shorted to negative: disconnect the injector connector, set the key to ON and check if there is a ground connection on the grey/green cable: if there is voltage, restore the cable harness between the filter box connector and the Marelli control unit; if there is no voltage, reconnect the connector and disconnect the injector connector and check if there is a ground connection on PIN -: if there is voltage, restore the filter box cable harness. If there is no voltage, replace the injector.
- the circuit is open: check the component correct electrical characteristic: if it is not correct, replace the component; if it is correct, check the filter box small connector, the connector on the component and the Marelli control unit connector: If not OK, restore; if OK, check cable continuity between ENGINE PIN 50 and component PIN - and restore the cable harness.

**Front cylinder injector P0202** - See front injector

#### Error cause

- If shorted to positive: excessive voltage has been detected at PIN 34 of the ENGINE connector.
- If shorted to negative: no voltage has been detected.
- If the circuit is open: an interruption has been detected.

#### Troubleshooting

- shorted to positive: disconnect the injector connector, set key to ON, activate the component with Navigator and check the voltage on the grey/green cable on the filter box small connector towards the Marelli control unit: if there is voltage, restore the cable harness between the filter box connector and the Marelli control unit. If there is no voltage, reconnect the

connector and check if there is voltage at PIN -: if there is voltage, restore the filter box cable harness. If there is no voltage, replace the sensor.

- shorted to negative: disconnect the injector connector, set the key to ON and check if there is a ground connection on the grey/red cable: if there is voltage, restore the cable harness between the filter box connector and the Marelli control unit; if there is no voltage, reconnect the connector and disconnect the injector connector and check if there is a ground connection on PIN -: if there is voltage, restore the filter box cable harness. If there is no voltage, replace the injector.
- the circuit is open: check the component correct electrical characteristic: if it is not correct, replace the component; if it is correct, check the filter box small connector, the connector on the component and the Marelli control unit connector: If not OK, restore. If OK, check cable continuity between the ENGINE PIN 34 and component PIN - and restore the cable harness.

---

## Coil

### COIL

#### Function

Spark generation.

#### Operation / Operating principle

Inductive discharge system.

**Level in electrical circuit diagram:**coils and injectors.

#### Location:


- on the vehicle: on the cylinder head
- connector (if available): -

#### Electrical characteristics:


- Primary circuit resistance: approx. 1 Ohm at 20°C between PIN 1 and 3.
- Secondary circuit resistance: MOhm value range (with positive probe on coil).

#### Pin-out:


1. Supply + batt V
2. Secondary circuit ground connection
3. Activation from control unit



## FRONT CYLINDER



## REAR CYLINDER

**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: PARAMETERS**

Rear coil ignition advance

Front coil ignition advance

**NAVIGATOR: STATUSES**

-

**NAVIGATOR: ACTIVATION****Front coil**

The auxiliary injection relay (No. 40 in the wiring diagram, placed under the fuel tank, right side, second relay starting from the front; CHECK, however, the identification of the relay with the colour of the cables) is energised for 5 seconds and the sky blue/orange cable of the coil is closed to ground for 2 ms per second. Disconnect the 4-way connector of the fuel pump to be able to hear the relay and injector activation. The continuity of the wiring is necessary for correct activation: no error indications are displayed in case of lack of activation.

**Rear coil**

The auxiliary injection relay (No. 40 in the wiring diagram, placed under the fuel tank, right side, second relay starting from the front; CHECK, however, the identification of the relay with the colour of the cables) is energised for 5 seconds and the sky blue/green of the coil is closed to ground for 2 ms per second. Disconnect the 4-way connector of the fuel pump to be able to hear the relay and injector activation. The continuity of the wiring is necessary for correct activation: no error indications are displayed in case of lack of activation.

**NAVIGATOR: ELECTRICAL ERRORS**

**Lambda probe P0130** - shorted to positive / circuit, shorted to negative

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 17 of the ENGINE connector. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 17 of the ENGINE connector.

Troubleshooting

- shorted to positive: disconnect the coil connector, set the key to ON, activate the coil with Navigator and check voltage at connector PIN 3: if there is voltage, restore the cable harness; if voltage = 0, replace the coil. Open circuit, shorted to negative: check the coil connector and the Marelli control unit connector. If not OK, restore; if everything is OK, check cable continuity between the two cable terminals. If there is no continuity, restore the cable harness; if there is cable continuity, with key set to ON, check the cable ground insulation (from coil connector or control unit connector). If not OK, restore the cable harness.

**Rear coil P0352-** shorted to positive / open circuit, shorted to negative.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 19 of the ENGINE connector.
- If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 19 of the ENGINE connector.

Troubleshooting

- Shorted to positive: disconnect the coil connector, set the key to ON, activate the coil with Navigator and check voltage at connector PIN 3: if there is voltage, restore the cable harness; if voltage = 0, replace the coil.
- If the circuit is open, shorted to negative: check the coil connector and the Marelli control unit connector. If not OK, restore; if everything is OK, check cable continuity between the two cable terminals. If there is no continuity, restore the cable harness; if there is cable continuity, with key set to ON, check the cable ground insulation (from coil connector or control unit connector). If not OK, restore the cable harness.

**NAVIGATOR: LOGIC ERRORS**

-

---

## Throttle body

### THROTTLE BODY

#### Function

To inform the throttle control unit the position of the two throttle valves and to drive them both.

#### Operation / Operating principle

All the unit internal components (potentiometer and electric motor) are contactless; therefore, no electrical diagnosis is possible for the throttle body, only for the circuits connected to it.



**Throttle body activation takes place every time the key is set to ON: correct activation is indicated when the stop lights turn on.**

If during activation, the engine is started, the activation is not completed and the stop lights do not turn on.


Every 150 key-ONs, however, the throttle valves are forced to activation. If start-up is attempted during this activation (which requires 3 seconds), the engine will not start.

#### Level in electrical circuit diagram:

throttle control unit.

#### Location:

- on the vehicle: inside the filter box
- connector: on the throttle body



#### Pin-out:

1. potentiometer signal: 1
2. supply voltage + 5V
3. throttle valve control (+)
4. potentiometer signal: 2
5. throttle valve control (+)
6. ground connection

#### CAUTION

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

#### NAVIGATOR: PARAMETERS

##### Front throttle Potentiometer 1 (voltage)

**Example value:** 800 mV

The value in the example refers to engine conditions with key set to ON.

##### Front throttle Potentiometer 2 (voltage)

**Example value:** 3878 mV

The value in the example refers to engine conditions with key set to ON.

##### Rear throttle Potentiometer 1 (voltage)

**Example value:** 780 mV

The value in the example refers to engine conditions with key set to ON.

##### Rear throttle Potentiometer 2 (voltage)

**Example value:** 3756 mV

The value in the example refers to engine conditions with key set to ON.

##### Front throttle Potentiometer 1 - 2 (degrees) / Rear throttle Potentiometer 1 - 2 (degrees)

**Example value:** 6.5°

With key set to ON, the throttle is kept in position by the springs (approximately 5 - 7°). After the engine starts up at idle, the throttle is kept close to the mechanical minimum (above or equal to 0.5°). When the gear is not engaged, at approx. 6000 rpm, throttles open very little because the requested torque is too low (approximately 5 - 7°).

**Front / rear cylinder throttle correction****Example value:** 0.0°

For example, if there is a hole in the intake manifold, the pressure read is different from the pressure estimated by the control unit and the system tries to reach an "estimated" situation by opening the throttle a little bit more; therefore, this parameter takes a value different from zero: an acceptable value should be between -0.7° and +0.7°.

**Front cylinder Limp home position / Rear cylinder Limp home position****Example value:** 800 mV / 780 mV

Voltage stored in the control unit corresponding to the throttle Limp home position.

**Front throttle lower position / Rear throttle lower position****Example value:** 502 mV / 492 mV

Voltage stored in the control unit corresponding to the throttle mechanical minimum position.

**NAVIGATOR: STATUSES****Throttle Self-learning****Example value:** carried out/not carried out

Indicates whether or not the self-acquisition process has been carried out through the diagnosis instrument.

**NAVIGATOR: ACTIVATION**

-

**NAVIGATOR: ELECTRICAL ERRORS****Potentiometer 1 sensor, front throttle position P0120****Example value:** short circuit to positive / open circuit, short circuit to negativeError cause

- If shorted to positive: excessive voltage has been detected at PIN A6 of the throttle control unit. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN A6 of the throttle control unit.

Troubleshooting

- shorted to positive: check the value shown by the parameter of the front throttle Potentiometer 1 (voltage): disconnect the left connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle body if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle body connector and the throttle valve connector. If not OK, restore; if everything is OK, check circuit continuity between the two terminals. If not OK, restore the cable harness; if OK, check the circuit ground insulation (from throttle sensor connector or control unit connector). If it is ground insulated, check that there is power (+5 V) at the throttle body connector PIN 2, and that PIN 6 is connected to ground. If both are correct, replace the throttle body.

**Potentiometer 2 sensor, front throttle position P0122**

**Example value:** short circuit to positive / open circuit, short circuit to negative

Error cause

- If shorted to positive: excessive voltage has been detected at PIN A5 of the throttle control unit. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN A5 of the throttle control unit.

Troubleshooting

- shorted to positive: check the value shown by the parameter of the front throttle Potentiometer 2 (voltage): disconnect the left connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle body if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle body connector and the throttle valve connector. If not OK, restore; if everything is OK, check circuit continuity between the two terminals. If not OK, restore the cable harness; if OK, check the circuit ground insulation (from throttle sensor connector or control unit connector). If it is ground insulated, check that there is power (+5 V) at the throttle body connector PIN 2, and that PIN 6 is connected to ground. If both are correct, replace the throttle body.

**Potentiometer 1 sensor, rear throttle position P0125**

**Example value:** short circuit to positive / open circuit, short circuit to negative

Error cause

- If shorted to positive: excessive voltage has been detected at PIN B6 of the throttle control unit. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN B6 of the throttle control unit.

Troubleshooting

- shorted to positive: check the value shown by the parameter of the Rear throttle Potentiometer 1 (voltage): disconnect the left connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle body if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle body connector and the throttle valve connector. If not OK, restore; if everything is OK, check circuit continuity between the two terminals. If not OK, restore the cable harness; if OK, check the circuit ground insulation (from throttle sensor connector or control unit connector). If it is ground insulated, check that there is power (+5 V) at the throttle body connector PIN 2, and that PIN 6 is connected to ground. If both are correct, replace the throttle body.

**Potentiometer 2 sensor, rear throttle position P0127**

**Example value:** short circuit to positive / open circuit, short circuit to negative

Error cause

- If shorted to positive: excessive voltage has been detected at PIN B5 of the throttle control unit. If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN B5 of the throttle control unit.

#### Troubleshooting

- shorted to positive: check the value shown by the parameter of the Rear throttle Potentiometer 2 (voltage): disconnect the left connector and see the value displayed by Navigator: if the voltage does not vary, there is a short circuit in the cable wiring; replace the throttle body if the voltage drops to zero.
- if the circuit is open, shorted to negative: check the throttle body connector and the throttle valve connector. If not OK, restore; if everything is OK, check circuit continuity between the two terminals. If not OK, restore the cable harness; if OK, check the circuit ground insulation (from throttle sensor connector or control unit connector). If it is ground insulated, check that there is power (+5 V) at the throttle body connector PIN 2, and that PIN 6 is connected to ground. If both are correct, replace the throttle body.

#### **Front throttle supply voltage during self-acquisition P0164**

**Example value:** low supply voltage

#### Error cause

- The throttle power supply voltage is too low to carry out the self-acquisition test correctly (at each key ON). The instrument panel does not indicate the presence of this error even in the ATT status.

#### Troubleshooting

- The throttle test is not carried out when the key is set to ON because the test could show unreal errors (because the voltage is too low). Voltage is detected by the Marelli control unit.

#### **Front throttle control circuit P0166**

**Example value:** short circuit to positive / short circuit to negative / open circuit, overvoltage, excessive internal temperature.

#### Error cause

- If shorted to positive: excessive voltage has been detected at PIN C1 of the throttle control unit connector. If shorted to negative: no voltage has been detected. If the circuit is open: an interruption has been detected.

#### Troubleshooting

- shorted to positive: disconnect the throttle body connector, set key to ON and check voltage at PIN 3: if the voltage read is higher or equal to 5V, there is a short circuit on the cable harness; replace the throttle body if the voltage is null

- shorted to negative: disconnect the throttle body connector, set the key to ON and check if PIN 3 is in continuity with the vehicle ground connection: if it is, there is a short circuit in the cable ground connection; if it is not, replace the throttle body.
- open circuit, overcurrent, excessive inside temperature: check the throttle body connector and the throttle control unit connector. If not OK, restore. If everything is OK, disconnect the throttle body connector (PIN 3) and the throttle control unit connector (C1) and check the circuit continuity between the two terminals; if there is no continuity, restore the cable harness. If there is continuity, with the throttle body connector connected, check that the resistance, from the throttle control unit connector, between PIN A1 and C1 is within 1 and 2.5 Ohm; if it is not, replace the throttle body; if it is, check that the throttle body is not mechanically blocked: if blocked, solve the problem and replace the body; if it is not, replace the throttle control unit.

**Rear throttle supply voltage during self-acquisition P0184**

**Example value:** low supply voltage

Error cause

- The throttle power supply voltage is too low to carry out the self-acquisition test correctly (at each key ON). The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting

- The throttle test is not carried out when the key is set to ON because the test could show unreal errors (because the voltage is too low). Voltage is detected by the Marelli control unit.

**Rear throttle control circuit P0186**

**Example value:** short circuit to positive / short circuit to negative / open circuit, overcurrent, excessive internal temperature.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 8A of the throttle control unit connector. If shorted to negative: no voltage has been detected. If the circuit is open, there is overvoltage or excessive internal temperature: an interruption or excessive ampere input or control unit overheating has been detected.

Troubleshooting

- shorted to positive: disconnect the throttle body connector, set key to ON and check voltage at PIN 3: if the voltage read is higher or equal to 5V, there is a short circuit on the cable harness; replace the throttle body if the voltage is null.
- shorted to negative: disconnect the throttle body connector, set the key to ON and check if PIN 3 is in continuity with the vehicle ground connection: if it is, there is a short circuit in the cable ground connection; if it is not, replace the throttle body.

- open circuit, overcurrent, excessive inside temperature: check the throttle body connector and the throttle control unit connector. If not OK, restore. If everything is OK, disconnect the throttle body connector (PIN 3) and the throttle control unit connector (C8) and check the circuit continuity between the two terminals; if there is no continuity, restore the cable harness. If there is continuity, with the throttle body connector connected, check that the resistance, from the throttle control unit connector, between PIN A8 and C8 is within 1 and 2.5 Ohm; if it is not, replace the throttle body; if it is, check that the throttle body is not mechanically blocked: if blocked, solve the problem and replace the body; if it is not, replace the throttle control unit.

**NAVIGATOR: LOGIC ERRORS**

**Potentiometer 1 sensor, front throttle position P0121** - signal not valid.

Error cause

- Signal not within the expected value drawn according to the values of the intake pressure.

Troubleshooting

- Check the parameter of the Potentiometer 1 Front throttle (voltage) to get which signal the control unit receives and to compare it to the Potentiometer 1 Rear throttle (voltage). Check the throttle body connector as well as the throttle control unit connector. Check that cable resistance between the throttle body connector (PIN 1) and the throttle control unit (PIN 6A) is a few tenths of an Ohm. If this is not the case, restore the cable harness. If the value is correct, replace the complete throttle body.

**Potentiometer 2 sensor, front throttle position P0123** - signal not valid.

Error cause

- Signal not within the expected value drawn according to the values of the intake pressure.

Troubleshooting

- Check the parameter of the Potentiometer 1 Front throttle (voltage) to get which signal the control unit receives and to compare it to the Potentiometer 2 Rear throttle (voltage). Check the throttle body connector as well as the throttle valve control unit connector. Check that cable resistance between the throttle body connector (PIN 4) and the throttle control unit (PIN 5A) is a few tenths of an Ohm. If this is not the case, restore the cable harness. If the value is correct, replace the complete throttle body.

**Front throttle valve position sensors P0124** - illogical signal.

Error cause

- Potentiometer 1 and potentiometer 2 do not show a logical value: the sum of the two voltages should be constant. The cause may be a malfunction in one of the two sensors or an abnormal resistance in one of the two circuits.

Troubleshooting

- Check the throttle body connector as well as the throttle control unit connector. Check that cable resistance between the throttle body connector (PIN 1) and the throttle control unit (PIN 6A) is a few tenths of an Ohm. Check that cable resistance between the throttle body connector (PIN 4) and the throttle control unit (PIN 5A) is a few tenths of an Ohm. If one of the two is different, restore the cable harness. If correct, replace the complete throttle body.

**Potentiometer 1 sensor, rear throttle position P0126** - signal not valid.

Error cause

- Signal not within the expected value drawn according to the values of the intake pressure.

Troubleshooting

- Check the parameter of the Potentiometer 1 Rear throttle (voltage) to get which signal the control unit receives and to compare it to the Potentiometer 1 Front throttle (voltage). Check the throttle body connector as well as the throttle control unit connector. Check that cable resistance between the throttle body connector (PIN 1) and the throttle control unit (PIN 6B) is a few tenths of an Ohm. If this is not the case, restore the cable harness. If the value is correct, replace the complete throttle body.

**Potentiometer 2 sensor, rear throttle position P0128** - signal not valid.

Error cause

- Signal not within the expected value drawn according to the values of the intake pressure.

Troubleshooting

- Check the parameter of the Potentiometer 2 Rear throttle (voltage) to get which signal the control unit receives and to compare it to the Potentiometer 2 Front throttle (voltage). Check the throttle body connector as well as the throttle control unit connector. Check that cable resistance between the throttle body connector (PIN 4) and the throttle control unit (PIN 5B) is a few tenths of an Ohm. If this is not the case, restore the cable harness. If the value is correct, replace the complete throttle body.

**Rear throttle position sensors P0129** - illogical signal.

Error cause

- Potentiometer 1 and potentiometer 2 do not show a logical value: the sum of the two voltages should be constant. The cause may be a malfunction in one of the two sensors or an abnormal resistance in one of the two circuits.

Troubleshooting

- Check the throttle body connector as well as the throttle control unit connector. Check that cable resistance between the throttle body connector (PIN 1) and the throttle control unit (PIN 6B) is a few tenths of an Ohm. Check that cable resistance between the throttle body connector (PIN 4) and the throttle control unit (PIN 5B) is a few tenths of an Ohm. If one of the two is different, restore the cable harness. If correct, replace the complete throttle body.

**Front throttle Limp Home self-acquisition P0160** - test failed.

Error cause

- Throttle position, kept by the springs, not within the expected range (at each key ON). The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting

- Check if the throttle body and the intake duct are clean. If they are, replace the throttle body.

**Front throttle mechanical springs self-acquisition P0161** - test failed.Error cause

- Return time of the throttle, kept in position by the springs, not within the expected limits: the causes can be a deterioration of the performance of the springs or excessive throttle friction (at each key ON).

Troubleshooting

- Check if the throttle body and the intake duct are clean. If they are, replace the throttle body.

**Front throttle minimum mechanical position self-acquisition P0162** - test failed.Error cause

- Position of the throttle stop not within the expected range (at each key ON).

Troubleshooting

- Check if the throttle body and the intake duct are clean. If they are, replace the throttle body.

**Detection of front throttle valve Recovery conditions (air T<sup>0</sup>,water T<sup>0</sup>) P0163** - possible presence of ice.Error cause

- A correct throttle rotation cannot be detected given low ambient and engine temperatures: some ice may have formed in the duct (at each key ON). The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting

- Check that the throttle body is clean and that there is no ice or condensation in the intake duct. If they are, replace the throttle body.

**Front throttle first self-learning NOT performed P0165** - test not carried out.Error cause

- The first throttle self-acquisition process has not been successful or has not been carried out. The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting

- Delete errors hindering throttle self-learning.

**Front throttle position error P0167** - misalignment between control and activation.Error cause

- The throttle mechanical control may be damaged.

Troubleshooting.

- Replace the throttle body.

**Rear throttle Limp Home self-acquisition P0180** - test failed.Error cause

- Throttle position, kept by the springs, not within the expected range (at each key ON). The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting

- Check if the throttle body and the intake duct are clean. If they are, replace the throttle body.

**Rear throttle mechanical spring self-acquisition P0181** - test failed.Error cause

- Return time of the throttle, kept in position by the springs, not within the expected limits: the causes can be a deterioration of the performance of the springs or excessive throttle friction (at each key ON).

Troubleshooting.

- Check if the throttle body and the intake duct are clean. If they are, replace the throttle body.

**Rear throttle minimum mechanical position self-acquisition P0182** - test failed.Error cause

- Position of the throttle stop not within the expected range (at each key ON).

Troubleshooting.

- Check if the throttle body and the intake duct are clean. If they are, replace the throttle body.

**Detection of the rear throttle Recovery conditions (air T°, water T°) P0183** - possible presence of ice.Error cause

- A correct throttle rotation cannot be detected given low ambient and engine temperatures: some ice may have formed in the duct (at each key ON). The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting

- Check that the throttle body is clean and that there is no ice or condensation in the intake duct. If they are, replace the throttle body.

**Rear throttle first self-acquisition NOT performed P0185** - test not carried out.Error cause

- The first throttle self-acquisition process has not been successful or has not been carried out. The instrument panel does not indicate the presence of this error even in the ATT status.

Troubleshooting.

- Delete errors hindering throttle self-learning.

**Rear throttle position error P0187** - misalignment between control and activation.

Error cause

- The throttle mechanical control may be damaged.

Troubleshooting.

- Replace the throttle body.

**RESET PROCEDURE**

If the Marelli control unit or the throttle body is replaced, do not start the engine within the 3 seconds after the key is set to ON; during this time the control unit carries out the throttle self-learning process: then make sure that the throttle self-learning status reads: carried out. If the indication is "Not carried out", delete any possible errors present in the vehicle. Carry out Throttle self-learning process on the adjustable parameters screen page (screwdriver and hammer), and check again that the throttle self-learning status reads: carried out.

---

## Engine oil pressure sensor

### ENGINE OIL PRESSURE SENSOR

**Function:** it indicates to the instrument panel if there is enough oil pressure ( $0.5 \pm 0.2$  bar ( $7.25 \pm 2.9$  PSI)) in the engine.

**Operation / Operating principle:** normally closed switch. With oil pressure above  $0.5 \pm 0.2$  bar ( $7.25 \pm 2.9$  PSI), open circuit.

**Location on the vehicle:** right side of the vehicle, under the oil sump

**Pin-out:** Voltage 5V



**Instrument panel****Error DSB 07**Error cause

- An oil sensor fault is signalled when, with engine off, it is detected that the sensor circuit is open. The test is performed only once when the key is set to ON. There is an error when the general warning light turns on.

Troubleshooting

- Check the sensor connector and the instrument panel connector (PIN 17): if they are not OK, restore. If OK, check continuity of the purple cable between the sensor connector and the instrument panel connector PIN 17: if not OK, restore the cable harness; if OK, replace the sensor.

**Error DSB 08**Error cause

- An oil sensor fault is signalled when, with engine running, it is detected that the sensor circuit is closed. There is an error when the general warning light turns on.

Troubleshooting

- Check if oil pressure is low with the specific gauge.
-

## Neutral sensor

### GEAR IN NEUTRAL SENSOR

#### Function

it tells the gear position to the control unit: if it is in neutral or in gear.

#### Operation / Operating principle

for gear in neutral, the circuit is closed to ground connection: then, via CAN, the control unit sends the signal to the instrument panel which turns on the neutral speed warning light.

**Level in electrical circuit diagram:** Start-up enabling switches

#### Location:

- on the vehicle: left side of the vehicle, near flywheel cover
- connector: upper part of the flywheel cover

#### Electrical characteristics:

- gear in neutral: closed circuit (continuity)
- gear engaged: open circuit (infinite resistance)

#### Pin-out:

1. Voltage 12V

#### CAUTION

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**


#### NAVIGATOR: STATUSES

##### Gear in neutral

**Example value:** yes/no

#### NAVIGATOR: NOTES

- Indication on the instrument panel always gear engaged: check the correct position of the cable terminals on the connector and the correct connection of the cables on the terminals. If they are not correct, restore the cable harness; if correct, disconnect the connector and, with gear in neutral, check continuity to terminal ground connection, sensor side: if there is no continuity, replace the sensor (after checking cable continuity on the sensor side and the correct mechanical position). If there is, check the correct position of the terminal on the



control unit connector and the correct connection of the cables on the terminals. If they are not correct, restore the cable harness; if OK, check the cable continuity between the sensor connector and ENGINE connector PIN 16: if there is no continuity, restore the cable harness. If there is, replace the instrument panel if the vehicle performance is correct (the engine starts with gear in neutral but the neutral warning light is off) or replace the control unit if the vehicle performance is not correct (the engine does not start with gear in neutral).

- Indication on the instrument panel always gear in neutral: disconnect the terminals from the sensor and check if there is continuity between the ground connection and the PIN towards the sensor, with gear engaged: if there is continuity, replace the sensor. If it is insulated from the ground connection, it means that the green/black cable from sensor PIN 1 to ENGINE connector PIN 16 is shorted to ground: restore the cable harness

---

## Clutch lever sensor

### CLUTCH LEVER SENSOR

#### Function

It tells the clutch lever position to the control unit.

#### Operation / Operating principle

If there is gear engaged but the clutch is pulled, i.e. circuit closed to ground, vehicle start-up is not enabled.

**Level in electrical circuit diagram:** Start-up enabling switches.

#### Location:

- on the vehicle: under clutch lever
- connector: on the sensor

#### Electrical characteristics:


- Clutch pulled: closed circuit (continuity)
- Clutch released: open circuit (infinite resistance)

#### Pin-out:

1. Voltage 12V
2. Ground connection

**CAUTION**

BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.

**NAVIGATOR: STATUSES****Clutch**

**Example value:** Indefinite - released - pulled

The statuses regularly viewed are Released / Pulled

**Troubleshooting:**

- Indication on Navigator always released: check the correct position of the cable terminals on the connector and the correct connection of the cables on the terminals. If they are not correct, restore the cable harness; if correct, disconnect the two terminals from the sensor and, with key set to ON, check continuity to ground connection of PIN 2: if there is no continuity, restore the cable harness; if there is, replace the sensor
- Indication on Navigator always pulled: disconnect the terminals from the sensor and check if there is continuity between the two PINS, with clutch released: if there is continuity, replace the sensor. If the circuit is open, it means that the brown/purple cable from sensor PIN 1 to ENGINE connector PIN 50 is shorted to ground: restore the cable harness

**Side stand sensor****SIDE STAND SENSOR****Function**

It tells the side stand position to the control unit.


**Operation / Operating principle**

If the gear is engaged and the side stand is unfolded, and therefore the circuit is open, the control unit does not enable vehicle start-up or shuts off the engine if it is rotating.

**Level in electrical circuit diagram:** Start-up enabling switches

**Location:**

- on the vehicle: on the side stand



- connector: left side, near the Marelli control unit

**Electrical characteristics:**

- Side Stand Up: closed circuit (continuity)
- Side Stand Down: open circuit (infinite resistance)

**Pin-out:**

1. Ground connection
2. Voltage 12V

**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: STATUSES****Side stand**

**Example value:** up/down

Indication on Navigator **always down**: check the connector: if not OK, restore; if it is OK, disconnect the two terminals from the sensor and check continuity to ground of PIN 1: if there is no continuity, restore the cable harness; if there is, replace the sensor.

Indication on Navigator **always up**: disconnect the terminals from the sensor and check if there is continuity between the two PINS, with stand down: if there is continuity, replace the sensor; if the circuit is open, it means that the brown/green cable from sensor PIN 2 to ENGINE connector PIN 6 is short circuit to ground: restore the cable harness.

---

**Bank angle sensor****FALL SENSOR****Function**


it tells the vehicle position to the control unit.

**Operation / Operating principle**

When the sensor is inverted, the circuit is closed to ground: When the Marelli control unit detects this ground connection, it does not enable start-up or shuts off the engine.

**Level in electrical circuit diagram:** Start-up enabling switches.


**Location:**



- on the vehicle: under the saddle
- connector: near the sensor

**Electrical characteristics:**

- Sensor in vertical position: open circuit (resistance: 62 kOhm)
- Sensor inverted: closed circuit (continuity)

**Pin-out:**

1. Ground connection
2. Voltage 5V

**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: PARAMETERS****Fall sensor**

**Example value:** Normal / Tip over

Indication on Navigator always **Normal**, even when the sensor is inverted: disconnect the connector and, with sensor inverted, check if there is continuity between the two PINS of the sensor: if there is no continuity, replace the sensor; if there is, check the connector. If not OK, restore the cable harness; if OK, check continuity to ground of PIN 1: if there is no continuity, restore the cable harness; if there is, with key set to ON, check if there is 5V voltage at PIN 2. If there is not, check the Marelli control unit connector (ENGINE connector PIN 8).

Indication on Navigator always **Tip over**: disconnect the connector and check if there is continuity between the two PINS when the sensor is in vertical position: if there is continuity, replace the sensor; if there is not, it means that, with key set to ON, there is no 5V voltage at PIN 2: restore the cable harness whose pink/white cable will be shorted to ground

---

## Electric fan circuit

**ELECTRIC FAN CIRCUIT****Function**

Radiator fan and coolant - Operation.

**Operation / Operating principle**

When the control unit detects a temperature of approx. 102 °C, it closes the fan control relay pickup circuit to ground.

**Level in electrical circuit diagram:**electric fan

**Location:**

- the relay is located under the fuel tank, left side, first front relay (CHECK, however, the identification of the relay with the colour of the cables).

**Electrical characteristics:**

- relay normally open;
- drive coil resistance 110 Ohm (+/- 10 %)

**NAVIGATOR: STATUSES****Fan relay**

**Example value:** on/off

**NAVIGATOR: ACTIVATION****Fan:**

The fan relay (No. 44 in the wiring diagram, placed under fuel tank, left side, first front relay; CHECK, however, the identification of the relay with the colour of the cables) is energised for 10 seconds. The continuity of the wiring is necessary for correct activation: no error indications are displayed in case of lack of activation.

---

**NAVIGATOR: ELECTRICAL ERRORS**

**Cooling fan relay P0480** - shorted to positive / shorted to negative / open circuit.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 54 of the VEHICLE connector.
- If shorted to negative: short circuit to ground detected.
- If the circuit is open: interrupted circuit detected. Excessive voltage can only be detected after the fan relay gets activated.

Troubleshooting

- If shorted to positive: check the relay electrical specifications are correct by disconnecting it from the cable harness. If they are not correct, replace the relay; if correct, restore the cable harness (pink/blue cable).
- If shorted to negative: check the relay electrical specifications are correct by disconnecting it from the cable har-

ness. If they are not correct, replace the relay; if correct, restore the cable harness (pink/blue cable).

- If the circuit is open: check the relay connector and the Marelli control unit VEHICLE connector: If not OK, restore; if OK, restore the cable harness (red/blue cable).

## RUN/STOP switch

### OPTION 01

#### Run / stop switch

##### Function

It tells the control unit if the rider wishes to enable engine start-up or to keep the engine running.

##### Operation / Operating principle

If the driver wants to shut off the engine or to disable engine start-up, the switch should be open, i.e. the Marelli control unit should not detect voltage at VEHICLE connector PIN 26.

**Level in electrical circuit diagram:** start-up enabling switches.

##### Location:


- on the vehicle: right light switch
- connector: inside the rubber protection located between the water radiator and the fuel tank, to the right.

##### Electrical characteristics:

- STOP position: the circuit is open
- RUN position: closed circuit (continuity)

##### Pin-out:

1. Yellow/grey cable: -
2. Red/black cable: Voltage 12V



### CAUTION

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: PARAMETERS**

-

**NAVIGATOR: STATUSES****Run / stop switch****Example value:**Run/Stop

Indication on Navigator always STOP: disconnect the connector and, with the switch set to RUN, check if there is continuity toward the switch of the two yellow/grey and red/black cables: if there is no continuity, replace the sensor; if there is, check the connector. If not OK, restore the cable harness; if it is OK, with key set to ON, check if there is voltage to the red/black cable: if there is no voltage, restore the cable harness; if there is, check the yellow/grey cable ground insulation: if there is continuity to ground, restore the cable harness; if it is correct, take the key to OFF and check the VEHICLE connector is in good conditions and the continuity of the grey/yellow cable between the sensor in question and the VEHICLE connector PIN 26: if not OK, restore the cable harness; if OK, replace the Marelli control unit.

Indication on Navigator always RUN: disconnect the connector and, with the switch set to STOP, check if there is continuity between the two cables of the switch: if there is continuity, replace the switch; if there is not, it means that, with key set to ON, the yellow/grey cable is shorted to positive: restore the cable harness.

**OPTION 02****Function**

It tells the control unit if the rider wishes to enable engine start-up or to keep the engine running.

**Operation / Operating principle**


If the driver wants to shut off the engine or to disable engine start-up, the switch should be open, i.e. VEHICLE connector PIN 26 of the Marelli control unit must not be connected to ground.

**Level in electrical circuit diagram:**

Start-up enabling switches

**Location:**

- on the vehicle: right light switch.
- connector: inside the rubber protection located between the water radiator and the fuel tank, to the right.

**Electrical characteristics:**

- STOP position: the circuit is open

- RUN position: closed circuit (continuity)

**Pin out:**

1 blue/green cable: ground connection

2

3 Red/black cable: 5 V (supply)

4 Yellow/grey cable: Run/Stop

**CAUTION**

**BEFORE CARRYING OUT ANY TROUBLESHOOTING, CAREFULLY READ THE GENERAL TROUBLESHOOTING CONCEPTS FOR ELECTRICAL DEVICES AT THE BEGINNING OF THE CHECK AND CONTROL SECTION IN THE ELECTRICAL SYSTEM CHAPTER.**

**NAVIGATOR: STATUSES**

RUN / STOP switch

- Run/Stop

**NOTES**

- Indication on Navigator always STOP: disconnect the connector and, with the switch set to RUN, check if there is continuity towards the two cables switch - Blue/Green and Yellow/Red: If there is not continuity, replace the sensor; if there is continuity, check the connector: if not OK, restore the cable harness; if OK, check, with key set to ON, if there is voltage on Yellow/Red cable: if there is no voltage, restore the cable harness; if there is, check the Yellow/Red cable ground insulation: If there is continuity with ground connection, restore the cable harness; if OK, set the key to OFF and check the VEHICLE connector and the engine-vehicle cable harness connector: if not OK, restore; if OK, check continuity of the Yellow/Red cable between switch connector and PIN C7 of the engine-vehicle cable harness connector and between the PIN C7 and the VEHICLE connector PIN 78: if not OK, restore the cable harness; if OK, replace the Marelli control unit.
- Indication on Navigator always RUN: disconnect the connector and, with the switch set to STOP, check if there is continuity between the two cables of the switch: if there is continuity, replace the switch; if there is not continuity, it means that, with key set to ON, the Yellow/Red cable (between switch and the PIN C7 of the engine-vehicle cable harness connector or from the latter to the PIN 78 of the control unit connector) is shorted to positive: restore the cable harness.

---

**Throttle control unit****THROTTLE CONTROL UNIT****Function**

It receives the throttles target position from the Marelli control unit and it moves them so that they reach that target by reading their position through the potentiometers (2 per throttle body).

**Level in wiring diagram:** throttle control unit

**Location:**

- on the vehicle: inside the filter casing
- connector: on the control unit


**Pin-out:** see the CONNECTORS section

**See also**

[Throttle control unit](#)

## Connectors

## ECU




### MARELLI CONTROL UNIT PIN OUT

Specification		Desc./Quantity
1	Key switch	Vehicle connector: 12/29
2	Revolution sensor input (+)	Engine connector: 9
3	Revolution sensor input (-)	Engine connector: 23
4	Vehicle speed input	Vehicle connector: 49
5	Throttle grip input - Track A	Vehicle connector: 42
6	Throttle grip input - Track B	Vehicle connector: 40
7	Throttle grip input - Track C	Engine connector: 30
8	Throttle grip input - Track D	Engine connector: 44
9	Front cylinder intake pressure sensor input	Vehicle connector: 34
10	Rear cylinder intake pressure sensor input	Vehicle connector: 5
11	Water temperature sensor input	Engine connector: 45
12	Side stand input	Vehicle connector: 6
13	"start engine" input	Vehicle connector: 14
14	Clutch sensor input	Vehicle connector: 50


	Specification	Desc./Quantity
15	Fall sensor input	Engine connector: 8
16	Gear/neutral input	Engine connector: 16
17	Start-up control output	Engine connector: 2
18	Serial line K for diagnosis	Vehicle connector: 10
19	Auxiliary injection relay control output	Vehicle connector: 62
20	Front coil control output	Engine connector: 17
21	Rear coil control output	Engine connector: 19
22	Front injector control output	Engine connector: 50
23	Rear injector control output	Engine connector: 34
24	Air temperature sensor input	Engine connector: 63
25	Front throttle reset output	Vehicle connector: 56
26	Rear throttle reset output	Vehicle connector: 55
27	"Engine stop" input	Vehicle connector: 26
28	Electric fan relay control output	Vehicle connector: 54
29	STOP light relay control output	Vehicle connector: 59
30	Lambda heater control output	Engine connector: 32
31	Lambda sensor input (+)	Engine connector: 43
32	Lambda sensor input (-)	Engine connector: 60
33	Purge Canister valve control output (optional)	Engine connector: 51
34	Control unit direct power supply	Vehicle connector: 16
35	Power ground connection 1	Engine connector: 21
36	Power ground connection 2	Engine connector: 5
37	Power ground connection 3	Engine connector: 22
38	Power ground connection 4	Engine connector: 6
39	Reference voltage output +5V: tracks A-C and pressure sensor	Engine connector: 15
40	Reference voltage output +5V: tracks B-D and speed sensor	Engine connector: 13
41	Analogue ground connection 1	Engine connector: 35
42	Analogue ground connection 2	Vehicle connector: 46 Engine connector: 36
43	CAN H Line (high speed)	Vehicle connector: 51
44	CAN L Line (high speed)	Vehicle connector: 20
45	Timing sensor	Engine connector: 24

**NOTE**


THE CONNECTOR CAN BE VIEWED FROM THE CABLE HARNESS SIDE, THAT IS LOOKING AT THE CABLES WHEN GOING OUT OF THE "MAIN" CABLE HARNESS AND INTO THE CONNECTOR.




ECU "E" (Bi)

**NOTE**

THE CONNECTOR CAN BE VIEWED FROM THE CABLE HARNESS SIDE, THAT IS LOOKING AT THE CABLES WHEN GOING OUT OF THE "MAIN" CABLE HARNESS AND INTO THE CONNECTOR.



ECU "V" (G)



## Throttle control unit




### EFI THROTTLE CONTROL UNIT PIN OUT

Specification	Desc./Quantity
1 1A - Front throttle motor control (-)	Front throttle body PIN: 5
2 2A - CAN L	
3 3A - Voltage for front throttle potentiometers (+ 5 V)	Front throttle body PIN: 2
4 4A - Key input	
5 5A - Input for front throttle potentiometer 2 signal	Front throttle body PIN: 4
6 6A - Input for front throttle potentiometer 1 signal	Front throttle body PIN: 1
7 7A - Front throttle reset signal input	
8 8A - Rear throttle motor control (+)	Rear throttle body PIN: 3
9 1B - Battery power supply input	
10 2B - CAN H	
11 3B - Voltage for rear throttle potentiometers (+ 5 V)	Rear throttle body PIN: 2
12 4B - Firmware reprogramming power supply	
13 5B - Input for rear throttle potentiometer 2 signal	Rear throttle body PIN: 4
14 6B - Input for rear throttle potentiometer 1 signal	Rear throttle body PIN: 1

Specification		Desc./Quantity
15	7B - Rear throttle reset signal input	
16	8B - Battery power supply input	
17	1C - Front throttle motor control (+)	Front throttle body PIN: 3
18	2C - Ground connection	
19	3C - Ground connection	Front throttle body PIN: 6
20	4C - Ground connection	Rear throttle body PIN: 6
21	5C - Ground connection	
22	6C - Ground connection	
23	7C - Ground connection	
24	8C - Rear throttle motor control (-)	Rear throttle body PIN: 5

NOTE


THE CONNECTOR CAN BE VIEWED FROM THE CABLE HARNESS SIDE, THAT IS LOOKING AT THE CABLES WHEN GOING OUT OF THE "MAIN" CABLE HARNESS AND INTO THE CONNECTOR.



Dashboard

NOTE

THE CONNECTOR CAN BE VIEWED FROM THE CABLE HARNESS SIDE, THAT IS LOOKING AT THE CABLES WHEN GOING OUT OF THE "MAIN" CABLE HARNESS AND INTO THE CONNECTOR.



INSTRUMENT PANEL PIN

Specification		Desc./Quantity
1	GREY BODY: + Live	PIN 1
2	GREY BODY: Right indicator control	PIN 2
3	GREY BODY: *	PIN 3
4	GREY BODY: High-beam lights input	PIN 4
5	GREY BODY: *	PIN 5
6	GREY BODY: Select 3 (Set)	PIN 6
7	GREY BODY: Select 2 (Down)	PIN 7
8	GREY BODY: Select 1 (Up)	PIN 8
9	GREY BODY: Fuel reserve sensor	PIN 9
10	GREY BODY: *	PIN 10
11	GREY BODY: + Battery	PIN 11
12	GREY BODY: Left indicator control	PIN 12
13	GREY BODY: Hazard control	PIN 13
14	GREY BODY: *	PIN 14
15	GREY BODY: *	PIN 15

	Specification	Desc./Quantity
16	GREY BODY: Indicator reset	PIN 16
17	GREY BODY: Oil sensor input	PIN 17
18	GREY BODY: 750/1200 Selection	PIN 18
19	GREY BODY: *	PIN 19
20	GREY BODY: K Line	PIN 20
21	BLACK BODY: + Battery	PIN 21
22	BLACK BODY: Front left turn indicator activation	PIN 22
23	BLACK BODY: Front right turn indicator activation	PIN 23
24	BLACK BODY: Aerial 2	PIN 24
25	BLACK BODY: *	PIN 25
26	BLACK BODY: CAN H	PIN 26
27	BLACK BODY: CAN L	PIN 27
28	BLACK BODY: ABS warning light input	PIN 28
29	BLACK BODY: *	PIN 29
30	BLACK BODY: Ground for sensors	PIN 30
31	BLACK BODY: + Battery	PIN 31
32	BLACK BODY: Rear left turn indicator activation	PIN 32
33	BLACK BODY: Rear right turn indicator activation	PIN 33
34	BLACK BODY: Aerial 1	PIN 34
35	BLACK BODY: Light relay activation	PIN 35
36	BLACK BODY: *	PIN 36
37	BLACK BODY: *	PIN 37
38	BLACK BODY: General ground	PIN 38
39	BLACK BODY: General ground	PIN 39
40	BLACK BODY: General ground	PIN 40


## ABS Modulator

### INSERTION PROCEDURE OF ABS CONTROL UNIT CONNECTOR

- Check the initial position of the lever that couples the connector.





- When the connector is fully inserted, the distance between the connector and the ABS control unit must be 7.5 mm (0.29 in).




- If the initial position of the connector and the driving lever is not that shown in fig. 1, the connector will not be properly coupled and the distance measured will be greater (12 mm approx. (0.47 in)). In this case repeat the operation as described in the two previous points.

**IT IS ADVISABLE TO CREATE A TEMPLATE TO CHECK THE CORRECT CONNECTOR INSERTION.**




- Insert the housing as shown in the figure.




#### INSERTION PROCEDURE OF ABS CONTROL UNIT CONNECTOR


- Check the initial position of the lever that couples the connector.




- When the connector is fully inserted, the distance between the connector and the ABS control unit must be 7.5 mm (0.29 in).




- If the initial position of the connector and the driving lever is not that shown in fig. 1, the connector will not be properly coupled and the distance measured will be greater (12 mm approx. (0.47 in)). In this case repeat the operation as described in the two previous points.



**IT IS ADVISABLE TO CREATE A TEMPLATE TO CHECK THE CORRECT CONNECTOR INSERTION.**



- Insert the housing as shown in the figure.



## Can line

### CAN line

#### Function

It allows communication between the Marelli injection control unit, the throttle control unit and the instrument panel.

**Level in electrical circuit diagram:**CAN line

**Pin-out:** see wiring diagram

### **NAVIGATOR: ELECTRICAL ERRORS**

**U1602 CAN line without signals - Bus Off.**

#### Error cause

- No communication on CAN line (PIN 20 and/or PIN 51 VEHICLE): problem on the whole network (for example, battery cut-off or short circuited or shorted to ground).

#### Troubleshooting

- Check the Marelli control unit VEHICLE connector: if not OK, restore; if OK, check the ground insulation of the two CAN lines from PIN 20 and PIN 51 of the VEHICLE connector: If not OK, restore the cable harness; if OK, check continuity of the two CAN lines from the Marelli control unit VEHICLE connector to the filter box large connector and to the instrument panel connector: if not OK, restore the cable harness; if OK, check that the two lines are not shorted to positive testing each of the 3 connectors (Marelli control unit connector, filter box large connector and instrument panel connector) with 1 connector disconnected at a time and by setting the key to ON: If not OK, restore; if OK, replace the Marelli control unit.

**Mute Node CAN Line, U1601 - Mute Node**

#### Error cause

- The injection ECU cannot send CAN signals; it receives signals from the instrument panel and the throttle control unit: the control unit may need replacing.

#### Troubleshooting

- Replace the Marelli control unit.

**CAN line to instrument panel, U1701 - no signal**

#### Error cause

- No signal is received from the instrument panel.

#### Troubleshooting

- Check the connector of the instrument panel: if not OK, restore; if OK, check the continuity of the two lines from the instrument panel connector to the VEHICLE connector of the Marelli control unit: if not OK, restore the cable harness; if OK, replace the instrument panel.

**CAN line to the throttle control unit, U1705 - no signal**

#### Error cause

- No signal is received by the throttle control unit.

#### Troubleshooting

- Check the filter box large connector and the throttle control unit connector: if not OK, restore; if OK, check the continuity of the two lines from the filter box large connector to the VEHICLE connector of the Marelli control unit: if not OK, restore the cable harness; if OK, check the

continuity of the two lines from the filter box large connector to the throttle control unit connector: if not OK, restore the cable harness; if OK, replace the throttle control unit.

**NAVIGATOR: LOGIC ERRORS**

**CAN Line to throttle control unit, U1706** - no message update.


Error cause

- No updated signal is received from the throttle control unit.
-


## INDEX OF TOPICS

ENGINE FROM VEHICLE

ENG VE


**FRONT CHASSIS**

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening shock absorber counterplate to RH frame bracket	M10x30	1	50 Nm (36.88 lbf ft)	-
2	TC TORX screw fastening trellis frame to frame side panels	M12x53	4	80 Nm (59 lbf ft)	-
3	Screw fastening chain roller bracket to LH plate	M8x35	1	25 Nm (18.44 lbf ft)	Loctite 243
4	Screw fastening chain roller to chain roller bracket	M8x45	1	25 Nm (18.44 lbf ft)	Loctite 243
5	Screw fastening chain roller bracket to LH plate	M8x20	1	25 Nm (18.44 lbf ft)	Loctite 243



**CENTRE FRAME**

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screws fastening side panels to engine	M12x282	3	80 Nm (59 lbf ft)	-
2	TCEI screw fastening lambda probe plate to RH frame (pre-fit on RH side panel)	M4x10	2	3 Nm (2.3 lbf ft)	-
3	SWP self-tapping screw fastening demand sensor mounting to demand sensor	M5x14	4	2.6 Nm (1.92 lbf ft)	-
4	Flanged TE screw fastening demand sensor to frame	M6x20	3	10 Nm (7.37 lbf ft)	-



### ENGINE

pos.	Description	Type	Quantity	Torque	Notes
1	Flanged TE screw fastening pinion	M10x1.25x25	1	50 Nm (36.88 lbf ft)	Loctite 270
2	TCEI screw fastening Pin to gearbox lever and Gearbox Lever to knurled shaft	M6x16	2	10 Nm (7.37 lbf ft)	-
3	LH lock nut for ball joint	M6	1	10 Nm (7.37 lbf ft)	-
4	RH lock nut for ball joint	M6	1	10 Nm (7.37 lbf ft)	-
5	Screw fastening engine bracket / clutch side crankcase half	M6	2	12 Nm (8.85 lbf ft)	-
6	Map sensor union (brass)	-	2	2 Nm (1.48 lbf ft)	Loctite 243
6	Map sensor union (steel)	-	2	3.50 Nm (2.58 lbf ft)	Loctite 243
7	LH ball joint on gearbox control lever	-	1	10 Nm (7.37 lbf ft)	Loctite 243
8	RH ball joint on gearbox control lever	-	1	10 Nm (7.37 lbf ft)	Loctite 243
-	Fastener for positive cable on engine	-	1	10 Nm (7.37 lbf ft)	-
-	TE screw fastening negative cable to engine	M6x12	1	10 Nm (7.37 lbf ft)	-

### Vehicle preparation

- Remove the air filter case.
- Remove the coolant radiator.
- Remove the exhaust system.
- Place the optional under-sump and rear wheel service stands.
- Remove the modulator.
- Undo and remove the screw and move the coil.



- Disconnect the engine temperature sensor connector.



- Disconnect the engine oil pressure sensor connector.



- Disconnect the starter motor power supply cable.



- Unscrew and remove the screw and collect the washer.
- Disconnect the ground leads.



- Move the breather pipe.




- Disconnect the speed sensor connector.



- Unscrew and remove the three screws.
- Remove the clutch control cylinder.
- Lock the plunger using a clamp.




- Unscrew and remove the two screws.
- Remove the chain guard.



- Unscrew and remove the three screws fixing the chain guide.
- Remove the clutch pin.

**CAUTION**

UPON REFITTING, PROPERLY GREASE THE O-RING INDICATED WITH THE ARROW AND BE CAREFUL NOT TO PINCH IT.




- Disconnect the gear in neutral sensor connector.



- Disconnect the side stand sensor connector.



- Loosen the screw and slide off the gear transmission connecting rod keeping it linked to the gear shift lever through the rod.



- Slacken the gearing chain tension.
- Unscrew and remove the screw; collect the washer and the spacer.
- Slide off the pinion from the chain and remove.



- Disconnect the generator connections.

**See also**

[Air box](#)  
[Removing the radiator](#)


---

## Removing the engine from the vehicle

- Carry out the operations described under Vehicle preparation.
- Support the engine by means of belt and hoist.
- Working on the left side, unscrew and remove the two upper nuts.




- Working on the right side, slightly slide off the two upper bolts.
- Collect the spacers on the opposite side.
- Check spacers length so as not to interchange them upon refitting
- Remove the two upper bolts and collect the washers.



- Working on the left side, unscrew and remove the lower bolt.



- Working on the right side, slightly slide off the lower bolt.
- Collect the spacer on the opposite side.
- Remove the lower pin and collect the washer.



- Lower the engine.

### See also

[Vehicle preparation](#)

## Installing the engine to the vehicle



- Place the engine on a suitable lower stand.
- Lift the engine.
- Place the engine so that the rear attachments on the chassis are aligned.

- Working on the right side, insert the three bolts with their washers.
- Working on the right side, place the spacers on the three bolts between the engine block and the chassis.



### CAUTION

THE SPACERS HAVE DIFFERENT SIZES. REFIT THEM IN THE SAME WAY THEY WERE BEFORE BEING REMOVED.



- Working from the left side, tighten the three nuts.
- Release the engine from the belt and the hoist.
- Refit the pinion and restore the gearing chain clearance.
- Reconnect the electric connections and clamp the cable harnesses.
- Carry out the vehicle preparation operations but in reverse order, restore the correct level of all fluids and carry out the adjustments that may be required.





**See also**

[Vehicle preparation](#)

[Adjusting](#)

---


INDEX OF TOPICS

ENGINE

ENG

## Gearbox

### Diagram




### Key

1. Complete gear shaft and spring
2. Selector lock
3. Selector sprocket wheel
4. M5x16 Screw
5. Sprocket wheel pawl
6. Spring
7. Pin for spring
8. Complete transmission gear shaft
9. Forks
10. Fork shaft
11. Gear selector
12. Fork shaft
13. Fork
14. Gear selector drum
15. M8x1.25 threaded pin
16. Selector locking plate

- 17.Complete main gear shaft
- 18.TE flanged screw, M6x15
- 19.Complete index lever
- 20.Spring
- 21.Nut
- 22.Threaded pin

## Gearbox shafts

### Gearbox shafts diagram



#### key:

- 1. Main gear shaft Z=14
- 2. 2nd gear on primary Z=17
- 3. 3rd - 4th gear on secondary Z=20/22
- 4. 5th gear on primary Z=23
- 5. 6th gear on primary Z=24
- 6. Thrust washer
- 7. Circlip
- 8. Thrust washer
- 9. Thrust washer
- 10.Circlip

- 11. Transmission shaft
- 12. 1st gear on primary Z=36
- 13. 2nd gear on secondary Z=32
- 14. 3rd gear on secondary Z=30
- 15. 4th gear on secondary Z=28
- 16. 5th gear on secondary Z=26
- 17. 6th gear on secondary Z=25
- 18. Thrust washer
- 19. Circlip
- 20. Thrust washer
- 21. Thrust washer
- 22. Thrust washer
- 23. Floating bushing
- 24. Floating bushing
- 25. Floating bushing

---

## Disassembling the gearbox

- Remove the gear selector as described in the Crankcase Opening section.
- Remove the two bolts of the forks.



- Slide off the desmodromic drum control.



- Remove the three gear selection forks.

**CAUTION**

THE MAIN SHAFT FORK IS SMALLER THAN THOSE OF THE SECONDARY SHAFT.  
ALL THE SECONDARY SHAFT FORKS ARE THE SAME SIZE.



- Carefully rotate the engine support.



- Carefully slide off the whole gear unit.



### Refitting


- Repeat the removal operations but in reverse order, make sure that the shim washer is fitted to the secondary shaft.



### See also

[Splitting the crankcase halves](#)

## Gear selector



**GEAR SELECTOR**

pos.	Description	Type	Quantity	Torque	Notes
1	Gear retainer pawl fastener screw	M6	1	12 Nm (8.85 lbf ft)	-
2	Selector plate fastener screw	M5	3	5.50 Nm (4.06 lbf ft)	-
3	Screw fastening Desmodromic selector drum / Selector sprocket	M8	1	23 Nm (16.96 lbf ft)	-
4	Gear sensor fastener screw	M5	2	5.50 Nm (4.06 lbf ft)	Loctite 243
5	Selector pin fastener onto clutch side crankcase half	M10x1.5	1	16 Nm (11.80 lbf ft)	-
6	Tightening tone wheel on secondary gearbox	M16x1	1	43 Nm (31.72 lbf ft)	Loctite 270


**Removing the gear selector**

To remove the gear selector refer to the operations described under Crankcase opening.

**Checking the gear selector****Selector spring**

Make sure that the spring ends on the two shifting positions (forward = downshifting and backward = up-shifting) are always in contact with the selector plate


Make sure that the clearance between the end of the spring on the selector plate and the stop pin is almost null, when in home position (see diagrams)

**Pawl**

Make sure that both pawl tips run free, without jamming

**Selector plate spring**

With a thickness gauge, check that the spring is not deformed by over-stretching.



---

## Gearbox Selector Shaft

---

### Removal

- Place the left hand crankcase in a press and extract the roller cage with the specific tool.

### NOTE

REPEAT THE SAME OPERATION FOR THE RIGHT HAND CRANKCASE HALF.

### Specific tooling

020724Y Gear control rod roller cage punch



### INSTALLATION

- Place the left hand crankcase in a press and install the roller cage with the specific tool.

### CAUTION

TO INSTALL THE ROLLER CAGE IN THE RIGHT HAND CRANKCASE HALF, WORK WITH THE CYLINDER ON THE SIDE OF THE 1 mm (\*) STEP ON THE TOOL TURNED TOWARD THE ROLLER CAGE, WHEREAS TO INSTALL THE CAGE IN THE LEFT HAND CRANKCASE HALF, USE THE CYLINDER ON THE SIDE OF THE 2 mm (\*\*) STEP ON THE TOOL.

### Specific tooling

020724Y Gear control rod roller cage punch



---

## Starter motor


---

## Removing the starter motor

- Disconnect the starter motor power supply cable.




- Undo and remove the four screws and remove the starter motor.



---

## Generator side



**IGNITION**

pos.	Description	Type	Quantity	Torque	Notes
1	Spark plug	-	2	13 Nm (9.59 lbf ft)	-
2	Freewheel Ring fastener screw	M6	6	14 Nm (10.33 lbf ft)	Loctite 242
3	Screw fixing rotor - Crankshaft - (12 mm - 0.47 in)	M12x1.25	1	130 Nm (95.88 lb ft)	-
3	Screw fixing rotor - Crankshaft - (14 mm - 0.55 in)	M12x1.25	1	190-200 Nm (140.14-147.51 lb ft)	-
4	Screw fastening Stator / Flywheel Cover	M6	3	9 Nm (6.64 lb ft)	-
5	Screw fastening pick-up / Flywheel cover	M5	2	3.50 Nm (2.58 lbf ft)	-
6	Flywheel cover fastener screw	M6	10	13 Nm (9.59 lb ft)	-
7	Screw fastening starter motor bracket to crankcase	M6	2	13 Nm (9.59 lbf ft)	-
8	Crankshaft access cap	-	1	4 Nm (2.95 lb ft)	-
9	Retainer plate fastener screw	M6	1	8 Nm (5.90 lbf ft)	-
-	Screw fastening bracket to starter motor	M6x14	2	13 Nm (9.59 lbf ft)	-
-	Pick-up cable retainer screw	M5	2	3 Nm (2.21 lbf ft)	-

**Removing the flywheel cover**

- Remove the flywheel cover inspection cap.



- Unscrew and remove the ten screws (1 - 2).

**NOTE**

SCREW (2) ON THE FLYWHEEL COVER IS SHORTER THAN SCREWS (1).




- Remove the flywheel cover using the specific tool.

**Specific tooling**

020712Y Handle for Flywheel cover removal

**Removing the flywheel cover components**

- Remove the two pick-up fixing screws.



- Remove the three stator fixing screws.

**CAUTION**

THE PICK-UP AND STATOR SHALL BE REMOVED SIMULTANEOUSLY AS THEY ARE PART OF THE SAME ELECTRICAL BRANCH.

**Magneto flywheel removal**

- Remove the flywheel cover.
- Unscrew and remove the screw and remove the retention plate.



- Heat the magneto flywheel with the specific heater.
- Lock the flywheel using the specific tool and loosen the screw.

**Specific tooling****020713Y Flywheel extractor**

- Screw the anticlockwise bolt of the special tool on the external body.
- Keeping the external body blocked and gripping the key, screw the anticlockwise bolt so as to remove the flywheel from the crankshaft.

**Specific tooling****020713Y Flywheel extractor**

- Unscrew and remove the anticlockwise bolt of the special tool from the external body.
- Unscrew the screw from the crankshaft.

**Specific tooling****020713Y Flywheel extractor**

- Remove the flywheel together with the freewheel.



- Remove the start-up transmission gear.
- In case of malfunction, the start-up transmission gear cannot be overhauled. Therefore, the complete transmission gear should be replaced.



- Collect the crankshaft woodruff key.



---

## Freewheel removal

- Heat the magneto flywheel with the specific heater.
- Undo and remove the six screws.
- Remove the freewheel from the magneto flywheel.



---

## Installing the flywheel


- Insert the woodruff key on the crankshaft.
- Insert the start-up transmission gear after applying a layer of grease.



- Insert the flywheel on the crankshaft.
- Screw the screw together with the washer but without tightening.



- Place the appropriate tool for locking the flywheel.
- Locking the flywheel in position, using the specific tool, tighten the screw on the crankshaft.

**CAUTION:**

**TO APPLY THE CORRECT TIGHTENING TORQUE, CHECK THE MEASURE OF THE SCREW THAT CAN BE M12 OR M14.**

- Remove the special tool.


**Specific tooling****020713Y Flywheel extractor**

- Place the retention plate.
- Tighten the screw.



---


**Clutch side****OPTION 01**



**WATER PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch side cover fastener screw	M6	13	13 Nm (9.59 lbf ft)	-
2	Fastener screw for Pump Cover / Clutch side cover	M6	3	13 Nm (9.59 lbf ft)	-
3	Screw fastening Pump Cover / Clutch Cover / clutch side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-
4	Nut fastening pump drive input gear on shaft	M6	1	12 Nm (8.85 lbf ft)	Loctite 244
5	Water pump rotor	-	1	4.50 Nm (3.32 lbf ft)	-

**OPTION 02**




### WATER PUMP

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch side cover fastener screw	M6	11	13 Nm (9.59 lbf ft)	-
2	Fastener screw for Pump Cover / Clutch side cover	M6	3	13 Nm (9.59 lbf ft)	-
3	Screw fastening Pump Cover / Clutch Cover / clutch side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-
4	Nut fastening water pump drive gear sprocket	M6	1	12 Nm (8.85 lbf ft)	-
5	Water pump rotor	-	1	4.50 Nm (3.32 lbf ft)	-
6	Screw fastening chain tensioner slider to water pump	M6	1	8-10 Nm (5.90-7.38 lbf ft)	-
7	Water pump support fixing screw	M6	3	12 Nm (8.85 lbf ft)	-
8	Water pump support plug	M6x10	1	6.5 Nm (4.79 lbf ft)	3M SCOTCH GRIP 2353

- Remove the water pump cover.
- Undo and remove the eleven screws working in a diagonal sequence.
- Collect the gasket.




Removing the clutch cover



CLUTCH COVER


pos.	Description	Type	Quantity	Torque	Notes
1	Fastener screw for Clutch Cover / Clutch side cover	M6	6	13 Nm (9.59 lbf ft)	-
2	Clutch fastener nut	M24x1.5	1	180 Nm (132.76 lbf ft) ± 5%	Chamfer
3	Fastening oil filler plug on Clutch cover	-	1	2 Nm (1.48 lbf ft)	-
4	Screw fastening fixing Plate / Clutch control Mounting	M5	3	5.50 Nm (4.06 lbf ft)	-
5	Screw fastening clutch control mounting on flywheel side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-

- Undo and remove the perimeter fastener screws.
- Remove the clutch cover.




Removing the clutch cover alone is only recommended when replacing the clutch plates. When removing the entire clutch assembly, removing the clutch side crankcase is recommended. However, removing the entire clutch assembly is possible by removing the clutch cover alone. In this case, proceed as follows:

- measure the projection of the clutch housing from the crankcase before disassembling;
- when refitting, check that the projection has not changed before tightening the clutch nut. If the projection has changed, rotate the crankshaft to correctly engage the engine oil pump drive gear on the clutch housing with the oil pump driven gear.



Disassembling the clutch



CLUTCH					
pos.	Description	Type	Quantity	Torque	Notes
1	Clutch spring fastener screw	M6	6	12 Nm (8.85 lbf ft)	-

- Remove the clutch side housing.
- Unscrew and remove the six screws by loosening them 1/4 of a turn at a time; operate in stages and diagonally, and retrieve the washers and the clutch springs.



- Remove the thrust plate.



- Remove the mushroom head clutch control rod.



- Remove the discs.
- Remove the shim and the cup spring.



- Fasten the clutch housing using the specific tool.

**Specific tooling****9100896 Clutch housing locking tool**

- Undo and remove the clutch hub nut, retrieving the washer.



- Remove the clutch hub.



- Retrieve the special washer between the clutch hub and the clutch housing.
- Collect the clutch housing.



- Collect the spacer and the needle bearings.



- Collect the shim washer.



## Checking the clutch plates

- Lay the friction discs and steel discs on a level surface and check them for cracks and potential distortions.

**Maximum distortion allowed: 0.20 mm (0.0079 in)**



- Measure the driving plate thickness at four positions, replace them all if not complying with specifications.

### CAUTION

THE STEEL DISCS MUST SHOW NO SCORES OR TEMPERING COLOUR.

- Measure the thickness of the clutch discs at four positions, replace them if not complying with specifications.


**Thickness of nine drive discs: 2.5 mm (0.10 in).**  
**Driven disc thickness: 2,75 - 2,85 mm (0.108 ÷ 0.112 in).**



---

**MUSHROOM VALVE CHECK**

- Check if the valve slides freely, without jamming.
- Blow compressed air into the valve and check that the lubricating oil passage holes open.



---

**Checking the clutch housing**

- Remove the clutch bell.
- Remove the seeger ring.



- Remove the oil pump control gear.



**UPON REFITTING, THE GEAR COLLAR MUST ALWAYS BE FACING THE CLUTCH BELL.**



- Remove the rotation locking pin from the oil pump control gear.



Check the clutch bell for damage and wear that may result in clutch irregular operation. Deburr the teeth or replace the bell.

**MAIN DRIVEN GEAR CHECK**


Check the main driven gear for damage and wear and, if necessary, replace the main transmission driving gear and the clutch bell all together.

Make sure there is not excessive noise during operation; if necessary, replace the main transmission driving gear and the clutch bell all together.

---

## Checking the pusher plate


Check the thrust plate and the bearing for damage and wear. If necessary, replace the parts.



---

## Checking the clutch hub

Check the clutch hub for damage and wear that may result in clutch irregular operation. If necessary, replace the bell.




---

## Checking the springs

- Check the springs for damage and, if necessary, replace the them all together.
- Measure the clutch spring length when unloaded; if necessary, replace the springs all together.

**Clutch spring length when unloaded: 46.6 mm  
(1.83 in)**



## Assembling the clutch

- Fit the shim washer.



- Fit the needle bearing and the spacer.




- Fit the clutch housing.
- Make sure that the oil pump control drive gear of the clutch housing engages correctly with the oil pump driven gear.



- Place the special washer correctly between the clutch bell and the hub.

**CAUTION**

**FIT THE SPECIAL WASHER WITH THE MACHINING FACING THE BELL**



- Position the clutch hub.



- Fit the clutch cover.
- Check that the measurement has not changed compared with the one carried out upon removal; tighten the clutch nut afterwards. If it has changed, rotate the crankshaft so that the oil pump control drive gear engages correctly with the oil pump driven gear on the clutch bell.



- Fit the washer and a new clutch hub nut.
- Tighten the clutch hub nut using the specific tool.



### Specific tooling

**9100896 Clutch housing locking tool**

- Tighten the nut and proceed to caulk.




- Insert the flat ring (1).
- Insert the cupped ring (2).

### CAUTION

**BE CAREFUL WITH THE CUPPED RING FITTING SIDE; THE RING CONE SHALL BE DIRECTED TOWARDS THE ENGINE.**

- Fit the lathed driven disc (3).
- Fit the nitrided steel disc (4).




- Fit the clutch plates. Start with the friction material discs and alternate with steel discs.
- Position all friction material discs with their teeth aligned in one of the long slots of the clutch housing.
- Place the control rod.



- Place the thrust plate.

**CAUTION**

ENSURE TO ALIGN THE ARROW ON THRUST PLATE WITH THE MACHINED REFERENCE ON HUB.



- Fit the clutch springs.
- Fit the screw washers.
- Tighten the six screws operating in stages and diagonally.



- Replace the gasket upon refitting.

## Head and timing

## Removing the head cover

The operations described below are valid for both heads.

- Unscrew and remove the four screws and collect the rubber rings.
- Remove the head cover.



## Removing the cylinder head

### NOTE

**THE OPERATIONS DESCRIBED BELOW REFER TO ONE HEAD REMOVING ONLY BUT APPLY TO BOTH HEADS.**

- Remove the head cylinder unit.
- Unscrew and remove the screw on the intake side.



- Unscrew and remove the screws on the exhaust side.




- Separate the cylinder from the head.
- Collect the gasket.



### See also

[Removing the cylinder](#)

## Cylinder head



### HEAD

pos.	Description	Type	Quantity	Torque	Notes
1	Water Temperature Sensor	M12x1.5	1	23 Nm (16.96 lbf ft)	-
2	Threaded plug for water sensor seat	M12x1.5	1	10 Nm (7.38 lbf ft)	Loctite Drise AL 506
3	Head stud bolt fastener nut - pre-tightening	M10x1.25	8	10 Nm (7.38 lbf ft)	Lubricate the threads before tightening
3	Head stud bolt fastener nut - tightening	M10x1.25	8	13 Nm (9.59 lbf ft) + 90° + 90°	Lubricate the threads before tightening
4	Fastener for Head / Cylinder / Outer side crankcase	M6	2	13 Nm (9.59 lbf ft)	-
5	Fastener for Head / Cylinder / Inner side crankcase	M6	4	12 Nm (8.85 lbf ft)	-
6	Nut fastening Stud Bolts / Head	M6	4	12 Nm (8.85 lbf ft)	-

pos.	Description	Type	Quantity	Torque	Notes
7	Nut fastening Stud Bolts / Head	M8	2	26 Nm (19.18 lbf ft)	-
8	Bleed union fastener screw	M5	4	6.5 Nm (4.79 lbf ft)	-
9	Water bleed union (steel)	-	1	3.50 Nm (2.58 lbf ft)	Loctite 243
10	Water bleed union (brass)	-	2	2 Nm (1.48 lbf ft)	Loctite 243

Removing the overhead camshaft


- Remove the clutch side crankcase half.
- Rotate the crankshaft until the rear cylinder reaches the TDC.



First remove the rear head cover in order to remove the rear head camshafts.

First remove the front head cover in order to remove the front head camshafts.

Mark the head camshafts, the corresponding sprocket wheels and cam caps in order not to interchange them upon refitting.



- Undo and remove the eight cam cap screws working in a diagonal sequence and in stages.
- Remove the cam cap carefully so as not to go through it and damage the seats of the calibrated dowels.
- Remove the camshafts with the gears.



## Removing the valves

- When removing the valve, mark the components according to the position and the cylinder they belong to, in order to refit the components to their correct positions.
- Remove the bucket tappets and the adjustment shims using a magnet.



- Compress the valve springs with the specific wrench and with the spring compressing tool.

### Specific tooling

**AP8140179 Valve spring compressor**

**020721Y Adaptor for valve removal**



- Remove the cotters using a magnet.



- Release the valve springs.
- Remove the valve spring fittings and the springs.



- Remove the valves.




## Checking the overhead camshaft

Check that the camshaft toothed wheel works properly: if it is damaged or does not move smoothly, replace both the timing chain and the camshaft toothed wheel.

### CAMSHAFT LOBES

- Check that they do not show blue colouring, pitting or scratches; otherwise, replace the camshaft and the relevant toothed wheel.
- Use a micrometer to check the sizes (a) and (b) of the camshaft lobes.




### Camshaft lobes sizes:

#### Inlet

- a: 36.28 / 36.32 mm (1.4283 / 1.4299 in); Limit: 36.15 mm (1.4232 in);
- b: 28 mm (1.1023 in);

#### Outlet

- a: 35.13 / 35.17 mm (1.3831 / 1.3846 in); Limit: 35.00 mm (1.3779 in);
  - b: 28 mm (1.1023 in);
- 
- Fasten the camshaft in horizontal position, as shown in the figure, and make it spin to check the eccentricity with a dial gauge; if necessary, replace the component.



**Camshaft eccentricity maximum limit 0.040 mm (0.0016 in)**

## Valve check

### CAUTION

**REPLACE THE VALVES ONE AT A TIME. DO NOT MIX THE COMPONENTS. EACH VALVE MUST BE INSERTED INTO ITS SEAT, WHICH IS MARKED PRIOR TO REMOVAL.**

### CAUTION

**THE SEAT (1) ON THE VALVE HEAD CANNOT BE REGROUND. IF REQUIRED, REPLACE THE VALVE.**

**GRINDING WITH ABRASIVE PASTE IS ALLOWED; VALVE STEM END REGRINDING IS NOT ALLOWED.**

Clean off any combustion residues from the valves.

Check the seat (1) on the valve head with a ruler flush.

The surface of the seat must not be concave; replace the valve if necessary.


Check the clearance between the stem and the valve guide:

inlet: **0.013 - 0.040 mm (0.00051 - 0.00157 in);**

**limit: 0.080 mm (0.00315 in)**

outlet: **0.025 - 0.052 mm (0.00098 - 0.00205 in);**

**limit: 0.100 mm (0.00394 in)**




Check the valve eccentricity:

**valve stem (3) maximum eccentricity allowed:**  
**0.05 mm (0.00197 in)**

**valve head (4) maximum eccentricity allowed:**  
**0.05 mm (0.00197 in)**

Check that the fixing grooves (5) of the valve cot-  
ters are in proper conditions.




### VALVE SPRINGS

Carry out a measurement and a visual inspection  
of the valve springs for damage, distortion or loss  
of tension.

Measure the spring length at release position.

Valve springs: **minimum wear limit (6) 42.5 mm**  
**(1.673 in).**

Valve springs: **minimum wear limit (7) 38 mm**  
**(1.496 in).**



## Checking the cylinder head

- Using a round scraper, clean off any carbon deposits in the combustion chamber.

### CAUTION

**DO NOT USE A POINTED INSTRUMENT TO AVOID DAMAGING OR SCRATCHING THE SPARK  
PLUG THREADS OR THE VALVE SEATS.**

- Check the head for damage or scratches and replace it if necessary.
- Check there are no mineral deposits or rust in the head water cooled jacket; clean off if required.
- Use a checking ruler and a thickness gauge positioned diagonally to the ruler to measure the cylinder head distortion.

**Maximum cylinder head distortion: 0.03 mm (0.0012 in)**

- Check that the tappet covers and the camshaft toothed wheel cover are not damaged or worn; replace the defective part(s).


## Installing the overhead camshaft

The camshaft refitting procedure is described in the "Timing" section.

**See also**

[Timing](#)

## Timing




### TIMING SYSTEM

pos.	Description	Type	Quantity	Torque	Notes
1	Camshaft gear fastener nut - pre-tightening	M15x1	4	30 Nm (22.13 lbf ft)	-
1	Camshaft gear fastener nut - tightening	M15x1	4	90 Nm (66.38 lbf ft)	-
2	Timing drive gear fastener screw	M24x1.5	2	40 Nm (29.50 lbf ft)	3M SCOTCH GRIP 2353


pos.	Description	Type	Quantity	Torque	Notes
3	Special screw for fastening mobile / fixed shoes	M8	4	19 Nm (14.01 lbf ft)	Loctite 242
4	Cam tower / head fastener screws - pre-tightening	M6	16	4.90 - 6.86 Nm (3.61 - 5.06) lbf ft	-
4	Cam tower / head fastener screws - tightening	M6	16	9.81 - 12.75 Nm (7.24 - 9.40 lbf ft)	-
4	Viti fissaggio castelletto / testa - serraggio	Torx	16	12 - 14 Nm (8.85 - 10.32 lbf ft)	-
5	Camshaft retainer plate fastener screw	torx M3	8	3 Nm (2.21 lbf ft)	Loctite 270

## Removing the chain tensioner

- Unscrew and remove the screw and collect the washer and the internal spring.



- Unscrew and remove the two screws.
- Remove the chain tensioner and collect the gasket.



## Chain removal

- Remove the chain tensioner.
- Remove the main pinion.
- Remove the movable chain slider and release the fixed chain slider from the clamp.
- Unscrew and remove the pin of the timing chain intermediate gear paying attention not to damage the O-ring.
- Collect the washer.



- Remove the timing chain intermediate gear.



- Slide off the timing chain from the crankshaft.

**NOTE**

IT IS ADVISABLE TO MARK THE CHAIN IN ORDER TO ENSURE THAT THE INITIAL DIRECTION OF ROTATION IS MAINTAINED.

**See also**

[Removing the chain sliders](#)

[Removing the chain tensioner](#)

---

**Removing the chain sliders**


- Remove the chain tensioner and the camshafts from the corresponding head.

**FRONT HEAD**

- First remove the clutch cover in order to remove the chain sliders from the front head.
- Unscrew and remove the movable chain tensioner slider screw.
- Slide it off from the head to remove it.




- Unscrew and remove the fixed chain tensioner slider screw.
- First remove the head in order to remove it.




---

#### REAR HEAD

- First remove the flywheel in order to remove the chain sliders from the front head.
- Unscrew and remove the movable chain tensioner slider screw.
- Slide it off from the head to remove it.



- Unscrew and remove the fixed chain tensioner slider screw.
- First remove the head in order to remove it.



#### See also

[Removing the chain tensioner](#)  
[Removing the head cover](#)

Magneto flywheel removal

---

### Checking the chain

Check the timing chain for damage or stiffness while moving. If required, replace both the timing chain and the camshaft sprocket wheels.

Check the timing chain guide for damage. If necessary, replace the parts.

---


## Installing the chain tensioner

Refit the removed timing system chain tensioner on the cylinder - head:

- Fit the timing chain on the crankshaft and on the intermediate gear.
- Remove the screw and collect the washer and the spring.



- Fit the chain tensioner body on the cylinder and insert a new paper gasket.
- Tighten the two screws to the prescribed torque.



- Insert the spring and tighten the screw together with the washer.



---

## Cam timing

---

### Timing

- Rotate the crankshaft until the front cylinder piston reaches the top dead centre.
- Lock the crankshaft with the specific special tool

#### Specific tooling

020720Y Timing tool

If necessary, remove the timing system gears from the camshafts:

- Place the camshaft with the timing system gear on a vice and protect the cams of the camshaft adequately.
- Unscrew and remove the nut.



**ANTICLOCKWISE NUT FOR BOTH REAR CYLINDER SHAFTS, AN ANTICLOCKWISE ARROW HAS BEEN PUNCHED ON IT.**



- Collect the washer.
- Remove the timing system gear from the camshaft.



- Clean gears surfaces (camshaft cone and gear cone) with: "System MC 217 spray metal cleaner".
  - Pre-fit the gear on the camshaft, so that it can turn freely.
  - Place the two camshafts in the head seats and align the two camshaft holes with the head holes.
- 
- Align the clearance recovery gear to the main timing system gear using the specific tool.

### Specific tooling

**020718Y Camshaft gear alignment pin**




- Using the specific jig, check the correct position of the cams.

**NOTE**

USE OF THE JIG: THIS TOOL IS PLACED ON THE CAMS WITHOUT THE CAM TOWER, USING THE PROFILE MARKED WITH THE NUMBER OF THE CYLINDER BEING USED, WITH THE MARKINGS FACING THE FLYWHEEL SIDE.

**NOTE**

THE JIG IS NOT A TOOL DESIGNED FOR TIMING BUT FOR IDENTIFYING THE CORRECT DIRECTION FOR CAM-SHAFT FITTING (THE SHAFTS MAY BE FITTED ROTATED BY 180° WITH REFERENCE TO THE CORRECT POSITION).

**Specific tooling****020723Y Jig for timing overhead camshafts**

- Place the cam tower.
- Pre-tighten the eight screws in the sequence indicated, to the prescribed torque.
- Tighten the eight screws in the sequence indicated, to the prescribed torque.
- Carry out camshaft timing with the appropriate dowels.

**Specific tooling****020719Y Timing pin****Locking torques (N\*m)**


**Cam tower / head fixing screws - M6 (16)** Pre-tightening: (4.90 - 6.86) Nm ((3.61 - 5.06) lb ft) Tightening: (9.81 - 12.75) Nm ((7.24 - 9.40) lb ft)

**CAUTION**

**PAY ATTENTION TO THE SCREW FIXING TYPE OF THE VALVE CAM TOWER, THREE DIFFERENT TYPES OF SCREWS CAN BE FOUND.**

- HEXAGONAL HEAD WITH 8 MM (0.31 in) SOCKET (1).
- HEAD WITH TORX MARK (2).
- FLANGED HEXAGONAL HEAD WITH 7 MM (0.27 in) SOCKET (3).

**FOR THIS LAST TYPE, THE TIGHTENING TORQUE GOES TO 12-14 Nm (8.85-10.32 lb ft). THE PRE-TIGHTENING IS THE SAME. THE SCREWS AND CAM TOWER CANNOT BE INTERCHANGED WITH THE PREVIOUS ONES.**

**CAUTION**

**INSTALL THE CAMSHAFT TIGHTENING NUTS WITH THE MARK FACING UP.**

- Pre-tighten the gear nut on the camshaft.



**REFIT THE NUT WITH THE MACHINED SURFACE FACING THE GEAR (THE MATERIAL ACRO-NYM SHOULD BE VISIBLE).**

**Locking torques (N\*m)**

**Nut fixing camshaft gears (pre-tightening) - M15x1 (4) 30 Nm (22.13 lb ft)**

- Remove the camshaft, lock it on a vice with aluminium jaws, then tighten it to the prescribed torque.



**DO NOT TIGHTEN THE CAMSHAFT GEAR NUT TO THE ULTIMATE TIGHTENING TORQUE WITH THE SHAFT MOUNTED ON THE CYLINDER. THIS OPERATION WOULD IRRETRIEVABLY DAMAGE THE HEAD.**

**Locking torques (N\*m)**

**Nut fixing camshaft gears - M15x1 (4) 90 Nm (66.38 lb ft)**


- Remove the gear alignment tool.

**Specific tooling****020718Y Camshaft gear alignment pin**

- Release the crankshaft from the specific special tool.
- Rotate the crankshaft in the riding direction until the rear cylinder piston reaches the top dead centre.
- Lock the crankshaft with the specific special tool.
- Carry out the timing operations performed for the front cylinder.

**Specific tooling****020720Y Timing tool**

Cylinder-piston assembly



CYLINDER

pos.	Description	Type	Quantity	Torque	Notes
1	Chain tensioner fastener screw	M6	4	13 Nm (9.59 lb ft)	-
2	Cylinder plate fastener screw	M6	4	7.84-9.81 Nm (5.78-7.23 lb ft)	-
3	Chain tensioner adjustment screw	M6	2	5.50 Nm (4.06 lb ft)	-

Removing the cylinder


- Remove the timing chain.
- Unscrew and remove the two head fastener screws located in the timing chain compartment.



- Unscrew and remove the outer screw.



- Unscrew and remove the four nuts, proceeding in stages and in a diagonal pattern.
- Ease the cylinder head assembly off the stud bolts.
- Remove the three nuts fastening the cylinder head on the intake and exhaust sides.



- Remove the gasket between the cylinder and the crankcase.



### See also

Chain removal

---

## Disassembling the piston

- Remove the head and cylinder.
- Take out the pin locking ring.



- Lock the connecting rod using the specific tool.
- Slide off the pin and remove the piston.

### Specific tooling

#### 020716Y Connecting rod locking



- Lock the connecting rod using circlips.



FOR SAFETY REASONS COVER THE CRANKCASE WITH A CLEAN CLOTH SO THAT THE SEEGER RINGS DO NOT FALL INTO THE CRANKCASE.



- Remove the top ring, the intermediate ring and the three oil scraper rings.





### See also

[Removing the cylinder head](#)  
[Removing the cylinder](#)


## Checking the cylinder

- All seal surfaces must be clean and flat.
- Make sure all threads are in proper conditions.
- Check cylinder sliding surface for signs of friction and scratches. Also check the seal surfaces for damages.

### CAUTION

**IF THE GROOVES ON THE CYLINDER LINER ARE EVIDENT, REPLACE THE CYLINDER AND THE PISTON.**

- Clean off lime scales on the cylinder cooling slots.
- Measure the cylinder bore at a distance of 10 - 43 - 90 mm (0.39 - 1.69 - 3.54 in) from the head coupling surface; the highest value should be considered to estimate wear limits.



**Cylinder bore "C": 92.000 mm (3.6220 - in) C=**  
**D1 or D2 max**

**Cylindricity tolerance: 0.020 mm (0.00079 in)**


Replace the cylinder, the piston and the piston ring all together if not complying with specifications.

**Checking the piston**

- Measure the piston skirt diameter "P" with a micrometer (a=10 mm (0.39 in) from the piston lower border).
- Calculate the clearance between piston and cylinder as follows:

**Piston - cylinder clearance  $C = C - P$**


**Piston - cylinder clearance: 0.050 - 0.064 mm (0.00197 - 0.00252 in) Limit: 0.100 mm (0.00039 in)**



- Replace the cylinder, the piston and the piston ring all together if not complying with specifications.

**PISTON RINGS**

- Clean off any carbon deposits from the grooves in the piston rings and from the rings themselves.
- Measure the piston ring side clearance and replace the piston and the piston rings all together if not complying with specifications.

**Piston ring side clearance:**

**Top ring (1st slot): 0.030 - 0.065 mm (0.0012 - 0.0026 in)**

**Intermediate ring (2nd slot): 0.020 - 0.055 mm (0.0008 - 0.0022 in)**

**Oil scraper ring (3rd slot): 0.010 - 0.045 mm (0.0004 - 0.0018 in)**

- Fit the piston ring to the cylinder.
- Level the installed piston ring with the piston crown.

- Measure piston ring port and replace it if not complying with specifications.

**CAUTION**


IT IS NOT POSSIBLE TO MEASURE THE GAP OF THE OIL SCRAPER RING END: IF CLEARANCE IS EXCESSIVE, REPLACE THE THREE PISTON RINGS.

**Piston ring end gap:**

**Top ring: 0.25 - 0.40 mm (0.0079 - 0.0157 in)**

**Intermediate ring: 0.35 - 0.55 mm (0.0138 - 0.0216 in)**

**Oil scraper ring: 0.20 - 0.70 mm (0.0079 - 0.0276 in)**

**PIN**


- Clean off combustion residues from the piston crown and from the area above the top ring.
- Check for cracks on the piston and for compression on the piston sliding surface (seizing); Replace the piston if required.

**CAUTION**

**SMALL STRIATIONS ON THE PISTON LINER ARE ADMISSIBLE.**

- Measure the pin outside diameter (a) and if not complying with specifications, replace the pin.


**Pin outside diameter: 22.00 - 21.97 mm (0.8661 - 0.8650 in) Limit: 21.96 mm (0.8646 in)**



- Measure the pin housing diameter (b) and replace the piston if not complying with specifications.

**Pin housing diameter (b): 22.010 - 22.015 mm (0.8665 - 0.8667 in)**

- Calculate the clearance between pin and pin hole and, if not complying with specifications, replace both pin and piston.



**Pin - piston clearance:  $C = b - a$**

**0.010 - 0.045 mm (0.0004 - 0.0018 in)**

**Limit: 0.060 mm (0.0024 in)**

**CAUTION**

**AD OGNI TIPO DI CILINDRO, IN ALLUMINIO O IN GHISA, DEVE ESSERE ACCOPPIATO L'APPOSITO PISTONE.**

**CYLINDER - PISTON COUPLING**

Specification	Desc./Quantity
Piston - cylinder coupling Type A	Cylinder: 91.990 - 91.977 mm (3.6216 - 3.6219 in) Piston: 91.933 - 91.940 mm (3.6217 - 3.6197 in)
Piston - cylinder coupling Type B	Cylinder: 91.997 - 92.004 mm (3.6219 - 3.6222 in) Piston: 91.940 - 91.947 mm (3.6197 - 3.6199 in)
Piston - cylinder coupling Type C	Cylinder: 92.004 - 92.011 mm (3.6222 - 3.6225 in) Piston: 91.947 - 91.954 mm (3.6199 - 3.6202 in)
Piston - cylinder coupling Type D	Cylinder: 92.011 - 92.018 mm (3.6225 - 3.6227 in) Piston: 91.954 - 91.961 mm (3.6202 - 3.6205 in)
Fitting clearance	0.050 - 0.064 mm (0.00197 - 0.00252 in)

Sui pistoni accoppiabili con i cilindri in ghisa è riportata l'indicazione "GH".




## Fitting the piston

An arrow stamped on the piston crown indicates the exhaust side.

- When refitting the piston rings on the piston, the arrow stamped inside the piston must be turned towards the operator.

The piston rings are different and must be installed with the "N" marking at the top.



- Fit the lower oil scraper ring on the piston with the gap turned towards the exhaust side.



- Install the remaining piston rings on the piston, offsetting the gaps in the rings by 90° relative to each other.
- Fit a new retainer ring on the piston.
- Fit the piston on the connecting rod and install the gudgeon pin.



#### Specific tooling

##### 020470Y Pin snap ring fitting tool

- Fit a new retainer ring on the piston to fasten the gudgeon pin.

#### Specific tooling

##### 020470Y Pin snap ring fitting tool



## Installing the cylinder

Fit the stud bolts, if previously removed.

#### CAUTION

**THE STUD BOLTS SHOULD BE FITTED SO THAT THEY PROTRUDE. DISTRIBUTE Loctite 270 (high-strength) ON THE THREAD AND SCREW THE STUD BOLT ON THE CRANKCASE UNTIL THEY PROTRUDE BY 137 mm (5.39 in), THEN MAKE SURE THE Loctite HAS SET.**

- Insert a new cylinder base gasket, it should be as thick as the gasket previously removed: 0.40 - 0.50 - 0.60 mm (0.0157 - 0.0197 - 0.0236 in).
- The silicone side should be facing the crankcase.

**CAUTION**

IF THE ORIGINAL GASKET THICKNESS CANNOT BE CHECKED OR SHOULD THE CYLINDER BE REPLACED, REFER TO THE "BASE GASKET SELECTION" SECTION.




- Before fitting the cylinder, place the chain sliders and the timing chain on the crankshaft; fit the timing chain on the crankshaft from the base side.

**NOTE**

BEFORE FITTING THE CYLINDER, CAREFULLY BLOW AIR INTO THE LUBRICATION DUCT AND LUBRICATE THE CYLINDER LINER.



- Insert the cylinder-head unit on the stud bolts.
- Working in a diagonal sequence and in stages, screw the four nuts once the stud bolt threads have been greased.




- Screw the screw located outside the cylinder.



- Tighten the three screws on the intake and discharge sides.
- Screw the two head fixing screws located inside the timing chain compartment.



- Check that the intermediate gear pin lubrication holes are clean.



- With a hook, hold the timing chain.
- Fit the timing chain on the intermediate gear.
- Slide in the pin together with a new O-Ring and a washer.



- Check that the axial clearance between the pin and the gear is between 0.30 and 0.60 mm (0.0118 - 0.0236 in).



- Tighten the intermediate gear pin once Loctite residues are thoroughly removed and a high-strength threadlock is applied on the thread.
- Make sure that both timing chain sliders are correctly fitted.
- Refit the overhead camshafts following the procedure described in the "Timing" section.



### See also

[Selecting the base gasket](#)

## Selecting the base gasket

- Place the specific special tool on the piston, which should have sealing rings and be fitted on the connecting rod.
- Lock the special tool with the clamp.

### Specific tooling

#### AP8140302 tool for sealing ring fitting



- Temporarily, fit the piston to the cylinder, without base or head gasket.
- Remove the clamp from the sealing ring locking tool.
- Remove the special tool for locking the connecting rod.



- Fit a dial gauge on the specific tool.
- Set the dial gauge to zero on a reference surface with a medium preload, e.g. 5 mm (0.2 in). Keeping the zero setting, fit the tool on the cylinder and lock it with two nuts (10 Nm - 7.38 lb ft) as shown in the figure.



### Specific tooling

020714Y Dial gauge mounting

- Rotate the crankshaft up to the TDC (the reversal point of the dial gauge rotation).
- Lock the crankshaft at TDC using the specific tool.
- Calculate the difference between the two measurements: using the chart below, identify the thickness of the cylinder base gasket to be used upon refitting. By correctly identifying the cylinder base gasket thickness, an adequate compression ratio can be maintained
- Remove the specific tool and the cylinder.



Specific tooling

020720Y Timing tool

BASE GASKET

Specification	Desc./Quantity
Measured protrusion -0.10 / + 0.0 mm (- 0.0039 / 0.0000 in)	Gasket 0.4 mm (0.0157 in)
Measured protrusion 0.05 / 0.10 mm (0.0020 / 0.0039 in)	Gasket 0.5 mm (0.0197 in)
Measured protrusion 0.15 / 0.30 mm (0.0059 / 0.0118 in)	Gasket 0.6 mm (0.0236 in)

Installing the cylinder head

- Place the fixed chain tensioner slider on the cylinder timing chain compartment, opposite to the chain tensioner.



- Fit a new gasket between the cylinder and the head.
- Couple the cylinder and the head.



- Screw without tightening the two screws on the outlet side.



- Screw without tightening the screw on the intake side.
- Tighten the cylinder-head fixing screws to the prescribed torque.
- Place the cylinder-head unit on the crankcase stud bolts.



## Installing the head cover


### CAUTION

**BEFORE REFITTING HEAD COVERS, CLEAN HEAD AND COVER SURFACES CAREFULLY.**

- Apply THREEBOND on the head cover perimeter along the gasket housing.




- Apply THREEBOND on the head in the areas indicated in the figure.




- For the remaining operations, follow the removal operations but in reverse order.

**Crankcase - crankshaft**



**CRANKCASE 1**

pos.	Description	Type	Quantity	Torque	Notes
1	Bearing retainer fastener screw	M6	3	10 Nm (7.38 lbf ft)	Loctite 270
2	Piston oil jet fastener screw	M5	2	5.50 Nm (4.06 lbf ft)	Loctite 242
3	Tapered plug for crankshaft main bearing lubrication	M8x1	4	15 Nm (11.06 lbf ft)	-
4	Calibrated Brass dowel fixed to complete crankcase	M8	2	5.50 Nm (4.06 lbf ft)	-



### CRANKCASE 2


pos.	Description	Type	Quantity	Torque	Notes
1	Engine speed sensor fixing screw	M6	1	13 Nm (9.59 lbf ft)	Loctite 243
2	Screw fastening flywheel side / clutch side crankcase halves	M6	8	13 Nm (9.59 lbf ft)	-
3	Screw fastening flywheel side / clutch side crankcase halves	M8	9	29 Nm (21.39 lbf ft)	-
4	Special calibrated screw for gearbox lubrication	-	1	18 Nm (13.28 lbf ft)	-

## Splitting the crankcase halves

- Fit the special tool, tightly fastening the four screws securing the tool onto the crankcase.
- Unscrew and remove the crankshaft fastener nut anticlockwise using the special tool, retrieving the washer.


### Specific tooling

#### 020711Y Engine pinion locking





- Use a commercially available extractor to remove the crankshaft gear.




- Remove the gearbox control rod, retrieving the washer.

- Unscrew and remove the screw fixing the speed sensor.
- Remove the speed sensor with caution.



- Heat the screws of the gearbox selector mounting plate.




- Unscrew and remove the three screws fastening the gearbox selector mounting plate.



- Remove the plate complete with selector



- Unscrew the two neutral sensor fastener screws.



- Remove the neutral sensor.



- Retrieve the sensor contact complete with spring.



- If the pinion has been removed, refit, fastening with the special tool.

## Specific tooling

9100896 Clutch housing locking tool



The tone wheel is fixed with Loctite threadlock and must therefore be heated with a special hot air gun, taking particular care not to heat excessively.

- Remove the speed sensor tooth with the special tool.

When refitting, fix the tone wheel with strong Loctite threadlock.

#### Specific tooling

020715Y Tone wheel removal



- Unscrew and remove the selector drum fastener screw.



- Remove the selector drum.




- Remove the pinion.



- Remove the clutch control rod.



- Working on the left hand side, unscrew and remove the nine M8 crankcase fastener screws.




- Working on the left hand side, unscrew and remove the nine M6 crankcase fastener screws.



- Remove the fuel vapour breather pipe mounting plate.

**CAUTION**

DURING REASSEMBLY, REMEMBER TO FIT THE FUEL VAPOUR BREATHER PIPE MOUNTING PLATE NEAR THE PINION.



- Rotate the engine and the engine mounting into a horizontal position.



- Unscrew and remove the pin, then re-tighten by one turn to give the crank-case halves clearance and verify tightness.

**CAUTION**

TAKE PARTICULAR CARE TO ENSURE THAT THE ENGINE AND ENGINE MOUNTING ARE STABLE AND ENSURE THAT THE ENGINE IS SECURELY FASTENED TO THE MOUNTING PLATE.



- Remove the two screws fastening the mounting.



- Separate the crankcase halves by giving short taps with a rubber mallet.



- Open the crankcase halves.



- Retighten the two screws to the engine mounting.



- If necessary, unscrew and remove the two screws fastening the rose pipe.
- Remove the rose pipe.




See also

[Removing the cylinder](#)

Magneto flywheel removal

Removing the crankshaft



**CRANKSHAFT**

pos.	Description	Type	Quantity	Torque	Notes
1	Crankshaft primary gear fastener nut	M24x1.5	1	270 Nm (199.14 lbf ft)	Anticlockwise nut
2	Connecting rod screw	M10	4	15 + 30 Nm (11.06 + 22.13 lbf ft) + 50° ± 2°, final control torque 65 - 78 Nm (47.94 - 57.53 lbf ft)	Lubricate the threads before tightening

- Remove the crankshaft.

**See also**

[Splitting the crankcase halves](#)

---

## Inspecting the crankcase halves

### BEARINGS AND OIL SEAL CHECK

Thoroughly clean the two sections of the crankcase, the ball bearings, the threads of the crankcase fixing screws and the bearing seats with a non-aggressive solvent. Clean the seal surfaces and check that they are not damaged.

**CAUTION**

**TO AVOID DAMAGING BOTH CRANKCASE HALVES PLACE THEM ON A FLAT SURFACE.**

Check that both crankcase halves are not cracked or damaged.

Check that all threads are in proper conditions.

Check that all oil seals remaining in their position are not worn or damaged.

Check all ball bearings for clearance, smoothness and potential distortions.

**CAUTION**

**LUBRICATE BALL BEARINGS WITH ENGINE OIL BEFORE FURTHER CHECKING.**

If the internal ring does not rotate smoothly and silently or if there is some noise while it turns, it means that the bearing is faulty and must be replaced.


### OIL FILTER AND OIL DELIVERY PIPE CHECK

Check the oil filter for damage. If necessary, replace the part.

Clean the oil net with petrol and inspect the net links for potential damage.



**CHECK THE ENGINE OIL FILTER O-RING.**




**LUBRICATION CHECK**

- Working on both crankcase halves, remove and thoroughly clean the nozzle that lubricates the piston crown.

REPLACE THE SPRAY NOZZLE O-RING IF NECESSARY.



- Replace the O-ring on the oil passage duct.



Before refitting



UPON REFITTING THE CRANKSHAFT, GREASE THE SHAFT BUSHING-CONNECTING ROD COUPLING.

---

**Inspecting the crankshaft components****Crankshaft axial clearance check**

- The shaft axial clearance on the crankcase should be checked with a comparator mounted on the specific comparator support.
- The clearance should be between 0.1 - 0.4 mm (0.0039 - 0.0157 in).
- If the clearance is beyond tolerance, check the reference surfaces.

**Specific tooling**

020714Y Dial gauge mounting


---

**Main bearing journal**

---

## Removal

- Mark the position of the original semi-bushings on the crankcase.
- To reduce the installation force necessary, score an incision approximately 0.5 mm (0.02 in) deep (without cutting into the steel shell) in each semi-bushing in the area indicated in the figure.



- Remove the bushings with the crankcase cold, using a press and the specific tool and pushing inward from the outside of the crankcase.



### Specific tooling

020726Y Extractor for bushings

## Installing


- The orientation of the semi-bushings must match the specifications indicated in the drawing as closely as possible.

### NOTE

WHEN REPLACING THE SEMI-BUSHINGS ALONE, THE NEW COMPONENTS MUST BE THE SAME COLOUR AS THE REMOVED COMPONENTS. IF THE COLOUR OF THE OLD COMPONENTS IS NO LONGER VISIBLE, USE THE TABLE TO IDENTIFY THE CORRECT COMPONENTS, REFERRING TO THE CRANKCASE AND CRANKSHAFT CLASSES.

Key:

\* Semi-bushing joint line.



- Fit the new bushings with the crankcase cold, using a press and the specific tool and pushing outward from the inside of the crankcase, until the punch comes into contact with the crankcase surface.



### Specific tooling

020727Y Punch for bushings

## Assembling the connecting rod

### CAUTION

TO FIT THE CONNECTING RODS, CHECK THE COUPLING TYPES INDICATED IN THE "CRANKCASE- CRANKSHAFT CONNECTING ROD" SECTION, IN THE "CHARACTERISTICS" CHAPTER OF THE WORKSHOP MANUAL.

## Installing the crankshaft

- Place the left side crankcase half on the engine support adequately.
- Place the crankshaft on the seat of the crankcase half with caution.



## Refitting the crankcase halves

- Fit the strum box, if previously removed.
- Tighten the two strum box fixing screws.



- Turn the engine support into horizontal position.
- Place the left crankcase half on the engine support, fitting it on the engine support pins.


### CAUTION

TAKE PARTICULAR CARE TO ENSURE THAT THE ENGINE AND ENGINE MOUNTING ARE STABLE AND ENSURE THAT THE ENGINE IS SECURELY FASTENED TO THE MOUNTING PLATE.

- Fit the complete transmission gears unit.
- Apply black sealing paste (Threebond) on the left crankcase half.

**CAUTION**

**BE CAREFUL NOT TO APPLY THREEBOND IN EXCESS AS IT MAY BLOCK OIL DUCTS THROUGH THE CRANKCASE HALVES.**



- Place the right crankcase half with the aid of a rubber hammer.



- Tighten the two fixing pins.




- Rotate the engine and the engine support into vertical position.

- Working on the left side, place the nine M6 screws fixing the crankcase.



- Working on the left side, place the nine M8 screws fixing the crankcase.
- Tighten all the crankcase fixing screws, both M6 and M8 type.



- Slide in the clutch control rod.



- Place the pinion.



- Place the gear selector drum and check that it is correctly timed; thrust the desmo drum axially from the fly-wheel side so that the timing roller protrudes.



- Tighten the gear selector drum fixing screw.



- Position the tone wheel.



- Tighten the tone wheel with the special tool.

**Use Loctite medium-strength for sealing.**

**Specific tooling**

**020715Y Tone wheel removal**



- Tighten the pinion fixing nut using the special tool.

**Specific tooling****9100896 Clutch housing locking tool**

- Position the sensor contact together with the spring.




- Place the neutral sensor and lubricate its seat to facilitate refitting.



**BE CAREFUL NOT TO DAMAGE THE O-RING WHEN INSERTING THE SENSOR IN ITS POSITION.**




- Tighten the two screws fixing the neutral sensor.



- Position the plate together with the selector.



- Tighten the three screws fixing the gear selector plate by applying Loctite medium-strength.



- Place the speed sensor with caution.
- Tighten the speed sensor fixing screw.



- Place the transmission control rod with the washer.


- Remove the grease off the primary pinion tapered pins - crankshaft coupling surfaces .
- Position the crankshaft gear.



- Position the washer and the crankshaft lock-nut.



- Fit the special tool and fix it steadfastly to the crankcase by tightening the four fixing screws on the crankcase.
- Tighten the crankshaft gear lock-nut.



### **Specific tooling**

#### **020711Y Engine pinion locking**




---

## **Lubrication**

---

Oil pump



OIL PUMP

pos.	Description	Type	Quantity	Torque	Notes
1	Oil drainage plug	M16x1.5	1	19 Nm (14.01 lbf ft)	-
2	Fastening oil sensor on clutch side crankcase half	-	1	13 Nm (9.59 lbf ft)	-
3	Fastening oil filter union on clutch side crankcase half	-	1	20 Nm (14.75 lbf ft)	-
4	Oil filter	-	1	14 Nm (10.33 lbf ft)	-
5	Oil pressure regulator valve	3/4" Unf 16	1	43 Nm (31.72 lbf ft)	-
6	Oil pump fastener screw	M6	2	5.50 Nm (4.06 lbf ft)	Loctite 242
7	Rose pipe fastener screw	-	2	12 Nm (8.85 lbf ft)	-
8	Complete oil pump gear fastener	M5	1	10 Nm (7.37 lbf ft)	Loctite 270
9	Oil pump cover fastener screw	M3	2	0.80 Nm (0.59 lbf ft)	-
10	Complete oil pump gear fastener	-	1	9-11 Nm (6.64-8.11 lbf ft)	-

Removing


OLD GENERATION PUMP REMOVAL

- Lock the pump gear with the commercially available hook spanner and undo the screw; then collect the washer.





- 
- Collect the shim washer.



- 
- Undo and remove the two screws fixing the oil pump.



- 
- Remove the entire pump.



---

#### NEW GENERATION PUMP REMOVAL

- Press the raised side of the safety washer using a screwdriver.



- Lock the pump gear with a commercial hook spanner and unscrew the nut, collecting the safety washer.



- Remove the water pump gear.



- Collect the shim washer.



- Undo and remove the two screws fixing the oil pump.



- Remove the entire pump.



---

## Inspection

- Undo and remove the two fixing screws.



- Using a thickness gauge check clearance between rotor and stator and replace the rotor / stator unit if necessary.

**clearance between rotor and stator:  $0.04 \pm 0.10$  mm (0.0016 in - 0.0039 in).**



- Slide off the shaft with the cover.



- Collect the lock pin from the shaft.



- Remove the oil pump rotor.



- Remove the oil pump stator.

**CAUTION**

CHECK THAT THE ROTOR AND STATOR ARE NOT DAMAGED (NO EVIDENT ABRASIONS, SCORES OR ANY OTHER MARKS).



## Installing

**NOTE**

PAY ATTENTION TO ALIGN THE REFERENCES ON STATOR AND ROTOR DURING INSTALLATION AND CHECK CLEARANCE WITH A FEELER GAUGE. IF REQUIRED, REPLACE THE STATOR / ROTOR UNIT.



### OLD GENERATION PUMP INSTALLATION

---


- Fit the oil pump in its seat.



- Tighten both oil pump fixing screws.



- Fit the shim washer.



- Fit the oil pump gear and fasten it through appropriate screw with corresponding washer.



- By means of a commercial hook spanner, lock the pump and tighten the screw to the prescribed torque.



### NEW GENERATION PUMP INSTALLATION


- Fit the oil pump in its seat.



- Tighten both oil pump fixing screws.



- 
- Fit the shim washer.



- 
- Fit the oil pump gear.



- 
- Fit the safety washer.
  - By means of a commercial hook spanner, lock the pump and tighten the nut to the prescribed torque.



- By means of a screwdriver, lift and bend the safety washer opposite the fitting tabs, until it rests on the nut.




## INDEX OF TOPICS

**P**OWER SUPPLY

**P SUPP**

Fuel pump



FUEL PUMP					
pos.	Description	Type	Quantity	Torque	Notes
1	TEFL screw fastening fuel pump	M5x16	6	6 Nm (4.42 lbf ft)	-

Electrical characteristics:

- Resistance: 0.7 +/- 0.2 Ohm

NAVIGATOR: ELECTRICAL ERRORS

Fuel pump relay control P0230


Example value: shorted to positive / open circuit, shorted to negative.

Error cause

- If shorted to positive: excessive voltage has been detected at PIN 62 of the VEHICLE connector.
- If the circuit is open, shorted to negative: voltage equal to zero has been detected at PIN 62 of the VEHICLE connector

Injection

## Diagram



### THROTTLE BODY

pos.	Description	Type	Quantity	Torque	Notes
1	Intake union fastener screw	M6	8	12 Nm (8.85 lb ft)	Loctite 242
2	RBW control unit fastener screw	M5	2	3.50 Nm (2.58 lb ft)	Loctite 242
3	Injector fastener screw	M6	2	12 Nm (8.85 lb ft)	Loctite 242
4	Injection Throttle Body fastener screw	M6	8	12 Nm (8.85 lb ft)	Loctite 242

## Ride by Wire

### RIDE BY WIRE

#### Operating logic

Those riding motorbikes do not require a specific throttle valve opening from their engines but actually a specific torque. The Ride by Wire system has been so designed that the throttles of the throttle bodies are mechanically isolated from the throttle control; their actuation depends exclusively on 2 electrical motors controlled by the control unit. Therefore, there is a "Throttle map" to which the control unit refers in order to decide the position at which the throttle valves should be and at what speed they should reach the pre-set position. The main parameters which influence the throttle map are:

- Throttle position and opening/closing speed
- Engine rpm
- Inlet pressure read at each inlet manifold
- Rear and front throttle valve position
- Air temperature

The functions required from the Marelli control unit therefore are:

1. Ride by Wire system control (throttle map)
2. Injection/ignition control
3. System safety checks

### **1 - Ride by Wire system control**

**THROTTLE GRIP POSITION SENSOR** The throttle grip is the part to which the throttle control cables arrive; its task is to translate the rider's power request into an electrical signal to be sent to the electronic control unit. The two throttle cables (opening and closing) actuate on a scroll mounted on a shaft and which is sent back to its home position by a return spring.

On the shaft covers there are 2 double track potentiometers (4 control tracks) by means of which the torque demand is read (and checked).

**Marelli 5DM electronic control unit** Besides the regular control functions of the injection system, it supervises the throttle bodies: Through the throttle grip position sensor, it reads the torque demand and, through the THROTTLE MAP, it decides the throttle opening and sends the command to the throttle valve control unit. It checks the correct operation of each component (Self-diagnosis), of the system (Safety), and carries out the emergency procedure (Recovery).

**EFI throttle control unit** The control unit receives the target throttle opening to be carried out and it actuates on the control acting on the throttle body motors.

It checks (through the throttle position sensor signal) that the throttle bodies have reached the target position.

It communicates the position reached to the Marelli control unit. It does not actuate on Safety strategies.

**Throttle Body** The two throttle bodies are made up of:

- Throttle valve with 2 return springs for the controlled minimum opening position.
- DC electrical motor
- Tinned double throttle position sensors with magnetic control (contactless)

The throttle bodies do not require any maintenance and cannot be overhauled. In case of electric or mechanic malfunction, replace the whole unit.

**Pressure sensors** The pressure sensors (one per cylinder) are fundamental not only for the injection map at low and stabilised speeds but also for checking the Ride by Wire system: their signal is connected to a TORQUE CHAIN for checking the correct opening of the throttle valves.

**Intake air temperature sensor** The signal coming from the sensor is used to calculate the estimated torque since the oxygen in the air also depends on its density which varies according to temperature.

### **2 - Injection/ignition control**

Map for injection type (alpha-D)/rpm where:

- alpha is the throttle position
- D is the pressure measured at inlet ducts
- Rpm are the engine revolutions
- At idle and for slow and stabilised speeds D/n

- For medium-high throttle openings  $\alpha/n$
- For temporary speed (speed change)  $\alpha/n$
- The main parameters that correct the injection map are:
- Engine temperature
- Atmospheric pressure (calculated)
- Lambda probe signal
- Air temperature

### 3 - System safety checks

The checks are structured in several levels:

- Level 1 - sensor correct operation
- Level 2 - comparison between requested torque and estimated torque generated by the engine
- Level 3 - a microprocessor controls the correct operation of the regular microprocessor

The consequent maintenance operations may be of different gravity according to the level and the defective component:

A the malfunction does not affect riding in safety, the warning light turns on, the word Service is displayed, the signal recovery value considered not reliable is used and the engine works regularly.

B the malfunction may affect riding in safety, the warning light turns on, the message Urgent Service is displayed, the torque demands are not fully activated (reduced torque).


C the malfunction may affect riding in safety, the warning light turns on, the message Urgent Service is displayed, the engine operates in Limp Home function (accelerated idle), the throttles which are at the position exclusively depending on the springs are not moved. The engine may shut off during the operation if it is running at idle speed and the gear is in neutral.

D the malfunction may affect riding in safety, the warning light turns on, the message Urgent Service is displayed, the engine stops running.

---

## Removing the throttle body

- Remove the filter casing.
- Working on both bodies, undo and remove the four screws and slide off the filter support.




- Remove the upper plate.



- Remove both bodies.

**UPON REFITTING, REPLACE THE THROTTLE BODY GASKET WITH A NEW ONE OF THE SAME TYPE.**



- Working on both bodies, undo and remove the two plate screws.



- Remove the plate.
- Working on both bodies, undo and remove the screw and detach the body.



- Working on the body in question, remove the injector, slide off the clip and the injector itself.

**CAUTION**

NEVER UNDO THE SCREWS IN THE FIGURE



---

## Using axone for injection system

The complete list of all the parameters- device status, errors, etc.- is available at the home page of the website **[www.serviceaprilia.com](http://www.serviceaprilia.com)** in the search section: Parameters Navigator.


The same parameters- device status, errors, etc. -are grouped per type of component they refer to in the **Electrical system chapter, Checks and Controls**

---

INDEX OF TOPICS

SUSPENSIONS	SUSP
-------------	------

## Front



### FRONT WHEEL

pos.	Description	Type	Quantity	Torque	Notes
1	Wheel axle nut	-	1	80 Nm (59 lbf ft)	-
2	TE flanged screw fastening front disc	M8x20	12	30 Nm (22.13 lbf ft)	Loctite 243

## Removing the front wheel


- Hold the vehicle front part.
- Unscrew the screws fixing the front pliers and slide them off the disc.



- Remove the wheel axle fixing nut.
- Retrieve the sealing washer.



- Loosen the screws on the wheel axle clamps.



- Tap the wheel axle slightly with a rubber mallet so that the hole on the opposite side is exposed.
- Remove the wheel axle by inserting a screwdriver in the holes on the pin.

- During extraction, support the wheel and then remove it.



- Collect the spacer from the front wheel right side.



## Checking the front wheel

### FRONT WHEEL BEARINGS

Carry out the check with the bearings fitted on the wheel.



**CHECK THAT ALL PARTS ARE IN GOOD CONDITION, ESPECIALLY THOSE LISTED AS FOLLOWS.**

#### ROTATION CHECK

- Manually rotate the inside ring of each bearing. Rotation must be constant, smooth and noiseless.

If one or both bearings do not fall within the control parameters:

- Replace both wheel bearings.

#### RADIAL AND AXIAL CLEARANCE CHECK

- Check the radial and axial clearance.

**Axial clearance: a minimum axial clearance is allowed.**

**Radial clearance: none.**

If one or both bearings do not fall within the control parameters:

- Replace both wheel bearings.



**ALWAYS REPLACE BOTH BEARINGS.**

**ALWAYS REPLACE THE BEARINGS WITH OTHERS OF THE SAME TYPE.**

#### GASKETS

- Check that the gaskets are in good conditions; replace them if they show signs of damage or excessive wear.




**ALWAYS REPLACE BOTH GASKETS.**

**ALWAYS REPLACE THE GASKETS WITH OTHERS OF THE SAME TYPE.**

#### WHEEL AXLE

- Use a dial gauge to check the wheel axle eccentricity. Replace the wheel axle if the eccentricity exceeds the limit value.




#### Characteristic

##### Maximum eccentricity:

0.25 mm (0.0098 in)

- Using a dial gauge, check that the radial (A) and the axial (B) eccentricities of the rim do not exceed the limit value. An excessive eccentricity is usually caused by worn or damaged bearings. Replace the rim if, after replacing the bearings, the value is not within the specified limit.




Characteristic

Maximum radial and axial eccentricity:

2 mm (0.0079 in)

Handlebar




HANDLEBAR

pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening counterweight to handlebar end	M6x50	2	10 Nm (7.37 lbf ft)	-
2	Stainless steel TCC screw fastening upper U-bolt to lower clamp	M8x25	4	25 Nm (18.44 lbf ft)	-
3	Screws fastening light switch assembly	-	2 + 2	1.5 Nm (1.11 lbf ft)	-
4	Light switch locking screws (Option)	M4	2	1.5 Nm (1.11 lbf ft)	-


Front fork

Diagram




FORCELLA ANTERIORE - SHOWA

Pos.	Descrizione	Tipo	Quantità	Coppia	Note
1	Screws (fasten onto fork hubs)	M8x40	4	25 Nm (18.44 lb ft)	-
2	ABS sensor fastener screw	M5	1	6 Nm (4.42 lbf ft)	-
3	ABS sensor plate fastener screw	M5x12	2	6 Nm (4.42 lbf ft)	-



**FRONT FORK - SACHS**

pos.	Description	Type	Quantity	Torque	Notes
1	Screws (fasten onto fork hubs)	M8x40	4	25 Nm (18.44 lb ft)	-
2	Bottom screw	-	2	30 Nm (22.13 lb ft)	Loctite 242
3	Cap	-	2	20 Nm (14.75 lb ft)	-
4	Nut on pumping member pin	-	2	20 Nm (14.75 lb ft)	-
5	ABS sensor fastener screw	M5	1	6 Nm (4.42 lbf ft)	-
6	ABS sensor plate fastener screw	M5x12	2	6 Nm (4.42 lbf ft)	-




**OPTION 01-** Steering upper plate **without** a headstock cut.

**STEERING - OPTION 1**

pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-
2	Headstock cap	M22x1	1	100 Nm (73.75 lb ft)	-
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-
4	TCEI screw fastening U-bolt onto fork yoke	M10x60	2	50 Nm (36.88 lb ft)	-

**OPTION 02-** Steering upper plate **with** a headstock cut.




**STEERING**

pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-
2	Headstock nut - pre-tightening	M22x1	1	10 Nm (7.37 lb ft)	Loctite 243
2	Headstock nut	M22x1	1	25 Nm (18.44 lb ft)	Loctite 243
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-
4	TCEI screw fastening U-bolt onto fork yoke	M10x60	2	50 Nm (36.88 lb ft)	-
5	Steering upper plate clamp closing screw	M8x30	1	25 Nm (18.44 lb ft)	Loctite 243

**Removing the fork legs**

- Remove the ABS sensor.
- Remove the front wheel.
- Support the stanchion and loosen the screws on the upper and then the lower plate.
- Remove the stanchion.





---

## Draining oil

**NOTE**

THE FOLLOWING OPERATIONS REFER TO THE SHOWA FORKS.

**NOTE**

THE OPERATIONS DESCRIBED BELOW ARE VALID FOR BOTH STEMS.


**NOTE**

BEFORE CARRYING OUT THE FOLLOWING OPERATIONS GET A CONTAINER WITH SUITABLE CAPACITY TO COLLECT THE OIL.

- Remove the fork.
- Being careful not to damage the stanchion when placing it in a vice, in vertical position, using the appropriate protection.

### Specific tooling

AP8140149 Protection for fitting operations



- Unscrew the sleeve cap.



- Drain the oil into a container of suitable capacity to collect fluids.



**DO NOT DISPOSE OF OIL INTO THE ENVIRONMENT. DISPOSE OF ENGINE OIL IN A SEALED CONTAINER AND TAKE IT TO YOUR SUPPLIER OR TO THE NEAREST USED OIL COLLECTION CENTRE.**



### See also

[Removing the fork legs](#)

#### NOTE

**THE FOLLOWING OPERATIONS REFER TO THE SACHS FORKS.**

#### NOTE

**THE STEMS ARE DIFFERENT.**

#### NOTE

**BEFORE CARRYING OUT THE FOLLOWING OPERATIONS GET A CONTAINER WITH SUITABLE CAPACITY TO COLLECT THE OIL.**

#### LEFT STEM

- Using the appropriate tool fasten the fork in the vice.

### Specific tooling

**AP8140149 Protection for fitting operations**



- Undo completely the sleeve cap.



- Using the specific tool, fixed to the pre-loading pipe, compress the spring.
- Insert a spanner in the lock nut of the cover.

**Specific tooling****020888Y Pliers for pre-fill pipe**

- Unscrew the cap and remove it.



- Compress the spring and remove the spanner using the specific tool.

**Specific tooling****020888Y Pliers for pre-fill pipe**

- Remove the spring preload pipe.



- Remove the washer.



- Remove the spring paying attention to drain the oil correctly.

**NOTE**

THE SPRING IS PROGRESSIVE, THE THICKEST SPIRALS ARE FACING DOWNWARDS.



- Drain the oil into a container of suitable capacity to collect fluids, pumping out oil a few times.



DO NOT DISPOSE OF OIL INTO THE ENVIRONMENT. DISPOSE OF ENGINE OIL IN A SEALED CONTAINER AND TAKE IT TO YOUR SUPPLIER OR TO THE NEAREST USED OIL COLLECTION CENTRE.

**RIGHT STEM**

- Using the appropriate tool fasten the fork in the vice.

**Specific tooling**

AP8140149 Protection for fitting operations



- Undo completely the sleeve cap.



- Using the specific tool, fixed to the pre-loading pipe, compress the spring.
- Insert a spanner in the lock nut of the cover.

**Specific tooling****020888Y Pliers for pre-fill pipe**

- Unscrew the cap and remove it.



- Compress the spring and remove the spanner using the specific tool.

**Specific tooling****020888Y Pliers for pre-fill pipe**

- Remove the spring preload pipe.



- Remove the washer.



- Remove the spring paying attention to drain the oil correctly.

**NOTE**

THE SPRING IS PROGRESSIVE, THE THICKEST SPIRALS ARE FACING DOWNWARDS.



- Drain the oil into a container of suitable capacity to collect fluids.



DO NOT DISPOSE OF OIL INTO THE ENVIRONMENT. DISPOSE OF ENGINE OIL IN A SEALED CONTAINER AND TAKE IT TO YOUR SUPPLIER OR TO THE NEAREST USED OIL COLLECTION CENTRE.




## Disassembling the fork

**NOTE**

THE FOLLOWING OPERATIONS REFER TO THE SHOWA FORKS.

**WARNING**

DO NOT INTERCHANGE THE STEMS, THEY HAVE INTERNAL DIFFERENCES. THE LEFT CARTRIDGE (2) HAS A SLOT AT THE BOTTOM, WHEREAS THE RIGHT ONE (1) HAS A SLOT AT THE TOP.

**NOTE**

THE OPERATIONS DESCRIBED BELOW ARE VALID FOR BOTH STEMS.

- Drain the fork oil.
- Place the stanchion on a work table in upright position.
- Fit the special tool.

**Specific tooling**

AP8140147 Spacer tool




With the help of a second operator:

- Insert the special tool between the nut and the preloading pipe.

**Specific tooling**

AP8140148 Spacer-piston separating plate



- Loosen the nut.



- Remove the sleeve cap carefully so as not to damage the rod when removing it.



- Remove the spacer.



### See also

[Draining oil](#)

- Measure the distance between the nut and the thread to restore this setting if necessary.
- Compress the spring so as to take out the tool.

### Specific tooling

**AP8140148 Spacer-piston separating plate**



- Remove the washer and the bushing.



- Slide off the preloading pipe together with the spring centring.



- Remove the spring. Let the oil deposited on the spring turns fully drip into the sleeve.



- Be careful not to damage the stanchion when placing it in a vice, in horizontal position, using the appropriate protections.


### Specific tooling

#### AP8140149 Protection for fitting operations

- Unscrew and remove the bottom screw and collect the special washer.



- Remove the pumping member pin.



- Remove the bottom cap.



- Slide off the dust scraper from the sleeve using a screwdriver as a lever.
- During this operation, pay attention not to damage the sleeve rim.



- Remove the retainer ring.



- Take out the sleeve from the stem using the stem as a hammer puller.

- From the stem remove the fixed fitted bushing, the movable bushing, the ring and the oil seal.



- Remove the ring and the dust guard.

**NOTE**

**THE FOLLOWING OPERATIONS REFER TO THE SACHS FORKS.**

**LEFT STEM**

- Remove the nut on the pumping member, retrieving the washer.



- Remove the internal dipstick of the pumping member.

**See also**[Draining oil](#)

- Slide off the dust scraper from the sleeve using a screwdriver as a lever.
- During this operation, pay attention not to damage the sleeve rim.



- Remove the retainer ring.



- Take out the sleeve from the stem using the stem as a hammer puller.

- Remove the fixed bushing (1), the movable bushing (2), the ring (3) and the oil seal (4) from the stem.




- Remove the lock seeger ring of the spring guide.
- Remove the spring guide.



- Using a hook spanner lock the pumping member pin
- Remove the stem bottom screw.

**Specific tooling**

**020889Y Pumping member ring nut locking spanner**



- Remove the pumping member pin.



---

**RIGHT STEM**


- Remove the nut on the pumping member, retrieving the washer.



- Slide off the dust scraper from the sleeve using a screwdriver as a lever.
- During this operation, pay attention not to damage the sleeve rim.

**See also**[Draining oil](#)

- Remove the retainer ring.



- Take out the sleeve from the stem using the stem as a hammer puller.

- Remove the fixed bushing (1), the movable bushing (2), the ring (3) and the oil seal (4) from the stem.




- Remove the lock seeger ring of the spring guide.
- Remove the spring guide.



- Using a hook spanner lock the pumping member pin
- Remove the stem bottom screw.

**Specific tooling**

**020889Y Pumping member ring nut locking spanner**



- Remove the pumping member pin.



---

**Checking the components****Stem**

Check the sliding surface for scorings and/or scratches.

These scorings can be eliminated by rubbing them with wet sandpaper (grain 1).

If the scorings are deep, replace the stem.

Use a dial gauge to check that the stem bending is below the limit value.

If over the value, replace the stem.

**CAUTION**

**A BENT STEM SHOULD NEVER BE STRAIGHTENED BECAUSE ITS STRUCTURE WOULD BE WEAKENED AND USING THE VEHICLE MAY BECOME DANGEROUS.**

**Characteristic****Bending limit:**

0.2 mm (0.00787 in)

**Sleeve**

Check that there are no damages and/or cracks; otherwise, replace it.

**Spring**

Check the spring is in good conditions.

Check that the following components are in good conditions:

- upper bushing;



- lower bushing;



- piston.

If there are signs of excessive wear or damage, replace the affected component.

**CAUTION**

REMOVE ANY IMPURITY IN THE BUSHINGS, TAKING CARE NOT TO SCRATCH THEIR SURFACE.



Replace the following components with new ones:


- seal ring;



- dust gaiter;



- O-Ring on the cap.



## Reassembling the fork

### NOTE

THE FOLLOWING OPERATIONS REFER TO THE SHOWA FORKS.

### NOTE

THE OPERATIONS DESCRIBED BELOW ARE VALID FOR BOTH STEMS.

- Lock the stem in a vice without damaging the surface.
- Protect the bearing tube end with adhesive tape.
- Lubricate the sliding edges with fork oil or sealing grease.
- Fit the dust gaiter, the retainer ring and the dust scraper on the stem.
- Fit the ring, the movable bushing and, after removing the tape, fit the fixed bushing.





- Fit the sleeve on the stem and set the oil seal into position with the aid of the specific tool.

**Specific tooling**

**AP8140189 Oil seal fitting tool for Ø 43 mm (1.69 in) orifices**

**AP8140146 Weight**



- Insert the retainer ring in its position.



- Fit the dust gaiter with the specific tool.

**Specific tooling**

**AP8140189 Oil seal fitting tool for Ø 43 mm (1.69 in) orifices**

**AP8140146 Weight**




- Screw the specific perforated rod on the pumping member threaded rod.

**Specific tooling**

**AP8140150 Perforated rod for piston air bleed**

- Fit the pumping member with the bottom cap in the sleeve.



- Tighten the screw fixing the pumping member on the fork end to the prescribed torque.



---

**NOTE**

**THE FOLLOWING OPERATIONS REFER TO THE SACHS FORKS.**

**NOTE**


**THE STEMS ARE DIFFERENT.**

---

- Lock the stem in a vice without damaging the surface.
- Protect the bearing tube end with adhesive tape.
- Lubricate the sliding edges with fork oil or sealing grease.
- Fit the dust guard, the snap ring and the oil seal on the stem.



- Fit the ring (1), the movable bushing (2), and after removing the tape, the fixed bushing (3).



- Fit the sleeve on the stem and set the oil seal into position with the aid of the specific tool.

### Specific tooling

**AP8140189 Oil seal fitting tool for Ø 43 mm (1.69 in) orifices**

**AP8140146 Weight**



- Insert the retainer ring in its position.



- Fit the dust gaiter with the specific tool.

### Specific tooling

**AP8140189 Oil seal fitting tool for Ø 43 mm (1.69 in) orifices**

**AP8140146 Weight**




- Insert the pumping member pin in the stem.



- Using a hook spanner lock the pumping member pin and tighten the fixing screw on the fork end to the prescribed torque.

**Specific tooling**

**020889Y Pumping member ring nut locking spanner**



- Insert the spring guide and lock it by the appropriate seeger.



- Place the fork vertically.
- Insert the washer.



**ONLY FOR THE LEFT STEM:** insert the internal dipstick of the pumping member.

- Fill with oil.




## Filling oil

### NOTE

**THE FOLLOWING OPERATIONS REFER TO THE SHOWA FORKS.**

- Place the sleeve upright in a vice fitted with protection shoes.
- Compress the sleeve in the stem.  
Place a support under the stem in order to leave it compressed.
- Pour part of the fork oil into the sleeve.
- Wait some minutes until the oil fills all the ducts.
- Pour the remaining oil.
- Pump out oil a few times.
- Measure the air gap between the oil level and the rim.



**THE SLEEVE MUST BE PERFECTLY UPRIGHT IN ORDER TO MEASURE THE CORRECT OIL LEVEL. THE OIL LEVEL MUST BE THE SAME IN BOTH STANCHIONS.**

### Specific tooling

**AP8140149 Protection for fitting operations**

#### Characteristic

**Oil level (from sleeve rim, without the spring and with pumping member compressed)**

147 mm (5.79 in)

- Tighten the appropriate tool on the pumping member pin rod.

### Specific tooling

**AP8140150 Perforated rod for piston air bleed**

- Insert the spring, with the closest turns side facing downwards.



- Fit the preloading pipe together with the spring centring.



- Fit the special tool.

### Specific tooling

#### AP8140147 Spacer tool




- With the aid of a second operator, hold the pumping member rod firmly, lower the spacer retention tool, insert the stop ring and the plate separating the spacer-pumping member between the ring and the nut.

### Specific tooling

#### AP8140148 Spacer-piston separating plate



- Insert the sleeve cap and screw the nut.



- Tighten the sleeve cap.


**NOTE**

**THE FOLLOWING OPERATIONS REFER TO THE SACHS FORKS.**

**NOTE**

**THE STEMS ARE DIFFERENT BUT THE OIL REFILLING PROCEDURE ARE THE SAME FOR BOTH.**

- Place the sleeve upright in a vice fitted with protection shoes.
- Compress the sleeve in the stem.  
Place a support under the stem in order to leave it compressed.
- Pour part of the fork oil into the sleeve.
- Wait some minutes until the oil fills all the ducts.
- Pour the remaining oil.
- Pump out oil a few times.
- Measure the air gap between the oil level and the rim.



**THE SLEEVE MUST BE PERFECTLY UPRIGHT IN ORDER TO MEASURE THE CORRECT OIL LEVEL. THE OIL LEVEL MUST BE THE SAME IN BOTH STANCHIONS.**

**Specific tooling****AP8140149 Protection for fitting operations****Characteristic****Oil level (from sleeve rim, without the spring and preload pipe and with stem at end of stroke)**

135 mm (5.31 in)

- Tighten the nut and the appropriate tool on the pumping member pin rod.

**Specific tooling****020890Y Pumping member stanchion support rod**

- 
- Insert the spring, with the closest turns side facing downwards.



- 
- Insert the washer.



- Insert the preload pipe.



- Fit the special tool.
- Lower the tool by compressing the spring. Insert a spanner in the lock nut.

### Specific tooling


**020888Y Pliers for pre-fill pipe**




- Tighten completely the nut on the pumping member pin rod.
- Insert the sleeve cap on the pumping member pin rod and tighten it.
- Tighten the nut, on the cover to the specified torque.



- Tighten the sleeve cap, to the prescribed tightening torque.




Steering bearing



**OPTION 01-** Steering upper plate **without** a headstock cut.

STEERING - OPTION 1					
pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-
2	Headstock cap	M22x1	1	100 Nm (73.75 lb ft)	-
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-
4	TCEI screw fastening U-bolt onto fork yoke	M10x60	2	50 Nm (36.88 lb ft)	-

**OPTION 02-** Steering upper plate **with** a headstock cut.



### STEERING


pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-
2	Headstock nut - pre-tightening	M22x1	1	10 Nm (7.37 lb ft)	Loctite 243
2	Headstock nut	M22x1	1	25 Nm (18.44 lb ft)	Loctite 243
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-
4	TCEI screw fastening U-bolt onto fork yoke	M10x60	2	50 Nm (36.88 lb ft)	-
5	Steering upper plate clamp closing screw	M8x30	1	25 Nm (18.44 lb ft)	Loctite 243

## Adjusting play

- Place the vehicle so that the front wheel is off the ground.
- Carry out a handlebar rotation test, using a dynamometer at the hand grip external end.
- The handlebar resistance to rotation must be of  $400 \pm 150$  g ( $0.88 \pm 0.33$  lb) in both directions.
- Adjust if clearance is detected.

**OPTION 01-** Steering upper plate **without** a headstock cut.


- Unscrew and remove the U-bolt four fixing screws.
- Remove the U-bolt.
- Remove the handlebar and place it paying attention that oil in the clutch and front brake tanks does not spill out.



- Unscrew and remove the top bolt on the headstock and retrieve the washer.



- Operating from both sides, loosen the screws fixing the stanchions to the upper plate.



- Undo and remove the two screws fixing the instrument panel support to the fork upper plate.



- Slide off the fork upper plate by moving it towards the instrument panel.

Get the suitable tool for the tightening of the ring nut. Carry out the following operations:

- carry out a first tightening of the ring nut to the indicated tightening torque for the settlement of the steering package.
- turn the steering completely from both sides, for several times.

Loosen the ring nut completely.

- carry out the final tightening of the ring nut to the indicated tightening torque.



### Specific tooling

**020884Y 46 mm wrench for steering ring nut**


#### STEERING RING NUT

pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-

- Fit the entire fork upper plate, adjusting with short taps with a rubber hammer
- Tighten the nut to the specified torque.



- Tighten the fixing screws of the upper plate to the prescribed tightening torque.



#### STEERING UPPER PLATES


pos.	Description	Type	Quantity	Torque	Notes
2	Headstock nut	M22x1	1	100 Nm (73.76 lbf ft)	
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-

When refitting the U-bolt, position the two references facing the front part of the vehicle.



**OPTION 02-** Steering upper plate **with** a headstock cut.


- Unscrew and remove the U-bolt four fixing screws.
- Remove the U-bolt.
- Remove the handlebar and place it paying attention that oil in the clutch and front brake tanks does not spill out.



- Undo and remove the top bolt on the headstock.



- Screw the fixing screws of the upper plate.



- Undo and remove the two screws fixing the instrument panel support to the fork upper plate.



- Slide off the fork upper plate by moving it towards the instrument panel.

Get the suitable tool for the tightening of the ring nut. Carry out the following operations:

- carry out a first tightening of the ring nut to the indicated tightening torque for the settlement of the steering package.
- turn the steering completely from both sides, for several times.

Loosen the ring nut completely.

- carry out the final tightening of the ring nut to the indicated tightening torque.



### Specific tooling

**020884Y 46 mm wrench for steering ring nut**

#### STEERING RING NUT

pos.	Description	Type	Quantity	Torque	Notes
1	Headstock ring nut - pre-tightening	M25x1	1	30 Nm (22.13 lb ft)	Steering package settlement
1	Headstock ring nut - tightening	M25x1	1	12 Nm (8.85 lb ft)	-

- Fit the entire fork upper plate, adjusting with short taps with a rubber hammer.
- Scatter the nut thread with the specific product and pre-fit it to the indicated tightening torque.

### Recommended products

**LOCTITE® 243 Loctite adhesive to assemble cylindrical pieces**

Loctite adhesive to assemble cylindrical pieces




- Tighten the fixing screws of the upper plate to the prescribed tightening torque.

CAUTION



TIGHTEN THE STEERING UPPER PLATE CLAMP CLOSING SCREW TO THE SPECIFIED TORQUE APPLYING LOCTITE 243.



- Finish the nut tightening to the indicated tightening torque.



STEERING UPPER PLATE

pos.	Description	Type	Quantity	Torque	Notes
2	Headstock nut - pre-tightening	M22x1	1	10 Nm (7.37 lb ft)	Loctite 243
2	Headstock nut	M22x1	1	25 Nm (18.44 lb ft)	Loctite 243
3	Stainless steel TCC screw fastening stanchions to upper and lower yokes	M8x30	6	25 Nm (18.44 lb ft)	-

When refitting the U-bolt, position the two references facing the front part of the vehicle.



## Assembling

- Grease the lower and upper bearing rollers
- Prefit the shim, dust gaiter and lower bearing on the steering yoke as shown in the figure.

### Recommended products

#### AGIP MP GREASE Grease for bearings, joints, couplings and linkages

As an alternative to the recommended product, use top brand grease for roller bearings with an operating temperature range of -22°F to +284°F (-30°C to +140°C), drop point between 302°F to 446°F (150°C to 230°C), high corrosion protection qualities and good water and rust resistance.




- Install the upper bearing on the steering tube as shown in the figure, with the conical part facing down.



- After inserting, the bearing must slide freely on the steering column till matching with the steering bearing conic in the frame.
- Ensure the bearing mating in its seat, using a teflon buffer from a suitable diameter.



- Fit the specific upper seal ring with the lip placed upwards and the surface with the words downwards.
- Enter it on the column and place it on the upper rim of the headstock.
- Finish inserting, until the stop, with the teflon buffer and rubber hammer.



- Pass with a brush on the seal ring to lay down potential grease storage.




- Place the tightening ring nut with the rim placed downwards.
- Carry out the steering bearings clearance adjustment.



## See also

[Assembling](#)


## Rear

**REAR WHEEL**

pos.	Description	Type	Quantity	Torque	Notes
1	Lower self-locking nut fastening sprocket to sprocket carrier	M10	5	50 Nm (36.88 lb ft)	-
2	TCEI screw fastening flexible coupling mounting on wheel	M10x30	5	50 Nm (36.88 lb ft)	Loctite 270

## Removing the rear wheel

- Place the vehicle on its rear service stand.
- Fasten the vehicle handlebar to the bench using belts.
- To facilitate operations, it is advisable to remove the chain protection by unscrewing the two screws.



**CAUTION**

**RIMUOVERE IL SENSORE VELOCITA' PRIMA DI PROCEDERE CON LA RIMOZIONE DELLA RUOTA POSTERIORE EVITANDO QUINDI DI DANNEGGIARLO**

- Fully slacken the gearing chain tension.
- Make the wheel move forward and release the gearing chain from the sprocket.



- Unscrew and remove the nut on the wheel axle.
- Collect the thrust washer and the right chain tensioner slider.



- Working on the right side, hit the wheel axle lightly so as to take out the head from its housing.
- Working on the left side, slide off the wheel axle together with the chain guide slider.
- Remove the wheel by freeing the disc from the brake calliper.
- Collect the spacer from the rear wheel right side.



- Working from the left side, unscrew and remove the five nuts and remove the sprocket and the bolts.



- Unscrew and remove the five screws and remove the anti-vibration buffer holder.
- Check the flexible couplings according to the routine maintenance table.



### See also

[Adjusting](#)

## Checking the rear wheel



**CHECK THAT ALL PARTS ARE IN GOOD CONDITION, ESPECIALLY THOSE LISTED AS FOLLOWS.**

### REAR WHEEL BEARINGS

Carry out the check with the bearings fitted on the wheel.

### ROTATION CHECK

- Manually rotate the inside ring of each bearing. Rotation must be constant, smooth and noiseless.

If one or both bearings do not fall within the control parameters:

- Replace both wheel bearings.



**ALWAYS REPLACE BOTH BEARINGS.**

**ALWAYS REPLACE THE BEARINGS WITH OTHERS OF THE SAME TYPE.**

- Check the radial and axial clearance.

**Axial clearance: a minimum axial clearance is allowed.**

**Radial clearance: none.**

If one or both bearings do not fall within the control parameters:

- Replace both wheel bearings.

### REAR WHEEL GASKETS

- Check that the gaskets are in good conditions; replace them if they show signs of damage or excessive wear.




**ALWAYS REPLACE BOTH GASKETS.**

**ALWAYS REPLACE THE GASKETS WITH OTHERS OF THE SAME TYPE.**

### REAR WHEEL AXLE

- Use a dial gauge to check the wheel axle eccentricity (1). Replace the wheel axle if the eccentricity exceeds the limit value (1).



### Characteristic


**Maximum eccentricity:**

0.25 mm (0.0098 in)

### REAR WHEEL RIM

- Using a dial gauge, check that the radial (A) and the axial eccentricity (B) of the rim (2) do not exceed the limit value.

An excessive eccentricity is usually caused by worn or damaged bearings. Replace the rim (2) if after replacing the bearings, the value is not within the specified limit.




### Characteristic

**Maximum radial and axial eccentricity:**

2 mm (0.0079 in)

## Shock absorbers



### REAR SUSPENSION

pos.	Description	Type	Quantity	Torque	Notes
1	Upper TCEI mounting screw	M10x50	1	50 Nm (36.88 lbf ft)	-
2	Lower TCEI mounting screw	M10x90	1	50 Nm (36.88 lbf ft)	-

## Removing

- Place the optional under-ump and rear wheel service stands.
- Unscrew and remove the upper screw and collect the washer.
- Loosen the under-ump optional service stand to lower the engine.
- Unscrew and remove the lower screw and retrieve the nut.
- Remove the shock absorber.




## INDEX OF TOPICS

CHASSIS
---------

CHAS
------

## Swinging arm



### SWINGARM

pos.	Description	Type	Quantity	Torque	Notes
1	Swingarm Pin adjustment bushing	-	1	12 Nm (8.85 lb ft)	-
2	Swingarm pin ring nut	-	1	60 Nm (44.25 lb ft)	-
3	Swingarm pin nut	-	1	90 Nm (66.38 lb ft)	-
4	TPSI screw fastening rear stand bushing	M6x40	2	10 Nm (7.37 lb ft)	-
5	TBEI screw fastening chain guard to swingarm	M5x9	1	6 Nm (4.42 lbf ft)	-
6	TBEI screw fastening rear mudguard to swingarm	M5x9	2	6 Nm (4.42 lbf ft)	Loctite 243
7	TBEI screw fastening chain guard to rear mudguard	M5x9	1	4 Nm (2.95 lbf ft)	-
8	TBEI screw fastening chain guide to swingarm	M5x9	2	6 Nm (4.42 lbf ft)	-
9	Wheel axle nut	M25x1.5	1	120 Nm (88.5 lbf ft)	-
10	Flanged TBEI screw fastening chain casing	M5x9	2	4 Nm (2.95 lbf ft)	Loctite 243

## Removing

- Remove the ABS sensor.
- Remove the exhaust system.
- Support the vehicle by means of the engine service stand and a hoist with belts fastened to the rear section of the frame.
- Remove the rear wheel.

- Slide off the rear calliper holding plate, keeping it linked to the brake pipe.

**CAUTION**


DO NOT ACTUATE ON THE REAR BRAKE LEVER AFTER REMOVING THE WHEEL. OTHERWISE, THE CALLIPER PLUNGERS COULD GO OUT OF THEIR SEAT, RESULTING IN BRAKE FLUID LEAKAGE.




- Unscrew and remove the two lower swingarm screws.
- Remove the cable guides.



- Unscrew and remove the shock absorber lower screw and collect the nut.
- Fasten the shock absorber to the chassis.



- With the specific box-spanner, unscrew and remove the locking ring nut.



- Working from the left side, unscrew and remove the nut and collect the washer.




REMOVAL SHOULD BE CARRIED OUT WITH UTMOST CAUTION.  
SUPPORT THE SWINGARM FROM THE FRONT TO AVOID ACCIDENTAL FALLS.  
PLACE A WOODEN SUPPORT UNDER THE FRONT PART OF THE REAR SWINGARM TO PREVENT IT FROM LOWERING AND TO KEEP IT UPRIGHT.



- Working on the right side, unscrew and remove the swingarm bolt.



UPON REMOVING THE REAR SWINGARM PAY ATTENTION NOT TO JAM THE GEARING CHAIN.



### See also

[Removing the rear wheel](#)

## Drive chain

### Adjusting


The vehicle is fitted with an endless chain, without master link.

#### NOTE

**CARRY OUT MAINTENANCE OPERATIONS AT HALF THE INTERVALS SPECIFIED IF THE VEHICLE IS USED IN PARTICULAR RAINY OR DUSTY CONDITIONS, OFF ROAD OR FOR TRACK USE.**

#### To check clearance:

- Shut off the engine.
- Rest the vehicle on its stand.
- Engage neutral gear.
- Check that the vertical oscillation at a point between the pinion and the sprocket on the lower branch of the chain is approx. 25 - 30 mm (0.98 - 1.18 in).



- Move the vehicle forward so as to check vertical oscillation of the chain in other positions too. clearance should remain constant at all wheel rotation phases.
- If clearance is uniform but over 30 mm (1.18 in) or below 25 mm (0.98 in), adjustment is necessary.



## ADJUSTMENT

### CAUTION

**GET A SPECIFIC REAR SERVICE STAND (OPT) TO ADJUST THE CHAIN.**

If you need to adjust chain tension after the check:

- Place the vehicle on its rear service stand (OPT).
- Loosen the nut (1) completely.
- Loosen both lock nuts (4).
- Actuate on the adjuster screws (5) and adjust the chain clearance checking that the references (2-3) match on both sides of the vehicle.
- Tighten both lock nuts (4).
- Tighten the nut (1).
- Check chain clearance.



### CAUTION

**TO ENSURE THAT THE WHEEL IS CORRECTLY CENTRED, THERE ARE FIXED REFERENCE MARKINGS (2-3) INSIDE THE CHAIN TENSIONER SLIDER SEATS ON THE SWINGARMS, IN FRONT OF THE WHEEL AXLE.**

## CHECKING THE CHAIN, THE PINION AND THE SPROCKET FOR WEAR

Furthermore, check the following parts and make sure the chain, the pinion and the sprocket do not show:

- damaged rollers;
- loosened pins;
- dry, rusty, flattened or jammed chain links;
- excessive wear;
- missing sealing rings;
- excessively worn or damaged pinion or sprocket teeth.



IF THE CHAIN ROLLERS ARE DAMAGED, THE PINS ARE LOOSE AND/OR THE SEAL RINGS ARE MISSING OR DAMAGED, THE WHOLE CHAIN UNIT (PINION, SPROCKET AND CHAIN) SHOULD BE REPLACED.

LUBRICATE THE CHAIN ON A REGULAR BASIS, PARTICULARLY IF YOU DETECT DRY OR RUSTY PARTS.

FLATTENED OR JAMMED CHAIN LINKS SHOULD BE LUBRICATED AND GOOD OPERATING CONDITIONS RESTORED.



THE GEARING CHAIN HAS SEALING RINGS AMONG THE LINKS THAT KEEP THE GREASE INSIDE.

ADJUST, LUBRICATE, WASH AND REPLACE THE CHAIN WITH UTMOST CAUTION.

CLEANING AND LUBRICATION


Do not wash the chain with water jets, steam jets, high-pressure water jets and highly flammable solvents.

- Wash the chain with fuel oil or kerosene. Maintenance operations should be more frequent if there are signs of quick rust.

Lubricate the chain at the intervals specified on the routine maintenance table and whenever necessary.

- Wash the chain, allow to dry and lubricate with spray grease for sealed chains.

Stand




STAND ASSEMBLY

pos.	Description	Type	Quantity	Torque	Notes
1	Stand screw	M10x1.25	1	10 Nm (7.37 lbf ft)	Loctite 243
2	Thin nut	M10x1.25	1	30 Nm (22.13 lbf ft)	Loctite 243
3	Spring fixing pin	-	1	7.5 Nm (5.53 lbf ft)	-

pos.	Description	Type	Quantity	Torque	Notes
4	TCEI screw fastening stand switch	M5x16	2	7 Nm (5.16 lbf ft)	-

Exhaust



EXHAUST SYSTEM

pos.	Description	Type	Quantity	Torque	Notes
1	SERPRESS self-locking nut fastening flange on head	M8	4	25 Nm (18.44 lbf ft)	-
2	Primary Clamp (between front/rear manifolds and central manifold)	M6	2	7 Nm (5.16 lbf ft)	-
3	Silencer Clamp (between central manifold and silencer)	M6	1	7 Nm (5.16 lbf ft)	-
4	Self-tapping TE screw fastening silencer mounting bracket to saddle mounting	M8x20	2	25 Nm (18.44 lbf ft)	-
5	Self-tapping TE screw fastening front silencer fixture to silencer mounting bracket	M8x35	2	35 Nm (25.81 lbf ft)	-

## Removing the tail pipe

- Loosen the clamp between the exhaust end and the manifold.



- Remove the saddle.
- Undo and remove the two upper screws and collect the washers.



- Remove the exhaust end backwards by sliding off the two brackets from the rubber rings in the upper section and the bracket from the chassis retainer in the lower part.



## Removing the manifold - tail pipe

- Remove the front exhaust manifold.
- Disconnect the lambda probe.
- Loosen the exhaust manifold and the exhaust end clamps from the rear cylinder.



- Remove the manifold - terminal coupling.

### See also

[Removing the exhaust manifold](#)

---

## Removing the exhaust manifold

The engine and the exhaust system components get very hot and remain in this condition for a certain time interval after the engine has been switched off. Before handling these components, make sure that you are wearing insulating gloves or wait until the engine and the exhaust system have cooled down.

### FRONT

- Unscrew and remove the two nuts on the head exhaust stud bolts.



- Loosen the clamp.
- Remove the exhaust manifold.



**REAR**

- Loosen the exhaust pipe between the manifold and the exhaust end.
- Unscrew and remove the two nuts on the head exhaust stud bolts.


**See also**

[Removing the manifold - tail pipe](#)

---

**Removing the lambda sensor**

- Remove the clamp.
- Disconnect the lambda probe connector.



- Unscrew and remove the lambda sensor.



## INDEX OF TOPICS

**B**RAKING SYSTEM

**BRAK SYS**

Interventions rules


CAUTION  
THE FRONT BRAKE DISC SHAPE DOES NOT CHANGE THE OPERATING AND MAINTENANCE SPECIFICATIONS OF THE SYSTEM.

ABS



ABS SYSTEM

pos.	Description	Type	Quantity	Torque	Notes
-	ABS ECU fastener screw	M6x25	1	10 Nm (7.37 lbf ft)	Loctite 243
-	ABS ECU fastener nut	M6	2	10 Nm (7.37 lbf ft)	-

**key:**

1. ABS ECU control unit
2. Front ABS sensor
3. Rear ABS sensor
4. Battery
5. Main relay
6. ECU
7. Instrument panel
8. K line (diagnosis)
9. Key
10. Fuses


**ABS ECU control unit pin configuration**

- PIN 1 - GND - Ground
- PIN 2 - PCC1 - Vehicle identification ground connection
- PIN 4 - IGN - Injection
- PIN 8 - WL - Alarm warning light
- PIN 11 - R\_SIGN - Rear ABS sensor signal
- PIN 12 - R\_GND - Rear ABS sensor ground connection
- PIN 13 - F\_GND - Front ABS sensor ground connection
- PIN 14 - F\_SIG - Front ABS sensor signal
- PIN 15 - PCC2 - Vehicle identification ground connection

- PIN 16 - ISO\_K - K line (diagnosis)
- PIN 18 - KL30 - Power supply

---


## Foreword



### key:

1. Rear brake calliper
  2. Modulator
  3. Front bleed valve
  4. Front brake reservoir
  5. Front brake callipers
  6. Rear brake pump
  7. Rear brake reservoir
-

## Operating diagram



### ABS functional diagram key

1. Front system circuit
2. Front brake pump
3. Front brake lever
4. Rear system circuit

5. Rear brake pump
6. Rear brake pedal control
7. ABS control unit
8. Rear brake calliper
9. Front calliper (2 callipers)
10. Front brake circuit intake solenoid valve (normally open)
11. Humidifier
12. Rear brake circuit intake solenoid valve (normally open)
13. Rear brake exhaust circuit solenoid valve (normally closed)
14. Rear/front brake circuit low pressure accumulator
15. Front brake exhaust circuit solenoid valve (normally closed)
16. DC electric motor
17. Double circuit hydraulic pump (ABS)
18. Rear brake reservoir
19. Front brake reservoir

## ABS OPERATION

### General specifications:

The front circuit is similar to the rear circuit.

- The ABS inlet valve (10 - 12) is normally open and it is closed only when the system intervenes to avoid wheel locking.
- The outlet valve (13 - 15) is normally closed and it is opened only when the system intervenes to avoid wheel locking.
- When the system is in standby, the ABS processor never stops monitoring the speed of the wheels in order to assess potential wheel slippage.
- When in standby, the system does not intervene at all when the rider brakes; the braking system is the same as the one without ABS.

**Stages in ABS cycle (the following operations refer to the front circuit but are also applicable to the rear one):**

**A - Brake activation: the rider starts braking** as he would usually do.

**B - Pressure reduction:** it coincides with danger recognition (wheel slippage above threshold): the system closes the inlet valve (10-12) and opens the outlet valve (13-15) temporarily.

At this stage the rider cannot increase the pressure on the callipers (8-9) and the system reduces the pressure on the callipers partially. The excess fluid temporarily fills the front reservoir (18-19) until the ABS pump (17) self-activates and delivers the fluid back to the brake pump (2-5).

**C - Pressure maintained:** the pressure in the callipers (8-9) remains low until total recovery of speed / wheel grip.

The system restores the fluid taken from the calliper (8-9) in the section of the system between the brake pump (2-5) and the ABS inlet valve (10-12).

**D - Pressure restored:** by opening the inlet valve (10-12) momentarily, the pressure of the callipers (8-9) is increased until maximum deceleration is reached. Then, the system gives the control over the braking back to the rider.

**E -** If the wheel does not reach complete grip, the system continues operating as before until complete grip is obtained or until the vehicle stops. An error can be detected if the duration of the pressure reduction phase exceeds the pre-set time limit.

---

### ABS SYSTEM DESCRIPTION

The ABS system is a device to avoid wheels locking in case of emergency braking, increasing vehicle braking stability when compared to a traditional braking system.

Sometimes when the brake is operated, the tyre locks with a consequent loss of grip, which makes it difficult to control the vehicle. A position sensor (3) on the tone wheel (2), forming an integral unit with the vehicle wheel, "reads" the status of the vehicle wheel spotting any possible lock.


A control unit (1) signals this out and adjusts the pressure in the braking circuit accordingly.

#### NOTE

**WHEN THE ABS SYSTEM STARTS WORKING, A VIBRATION IS FELT ON THE BRAKE LEVER.**



**THE WHEEL ANTILOCK BRAKING SYSTEM DOES NOT PREVENT FALLS WHILE ON A BEND. AN EMERGENCY BRAKING WITH THE VEHICLE INCLINED, HANDLE BAR TURNED, ON UN-EVEN OR SLIPPERY ROADS, OR WITH POOR GRIP CREATES LACK OF STABILITY DIFFICULT TO HANDLE. THEREFORE, RIDE CAREFULLY AND SENSIBLY AND ALWAYS BRAKE GRADUALLY. BRAKING WHILE TURNING A CORNER IS SUBJECT TO LAWS OF PHYSICS WHICH NOT EVEN ABS CAN ELIMINATE.**




When the sensors (3) detect a significant speed difference between the rear and the front wheels (for example, when rearing up on the back wheel), the ABS system could take this as a dangerous situation. In this case, two things may occur:

- The ABS system intervenes by releasing pressure from the calliper until the wheel turns again at the same speed of the other wheel. It is not possible to brake for an instant.
  - if the speed difference lasts long, the system may detect an error and deactivate the ABS system. As a consequence, the system works like any regular braking system.
-


**Riding with an active ABS system**

- At engine start-up, the ABS warning light (5) on the instrument panel (4) turns on and remains on until the vehicle exceeds 5 km/h (3.1 mph).

**If the ABS warning light remains on when the vehicle is running, it means that a fault has been detected and the ABS system has been automatically deactivated.**

**20 A fuse (ABS Main fuse) (6)**

Protects: ABS Control unit.

**Guide to diagnosis****PREMISE**

Each time the key is ON, at least one current or stored\* error of the ABS system is often detected:

- the EFI warning light turns on permanently and the word ABS is shown on the display (NA 850 Mana ABS).
- the ABS warning light turns on permanently (SL 750 SHIVER ABS / DORSODURO 750 ABS).

If on the vehicle NA 850 Mana ABS, temporary errors of other control units are detected, the word ABS shown on the display is displayed instead of the word relative to the other control units where errors have been detected (e.g. GEAR or SERVICE).

The ABS system is deactivated!

The system operates perfectly just as any other braking system without ABS

**\* The diagnosis requires exceeding the 5 km/h.**

**Each time the key is ON, if at least one current or stored\* error of the ABS system is not detected:**

- the EFI warning light flashes and the word ABS is shown on the display (NA 850 Mana ABS).
- the ABS warning light flashes (SL 750 Shiver ABS / Dorsoduro 750 ABS)

**When the 5 km/h (3.11 mph) are exceeded:**

- if errors are not detected

- the EFI warning light turns off and the word ABS on the display disappears (NA 850 Mana ABS).
  - the ABS warning light turns off (SL 750 Shiver ABS / Dorsoduro 750 ABS)
- if at least one malfunction is detected
- the EFI warning light turns on permanently and the word ABS appears on the display (NA 850 Mana ABS)
  - the ABS warning light turns on permanently (SL 750 Shiver ABS / Dorsoduro 750 ABS)

**The ABS system is deactivated!**

**The system operates perfectly just as any other braking system without ABS.**

The detection of malfunctions may require more or less time according to the type of failure.

Error detection logic foresees that for the errors to be diagnosed one or more conditions must persist within a given time.

If during this given time one of the conditions is missing but then it comes back, the timer is reset and the system is no longer able to diagnose the error.

The ABS system is still inactive.

**Example:**

- error code 5D93 requires some minutes before it is diagnosed during the given time:
- A - The EFI warning light keeps flashing with the word ABS on the display (NA 850 Mana ABS)
  - B - The ABS warning light keeps flashing (SL 750 Shiver ABS / Dorsoduro 750 ABS)

---

## **ABS FAULTS - GUIDE TO THE DIAGNOSIS**

1a. **NA 850 Mana** - WARNING LIGHT+ ABS ICON 1b. **Dorsoduro 750 - SL 750 Shiver** - ABS WARNING LIGHT TURNED ON

2. CONNECT AXONE

**DOES AXONE COMMUNICATE? (NO, go to 3; YES, go to 4)**

3.PERFORM THESE CHECKS:

- A. Ground connection PIN 1
- B. +12V at PIN 18
- C. +12V at PIN 4 with key ON

**4. ARE THERE ANY ERRORS? (YES, go to 5; NO, go to 6)**

5. CONSULT THE TABLE ERROR DISPLAY

6. ABS WARNING LIGHT ACTIVATION

**ACTIVE?(YES, go to 7; NO, go to 8)**

7. CONTACT TECHNICAL SERVICE

8. CHECK:

- A. Cable continuity between PIN 8 of the ABS control unit connector and PIN 28 of the instrument panel.
- B. Check connectors - refer to the operations described in the chapter

If the previous checks are OK, the causes might be:

- C. ABS control unit malfunction
- D. Instrument panel malfunction

**NOTE:** to check the wheel speed sensor through AXONE, refer to the operations described in chapter "ELECTRIC SYSTEM/CHECKS AND CONTROLS/SPEED SENSOR".

## Using axone for the abs

## Abs screen pages

### ISO screen page

#### ISO

This screen page shows general data regarding the control unit, for example software type, mapping, control unit programming date



#### ISO SCREEN PAGE

Characteristic	Value/example	Unit of measurement	Notes
Vehicle manufacturing date			
Frame number			
Software version			
Vehicle code	Mana/Shiver/Dorsoduro/Scarabeo		The vehicle code stored in the control unit is read.
Vehicle identification according to the status of Pin 2 and 15 of the ABS control unit connector	Mana/Shiver/Dorsoduro/Scarabeo		The vehicle type (Mana/Shiver/Dorsoduro) is defined according to the connection found for PIN 2 and PIN 15 of the ABS control unit connector. see table on workshop booklet


**NOTE:** the "X" in the table identifies the connector pin is grounded.

		PIN2	PIN15
	Shiver		X
	Mana	X	
	Scarabeo	X	X
	Dorsoduro		

## Parameter reading screen page

### ENGINE PARAMETER READING

This screen page shows the parameters measured by the several sensors (engine revs, engine temperature, etc.) or values set by the control unit (injection time, ignition advance, etc.)



### ENGINE PARAMETER READING

Characteristic	Value/example	Unit of measurement	Notes
Front wheel speed	0	km/h	With stopped wheel, 0 Km/h is displayed
Rear wheel speed	0	km/h	With stopped wheel, 0 Km/h is displayed
Battery voltage	11.9	V	

## Devices activation screen page

### DEVICES ACTIVATION

This screen page is used to delete errors in the control unit memory and to activate some systems controlled by the control unit.



### DEVICES ACTIVATION

Characteristic	Value/example	Unit of measurement	Notes
Front brake bleeding procedure			Useful in case of lever sponginess although the bleeding has been done as in a regular braking system
Rear brake bleeding procedure			Useful in case of lever sponginess although the bleeding has been done as in a regular braking system
ABS warning light			For Shiver and Dorsoduro models, the ABS warning light is caused to flash. For the Mana model, both the EFI warning light and the ABS word flash on the display.
Ambient parameter error reading (1)			The ambient parameters are 4: Number of error detections, Operation cycles from the last detection, Battery voltage, Speed.
Ambient parameter error reading (2)			Number of error detections: number of times the error has been detected by the control unit;
Ambient parameter error reading (3)			for example, if it indicates 2, it means that the error has been detected (ATT), then it has not been detected for a while (sent to the MEM) and then it has been detected again.
Ambient parameter error reading (4)			Operation cycles from the last reading: a cycle is counted if the following occurs: key ON and speed over 20 km/h.
Ambient parameter error reading (5)			If for example 5 is shown, it means that the last time the error has been measured was 5 cycles ago.
Error clearing (1)			Press "enter" to transfer errors from the memory (MEM) to the historical record (STO).
Error clearing (2)			In the next connection between Axone and the control unit, the historical errors (STO) are no longer shown.

## Errors display screen page

### ERRORS DISPLAY

This screen page shows potential errors detected in the vehicle (ATT) or stored in the control unit (MEM) and it allows to check error clearing (STO).



### ERRORS DISPLAY

Characteristic	Value/example	Unit of measurement	Notes
Front speed sensor: 5D90 electric malfunction			Electrical fault in sensor or cable harness
Front speed sensor: 5D91 the signal works irregularly			Faulty sensor or signal interference
Front speed sensor: 5D92 the signal decreases periodically			Possible tone wheel fault due to deformations or dirt; possible alterations on the wheel bearing surface. In very rare cases, abnormal tone wheel vibrations
Front speed sensor: no signal or speed measured too low in relation to the rear wheel 5D93			Faulty sensor or missing sensor/tone wheel or excessive distance between the sensor and the tone wheel or tone wheel with wrong number of teeth
Front speed sensor: 5D94 no acceleration after pressure reduction			Faulty sensor or missing sensor/tone wheel or excessive distance between the sensor and the tone wheel
Front speed sensor: 5D95 excessive measured speed			Faulty sensor/tone wheel, or tone wheel with wrong number of teeth or wrong tyre size
Rear speed sensor: 5DA0 electric malfunction			Electrical fault in sensor or cable harness
Rear speed sensor: 5DA1 the signal works irregularly			Faulty sensor or signal interference
Rear speed sensor: 5DA2 the signal decreases periodically			Possible tone wheel fault due to deformations or dirt; possible alterations on the wheel bearing surface. In very rare cases, abnormal tone wheel vibrations
Rear speed sensor: 5DA3 no signal or speed measured too low in relation to the front wheel			Faulty sensor or missing sensor/tone wheel or excessive distance between the sensor and the tone wheel or tone wheel with wrong number of teeth
Rear speed sensor: 5DA4 no acceleration after pressure reduction			Faulty sensor or missing sensor/tone wheel or excessive distance between the sensor and the tone wheel
Rear speed sensor: excessive measured speed 5DA5			Faulty sensor or tone wheel with wrong number of teeth or wrong tyre size
Control unit: missing valve calibration 5DD2			Possible control unit fault
Control unit 5DD3			Possible control unit fault
Recirculation pump 5DF0			Possible control unit fault
Recirculation pump 5DF1			Possible control unit fault
Control unit 5DF2			Possible control unit fault
Low electric voltage - long period measurement 5DF3			Voltage too low measured for 30 seconds at PIN 18 of the ABS control unit:
Control unit 5DF5			Possible control unit fault
High electric voltage 5DF7			Excessive voltage measured at PIN 18 of the ABS control unit
Vehicle code 5E59			Inconsistency detected between memory coding (ISO/Vehicle code) and what is measured at cable harness identification PIN (ISO screen page, Ve-

Characteristic	Value/example	Unit of measurement	Notes
			Vehicle identification line - Pins 2-15 of ABS control unit)
Control unit F000			Possible control unit fault

## Adjustable parameters screen page

### ADJUSTABLE PARAMETERS

Characteristic	Value/example	Unit of measurement	Notes
Coding (1)			Used for re-coding the control unit or coding a new one.
Coding (2)			Vehicle identification is done according to the connection of PINS 2 and 15 of the ABS control unit connector and is stored in the control unit memory.
Coding (3)			The identification can be read in the ISO diagram in the line: Vehicle code.


**NOTE:** the "X" in the table identifies the connector pin is grounded.

		PIN2	PIN15
	Shiver		X
	Mana	X	
	Scarabeo	X	X
	Dorsoduro		

## Modulator

### MODULATOR REMOVAL


- Remove the fairing lug.
- Release clamp (1) and disconnect connector (2).




- By unscrewing the nuts, remove and plug the brake oil pipes following this sequence: (3) - (4) - (6) - (5).



- Slide off the rear system pipes from the hooks (7).
- Undo and remove the three screws, collect the washers and remove the ABS modulator.




## Rear brake calliper

**REAR BRAKE**

pos.	Description	Type	Quantity	Torque	Notes
1	Rear brake lever pin	M6	1	25 Nm (18.44 lbf ft)	-
2	Flanged TE screw fastening pump to footrest mounting	M6x20	2	10 Nm (7.37 lbf ft)	-
3	TBEI screw fastening oil pipe to swingarm and rubber pipe to footrest mounting	M5x12	4	6 Nm (4.42 lbf ft)	-
4	Flanged self-locking nut	M6	1	10 Nm (7.37 lbf ft)	-
5	Screw + nut fastening pedal to brake lever	M6	1+1	10 Nm (7.37 lbf ft)	-
6	Brake pipe union	M10x1	2	25 Nm (18.44 lbf ft)	-
1	Flanged TE screw fastening rear disc	M8x20	5	30 Nm (22.13 lbf ft)	Loctite 243
7	ABS sensor fastener screw	M5	1	6 Nm (4.42 lbf ft)	-
-	Flanged TE screw	M6x16	1	10 Nm (7.37 lbf ft)	-

Front brake calliper



FRONT BRAKE

pos.	Description	Type	Quantity	Torque	Notes
1	Flanged TE screw fastening calliper	M10x1.25x55	4	50 Nm (36.88 lbf ft)	-
2	Pipe union with bleed outlet (Heng Tong)	M10x1	2	25 Nm (18.44 lbf ft)	-
-	Fastener for brake pipe on steering base	M6x25	1	10 Nm (7.37 lbf ft)	-

Front brake pads

Removal

- Turn the pins and remove both split pins.
- Remove both pins.
- Collect the anti-vibration springs.
- Extract one pad at a time.



**CAUTION**

**AFTER REMOVING THE PADS, DO NOT OPERATE THE BRAKE LEVER OR THE CALLIPER PLUNGERS COULD GO OUT OF THEIR SEATS RESULTING IN BRAKE FLUID LEAKS.**

## Rear brake pads

### Removal

- Remove the safety circlip.



- Unscrew and remove the pin.



- Extract one pad at a time.

**CAUTION**

**AFTER REMOVING THE PADS, DO NOT OPERATE THE BRAKE LEVER OR THE CALLIPER PLUNGERS COULD GO OUT OF THEIR SEATS RESULTING IN BRAKE FLUID LEAKS.**



## Bleeding the braking system

### VEHICLE PREPARATION

- It is important to check that there is always enough brake fluid in the reservoir.
- Using a bleed device facilitates these operations while, in the meantime, the "Brake fluid replacement" operations are performed.

- In this case, the bleed process must be accompanied by further pedal strokes and with the bleed device connected (about 5 for each wheel circuit).

---

**BLEED SYSTEM AFTER BRAKE PUMP REPLACEMENT****PRELIMINARY OPERATIONS**

- Install the new brake pump.
- Connect the reservoir to the brake pump.
- Connect the brake pipe to the pump line coupling.
- Fill the reservoir with new DOT4 brake fluid.



---

**REGULAR BLEEDING SYSTEM**

- Connect the bleed bottle to the bleed screw of the front brake calliper.
- Operate the brake lever.
- Open the bleed screw until all the pressure has been released and then close it.
- Release the brake lever.
- After releasing the lever, wait two seconds so that the brake fluid flows into the cylinder.
- Repeat this procedure until the brake fluid is clear and has no air bubbles. (about 10 to 20 times).

**NOTE: CHECK BRAKE FLUID LEVEL IN THE RESERVOIR AND, IF NECESSARY, TOP UP (CHECKING BRAKE PAD WEAR).**

- Bleed as previously described, also on the bleed valve installed on the front brake pump.
- Then perform the same procedure for the rear brake calliper, acting only on the valve installed on that calliper.

- Fill the reservoir until it reaches the reference "MAX" and refit the cap (check pad wear).
- Detach the bleed hoses and close the bleed screws again to the correct tightening torque.
- Check the stroke and the sensitivity of both the lever and the brake pedal.

**NOTE: IF AFTER BLEEDING, THE STROKE OF THE PEDAL OR THE LEVER IS TOO LONG, CHECK THAT THERE ARE NO LEAKS IN THE BRAKING SYSTEM AND IF EVERYTHING IS OK, CONTINUE BLEEDING OPERATIONS USING AXONE.**

---

#### **BRAKE BLEEDING AFTER ABS CONTROL UNIT REPLACEMENT**

##### **VEHICLE PREPARATION**

- Connect the bleed bottle to the bleed screws of the front and rear callipers and open it.
- Fully press down the lever and the brake pedal and fix them into position with the respective locking devices.
- Close the bleed screws of the front and rear callipers and remove the bleed bottle.
- Remove the damaged ABS control unit.



**Note: First of all, detach the brake pipes that go from the ABS control unit to the brake pump (1-4) and immediately seal the opened unions of the ABS control unit with protective caps. Afterwards, remove pipes (2-3) that go from the ABS control unit to the brakes and also seal these unions with protective caps.**

- Install the new ABS control unit, previously filled up.
- So that the brake fluid remains in the ABS control unit, first remove the protective caps of the braking circuit unions and connect the respective pipes.

**Once all the braking circuits have been connected, remove the protective caps from the braking pump unions and connect the braking pump pipes to the ABS control unit.**

- Unlock the lever and the brake pedal.
- Remove the cap of the reservoir and fill it with the new DOT 4 brake fluid up to the reference "MAX".

#### CAUTION

**PERFORM THE REGULAR BRAKING SYSTEM BLEED, AS DESCRIBED AT THE BEGINNING OF THE CHAPTER.**

- Always fill the reservoir up to the reference "MAX" and refit the cap.
- Check the stroke and the sensitivity of both the lever and the brake pedal.
- If after bleeding, the pedal or the lever stroke is too long, check that there are no leaks in the braking system and if everything is ok, continue bleeding operations using Axone as described.
- Detach the bleed hoses and close the bleed screws again to the correct tightening torque.

## **BRAKE BLEEDING AFTER CALLIPER REPLACEMENT**

**VEHICLE PREPARATION** - The operations are described for the front system, but they are also valid for both braking systems.

- Connect the bleed bottles to the bleed screw of the front calliper and open it.
- Fully press down the brake lever and fasten it into position with a locking device so as to avoid fluid flowing out from the open system.
- Close the bleed screws of the front calliper and remove the bleed bottle.



- Replace the damaged calliper with a new one.
- Unlock the brake lever.
- Remove the cap of the reservoir and fill it with the new DOT 4 brake fluid up to the reference "MAX".

### **BRAKING SYSTEM BLEEDING (only the new calliper)**

#### **CAUTION**

**PERFORM THE REGULAR BRAKING SYSTEM BLEED, AS DESCRIBED AT THE BEGINNING OF THE CHAPTER.**

- Always fill the reservoir up to the reference "MAX" and refit the cap.
- Check the stroke and the sensitivity of both the lever and the brake pedal.
- If after bleeding, the pedal or the lever stroke is too long, check that there are no leaks in the braking system and if everything is ok, continue bleeding operations using Axone as described.
- Detach the bleed hoses and close the bleed screws again to the correct tightening torque.

---

### **BLEEDING USING AXONE**

**This type of bleeding has to be carried out if after all the checks the brake lever and the pedal are still spongy.**

**The operations described here are valid for both systems even though the description refers to the front system.**

#### **FRONT**

- With Axone properly connected, select the function "FRONT BRAKE BLEEDING PROCEDURE".
- The pump starts rotating.
- While the pump is performing a rotation cycle, operate and release the front brake lever until the message Axone cycle completion is received.
- This procedure allows the air to turn and to accumulate.
- Once the procedure with Axone is finished, perform the REGULAR BLEEDING to remove the air from the system completely.

#### **CAUTION**

**PERFORM THE REGULAR BRAKING SYSTEM BLEED, AS DESCRIBED AT THE BEGINNING OF THE CHAPTER.**

---

---

## Changing the brake fluid

### BRAKE FLUID REPLACEMENT

#### VEHICLE PREPARATION

- Connect the bleeding unit to the reservoir of the braking system.

**Max. filling pressure to be applied to the system= 3 bar (300 kPa - 43.51 PSI).**


#### PURGING PROCESS TO CHANGE THE BRAKING SYSTEM FLUID

Connect the bleed bottle to the bleed screw of the front calliper and open it.

- Operate the bleeding unit and while the system is being purged, top up the reservoir with the new DOT 4 brake fluid; keep doing this until clean oil begins to flow out through the bleed tube.
- Leave the screw open until the fluid in the tube is clear and free of air bubbles.
- Close the bleed screw.
- Repeat this procedure on the remaining bleed valves of the system and close them all to the prescribed tightening torque.
- Remove the bleeding unit.
- Always fill the reservoir up to the reference "MAX" and refit the cap.
- Check the stroke and the sensitivity of both the lever and the brake pedal.
- If after bleeding, the pedal or the lever stroke is too long, check that there are no leaks in the braking system and if everything is OK, continue bleeding operations using Axone as described.
- Detach the bleed hoses and close the bleed screws again to the correct tightening torque.



Front brake pump




FRONT BRAKE PUMP

pos.	Description	Type	Quantity	Torque	Notes
1	Pipe union fastening brake pipe to pump	M10x1	1	25 Nm (18.44 lbf ft)	-
2	Fastener for front brake pump on handlebar	-	2	10 Nm (7.37 lbf ft)	-

## INDEX OF TOPICS

CLUTCH SYSTEM

CLU SYS



**CLUTCH PUMP**


pos.	Description	Type	Quantity	Torque	Notes
1	Clutch cylinder fastener	M6	2	10 Nm (7.37 lbf ft)	-
2	Pipe union with bleed outlet (Heng Tong) fastening pipe to cylinder	M10x1	1	25 Nm (18.44 lbf ft)	-
3	Fastener for clutch pump on handle-bar	-	2	10 Nm (7.37 lbf ft)	-
4	Screw fastening clutch control mounting on flywheel side crankcase half	M6	1	12 Nm (8.85 lbf ft)	-

**INDEX OF TOPICS**

**COOLING SYSTEM**

**COOL SYS**

Circuit diagram




COOLING SYSTEM

pos.	Description	Type	Quantity	Torque	Notes
1	Fan fastener screw	-	3	3 Nm (2.21 lbf ft)	-
2	Flanged TE screw fixing LH side radiator to trellis frame and radiator bracket to engine	M6x25	2	10 Nm (7.37 lbf ft)	-

Electric fan

- Remove the radiator
- Undo and remove the three screws and collect the washers; remove the electric fan.



See also

[Removing the radiator](#)

## Coolant replacement

- Remove the right side fairing.
- Place a container of suitable capacity.
- Loosen the screw, move the clamp and slide off the sleeve.



- Remove the cap.



- Empty the system into the specific container.
- Loosen the screw and move the clamp.
- Slide off the sleeve and empty the system completely.

### CAUTION

SHOULD GREASE BE NOTED IN THE WATER THIS IS TO BE CONSIDERED NORMAL BECAUSE DURING THE ASSEMBLY PHASE OF THE WATER PUMP SIGNIFICANT LUBRICATION OF THE SAME IS REQUIRED IN ORDER TO PREVENT DAMAGE.




- Refit both sleeves, place the corresponding clamps and tighten their screws.
- Fill the expansion tank up to the marked level.
- After bleeding the air from the tank, fit the expansion tank cap.
- Refit the front protection and tighten the screw.
- Fit the right side fairing.

---

## Water pump


### OPTION 01



**WATER PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch side cover fastener screw	M6	13	13 Nm (9.59 lbf ft)	-
2	Fastener screw for Pump Cover / Clutch side cover	M6	3	13 Nm (9.59 lbf ft)	-
3	Screw fastening Pump Cover / Clutch Cover / clutch side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-
4	Nut fastening pump drive input gear on shaft	M6	1	12 Nm (8.85 lbf ft)	Loctite 244
5	Water pump rotor	-	1	4.50 Nm (3.32 lbf ft)	-

**OPTION 02**



**WATER PUMP**

pos.	Description	Type	Quantity	Torque	Notes
1	Clutch side cover fastener screw	M6	11	13 Nm (9.59 lbf ft)	-
2	Fastener screw for Pump Cover / Clutch side cover	M6	3	13 Nm (9.59 lbf ft)	-
3	Screw fastening Pump Cover / Clutch Cover / clutch side crankcase half	M6	2	13 Nm (9.59 lbf ft)	-
4	Nut fastening water pump drive gear sprocket	M6	1	12 Nm (8.85 lbf ft)	-
5	Water pump rotor	-	1	4.50 Nm (3.32 lbf ft)	-
6	Screw fastening chain tensioner slider to water pump	M6	1	8-10 Nm (5.90-7.38 lbf ft)	-
7	Water pump support fixing screw	M6	3	12 Nm (8.85 lbf ft)	-
8	Water pump support plug	M6x10	1	6.5 Nm (4.79 lbf ft)	3M SCOTCH GRIP 2353

**Removal**

**OPTION 01**

**COVER REMOVAL**

- Drain off the cooling circuit completely.
- Undo and remove the five screws.
- Remove the water pump cover.



**PUMP ROTOR REMOVAL**

- Remove the clutch-side cover.
- Lock the pump shaft with a universal wrench on the hexagonal insert on the shaft.

- Unscrew and remove the anticlockwise nut fixing the rotor.
- Remove the rotor.



- Unscrew and remove the rotor control gear fixing nut and act on the gear hexagonal insert.
- Remove the rotor control gear.
- From the cover inside to the outside, remove the rotor control shaft with a punch and a rubber hammer.



- Use a screwdriver to remove the upper part of the shaft and integrated seal assembly as indicated.

**CAUTION**

BEFORE TIGHTENING THE 3 SCREWS, ENSURE THAT THE TOOL IS PERFECTLY CENTRED WITH THE SEAL AND THAT THE SCREWS ARE PERPENDICULAR TO THE SURFACE OF THE SEAL ITSELF. TIGHTENING THE SCREWS INCORRECTLY MAY DAMAGE THE OIL SEAL UNDERNEATH THE WATER SEAL AND THE COVER ITSELF.



- Fit the tool and use the specific punch to make 3 holes in the integrated seal.

**Specific tooling**

**020661Y Water pump overall seal replacement kit**



- Tighten the three screws.



- Fit the upper part of the tool.
- Fully tighten the pin with the bolt.
- Preventing the bolt from turning, tighten the nut to that the lower part of the tool, onto which the shaft and integrated seal are connected, raises.



- Remove the oil seal.



---

## OPTION 02

### COVER REMOVAL

- Drain off the cooling circuit completely.
- Unscrew and remove the five water pump cover fixing screws.



- Release the clamp.



- Remove the water pump cover.


#### **PUMP ROTOR REMOVAL**

- Remove the water pump cover H2O.
- Unscrew and remove the impeller paying attention to the left-handed threading of the pin.



#### **COMPLETE H2O PUMP REMOVAL**

- Remove the clutch cover.
- Unscrew and remove the three H2O pump fixing screws.



- Remove the H2O pump and slide off the drive chain.

#### **NOTE**

REPLACE THE O-RINGS ON REASSEMBLY





## **Installing**

#### **CAUTION**



PAY ATTENTION TO THE TYPE OF PUMP FITTED DURING FITTING. THERE ARE TWO TYPES, WITH (1) AND WITHOUT O-RING (2). THEY CANNOT BE INTERCHANGED BETWEEN THEM. IT IS POSSIBLE TO CHECK THE PRESENCE OF O-RING ON THE CARTER OR DIRECTLY ON THE PUMP. THE SEAT MUST BE AS SHOWN IN THE FIGURE. FURTHERMORE, THE CARTERS STAMPED WITH NUMBER 28127 AND FOLLOWING ARE ALL WITH O-RING SEAT.



**REFITTING**

- Insert a new oil seal using the appropriate tool to a depth of 2 mm (0.079 in) (determined by the tool), relative to the upper part of the crankcase, at the end of the flanged part of the seat orifice.

**CAUTION**

AFTER INSTALLING THE OIL SEAL, CHECK THAT THE WATER DRAINAGE HOLE UNDER THE OIL SEAL ITSELF IS NOT OBSTRUCTED.

**Specific tooling**

020885Y Water pump oil seal punch



- Fit a new shaft and integrated seal assembly using the specific tool.

**Specific tooling**

020725Y Punch for water pump overall sealing



- Fit the rotor drive gear.
- Fit the rotor drive gear fastener nut, applying leverage on the hexagonal insert on the gear itself.



- Fit the rotor and tighten with the relative nut while preventing the pump shaft from turning with a spanner.



- Fit the water pump cover, fastening the five screws.




---

**OPTION 02****COMPLETE H2O PUMP INSTALLATION**

- Insert the drive chain and position the H2O pump in its seat.



- Insert the three H2O pump fixing screws and tighten them to the prescribed torque.



- Spread grease generously on the side of the H<sub>2</sub>O pump, thereby facilitating insertion of the cover.

**CAUTION**

DURING ASSEMBLY OF THE COVER BE CAREFUL TO INSERT IT PERPENDICULARLY TO THE CRANKCASE WITH UNIFORM PRESSURE ON THE ENTIRE SURFACE, THEREFORE AVOIDING DAMAGE TO THE O-RINGS.




## Removing the radiator

- Drain off the cooling system.
- Undo and remove the screw.
- Remove the filler.




- Remove both clamps and slide off the corresponding pipes.




- Disconnect the electric fan connector.



- Undo and remove the screw, remove the horn.



- Working on the left side of the vehicle, unscrew and remove the screw.



- Lower the radiator from the upper fixing side to the chassis and remove it by sliding it off toward the vehicle right-hand side.



- To install the radiator, follow the operations explained above but in reverse order, and replace all the clamps removed.
- Restore the correct coolant level.

**See also**


Coolant replacement

---

**Removing the expansion tank**

- Remove the right side fairing.

- Loosen and move the clamp.
- Slide off the pipe.



- Release the clamp.
- Slide off the pipe.



- Undo and remove the screw and collect the washer.
- Slide off the expansion tank.



## Thermostatic valve

Traditional circuit, three-way thermostatic valve:


1. Hot water inlet from the heads.
2. Outlet towards the short circuit (direct to the pump).
3. Outlet towards the radiator



INDEX OF TOPICS


BODYWORK

BODYW



**INSTRUMENT PANEL**


pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening instrument panel mounting to fork yoke	M6x20	2	10 Nm (7.37 lbf ft)	-




**FRONT MUDGUARD**

pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening fork guard to calliper mounting bracket	M5x9	6	6 Nm (4.42 lbf ft)	Loct. 243

pos.	Description	Type	Quantity	Torque	Notes
2	TBEI screw fastening mudguard to stanchions	M5x9	4	4 Nm (2.95 lbf ft)	-
3	Screw fastening number panel to headlamp	-	4	1 Nm (0.74 lbf ft)	-


**FRONT BODYWORK**

pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening front side panels to tank	M5x9	6	4 Nm (2.95 lbf ft)	-
2	TBEI screw fastening front side panels and duct to radiator	M6x16	4	6 Nm (4.42 lbf ft)	-
3	TBEI screw fastening ignition block cover to spacer	M5x9	3	4 Nm (2.95 lbf ft)	-
-	Front tank fastener spacer	M6	2	10 Nm (7.37 lbf ft)	-




**REAR BODYWORK 1**

pos.	Description	Type	Quantity	Torque	Notes
1	Screws fastening battery cover to compartment	M5	2+1	4 Nm (2.95 lbf ft)	-
2	TBEI screw fastening battery compartment to saddle mounting	M5x9	2	6 Nm (4.42 lbf ft)	-




**REAR BODYWORK 2**

pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening LH - RH covers to silencer	M6x20	4	10 Nm (7.37 lbf ft)	-
2	TBEI screw fastening tail fairing to saddle mounting	M5x9	2	6 Nm (4.42 lbf ft)	-
3	Screw fastening tail fairing to battery compartment	-	3	4 Nm (2.95 lbf ft)	-

**REAR BODYWORK 3**


pos.	Description	Type	Quantity	Torque	Notes
1	TBEI screw fastening license plate mounting to mounting	M5x9	3	6 Nm (4.42 lbf ft)	-
2	Fastener for license plate mounting frame assembly to gusset plate - saddle lock	M6	4	10 Nm (7.37 lbf ft)	-
3	Screw fastening license plate mounting cover to license plate mounting	-	3	0.8 Nm (0.59 lbf ft)	-



**SADDLE MOUNTING**

pos.	Description	Type	Quantity	Torque	Notes
1	Upper LH TCEI screw fastening saddle mounting to frame	M8x55	1	25 Nm (18.44 lbf ft)	-
2	Upper RH TCEI screw fastening saddle mounting to frame	M8x60	1	25 Nm (18.44 lbf ft)	-
3	Lower TCEI screw fastening Saddle mounting to frame	M8x40	2	25 Nm (18.44 lbf ft)	-
-	TCEI screw fastening passenger grab handles to frame	M8x80	4	30 Nm (22.13 lbf ft)	-

Headlight assy.





HEADLAMP

pos.	Description	Type	Quantity	Torque	Notes
1	TE screw fastening headlamp to headlamp mounting and mudguard to steering base	M6x16	2	10 Nm (7.37 lbf ft)	-
2	Fastener for front turn indicators	M5	2	3 Nm (2.21 lbf ft)	-
3	TCEI screw fastening headlamp mounting to fork yoke	M6	3	10 Nm (7.37 lbf ft)	-

- Operating from both sides, unscrew and remove the front frame fixing screw and collect the nut.




- Remove the instrument panel.
- Working from the vehicle left side, unscrew and remove the pin, and collect the nut and the washer from the right side.



- Disconnect the front turn indicator cable harness.




- Disconnect the headlamp connector and remove the headlamp assembly.

**See also**

[Instrument cluster support](#)

---


Taillight assy.



TAILLIGHT

pos.	Description	Type	Quantity	Torque	Notes
1	TE screw fastening tail light to li- cense plate mounting frame	M6x45	3	10 Nm (7.37 lbf ft)	-
2	Fastener for rear turn indicators	M6	2	3 Nm (2.21 lbf ft)	-
3	Reflector fastener	M5	2	2 Nm (1.47 lbf ft)	-
4	Fastener for license plate light	M5	1	5 Nm (3.69 lbf ft)	-

- Remove the license plate support.
- Unscrew and remove the four screws.



- Unscrew and remove the screw.



- Unscrew and remove the three internal screws.



- Working from both sides, unscrew and remove the screw.



- Disconnect the taillight connectors.
- Remove the taillight.




**See also**

[Tail guard](#)

---

Footrest




FOOTPEGS

pos.	Description	Type	Quantity	Torque	Notes
1	Upper screw fastening passenger footrests to frame side panels	M8x35	2	25 Nm (18.44 lbf ft)	Loct. 243
2	Lower TCEI screw fastening passenger footrests to rider footrest mounting	M8x35	2	25 Nm (18.44 lbf ft)	Loct. 243
3	TCEI screw fastening rider footrest mounting to frame	M8x35	4	28 Nm (20.65 lbf ft)	Loctite 243

RIGHT FOOTREST

- Undo and remove the two external screws.




- Remove the right footrest
- Unscrew and remove both rear brake pump internal fixing screws.



---

#### LEFT FOOTREST

- Unscrew and remove the two external screws.



- Loosen the gear shift lever rod screw.
- Slide off the gear shift lever rod.
- Remove the left footrest.



---

#### Side body panels

- Unscrew and remove the screw.



- Unscrew and remove the rear screw.




- Remove the side fairing.



## License plate holder

### PLATE HOLDER REMOVAL


- Remove the saddle.
- Remove the tail fairing.
- Unscrew and remove the three screws.



- Disconnect the taillight connector.
- Release the taillight cable harness from the clamps.



- Disconnect the saddle unlocking cable.




- Slide off the license plate holder towards the back.

**See also**[Seat](#)[Tail guard](#)

---

**LICENCE PLATE HOLDER REMOVAL****OPTION 01**

- Remove the saddle unlocking cable (1) from the taillight and release the cable harness (2)



- Remove the three rear lower screws (3).




- Remove the rear cover of the license plate holder assembly (4)




- Remove the cable harness clamp




- Disconnect the connectors



- Remove the screws (5) that secure the license plate holder to the internal structure and be sure to collect the internal nuts




- Separate the license plate holder (6) by removing the rear cable harness (7) from the internal structure (8)




- Turn the turn indicators by 180 degrees and remove them.



- Remove the four screws (9) that secure the two components of the internal structure of the license plate holder and be sure to collect the internal nuts




- Release the opening cable and remove it



- Remove the fork spring




- Remove the hose control plate



- Remove the license plate light fixing screw in order to remove the lamp holder and be sure to collect the nut




- Remove the lamp holder to replace the license plate light bulb.




- Remove the lock block

## OPTION 02


- Remove the saddle unlocking cable (1) from the taillight and release the cable harness (2)



- Remove the taillight
- Remove the screw (3)



- Remove the three rear screws (4)



- Remove the screw (5) and the same from the opposite side



- Remove the screw (6) that secures the turn indicator to the license plate holder and to the rear section.
- Repeat the operation for the screw that secures the other turn indicator.
- Now it is possible to separate the front section of the plate from the rear.



- Remove the clamp and release the cable harness



- Turn the turn indicators by 180 degrees and remove them.




- Remove the license plate light fixing screw in order to remove the lamp holder and be sure to collect the nut



- Remove the lamp holder to replace the license plate light bulb.




- Release the opening cable and remove it



- Remove the fork spring




- Remove the hose control plate



- Remove the lock block


Air box



AIR FILTER BOX

pos.	Description	Type	Quantity	Torque	Notes
1	Cross head self-tapping screw fastening separator / filter box	M5x20	10	3 Nm (2.21 lbf ft)	-
2	SWP self-tapping screw	M2.9x12 TCCR	2	3 Nm (2.21 lbf ft)	-
3	Cross head self-tapping screw fastening cover / filter box	M5x20	8	3 Nm (2.21 lbf ft)	-
4	Cross head self-tapping screw fastening lateral cap / filter box	M5x20	3	3 Nm (2.21 lbf ft)	-
-	Cross head self-tapping screw	M5x10	2	3 Nm (2.21 lbf ft)	-

- Remove the air filter.
- Slide off the electrical components fastened to the air filter box.
- Undo and remove the eight screws.



- Unscrew and remove the inner screw.



- Unscrew and remove the screw.



- Remove the filter support partition.



- Release the cable harness from the clamps.

- Unscrew and remove the two screws after loosening the front and rear manifold clamps.



- Loosen the clamp to slide off the bleed pipe.



- Lift the filter box and working on both cylinders, loosen and move the clamp and slide off the oil vapour recovery pipe.



- Working on the left side, disconnect the two control unit connectors.

**CAUTION**

THE CONNECTORS ARE MARKED BY THE LETTERS "V" (VEHICLE) AND "E" (ENGINE). DO NOT INTERCHANGE THEM WHEN REFITTING.



- Unscrew and remove the screw and remove the ground lead.



- Disconnect the two connectors.



- Remove the filter box together with the throttle body, by lifting it up from behind.

**CAUTION**

COVER THE SLEEVE OPENINGS SO THAT NO FOREIGN BODIES COME IN.



Should the throttle body be removed, disconnect either the map sensor pipes or the intake ducts; it is necessary to check the air system tightness. Using Navigator, check the following parameters:

- a - take the vehicle temperature to 90 °C (194 °F) or above.
- b - front cylinder throttle valve correction between - 60 and 60.
- b - rear cylinder throttle valve correction between - 60 and 60.

- c - potentiometer 1 front throttle valve value is 0.5 or above.
- d - potentiometer 1 rear throttle valve value is 0.5 or above.
- e - the difference of throttle valve correction values between the front and rear cylinders should not exceed 0.6.


See also

Air filter


Lower cowl

Removal

- After positioning the vehicle on the side stand, operating on both sides, undo and remove the two screws and remove the fairing lug.



Fuel tank



FUEL TANK					
pos.	Description	Type	Quantity	Torque	Notes
1	TCEI screw fastening filler cap flange	M5x16	5	3 Nm (2.21 lbf ft)	-

pos.	Description	Type	Quantity	Torque	Notes
2	Rear TE screw fastening tank	M6x90	1	10 Nm (7.37 lbf ft)	-

**CAUTION**

**DURING FUEL TANK LIFTING AND REPOSITIONING, BE CAREFUL SO AS NOT TO CRUSH/ BEND OR SLIDE OFF TANK BREATHERS FROM THE CORRESPONDING TUBE-GUIDES**

**LIFTING THE FUEL TANK**

- Remove the saddle.
- Remove both side fairings.
- Undo and remove the two tank front screws.

**See also**


[Side body panels](#)

**TANK REMOVAL**

- Undo and remove the rear screw.
- Remove the rubber ring on the ignition lock.



- Pay attention not to damage the immobilizer aerial.



- Draw the tank backward as much as you can in order to avoid interferences in the front part when lifting the tank.

**CAUTION**

**PAY ATTENTION WHEN LIFTING THE TANK SINCE IF BREATHER PIPES ARE NOT ACCOMPANIED, THEY MAY TEAR.**



- Insert a pin in the rear fixing screw hole so that you can lift the tank and be able to disconnect the breather pipes.



- Disconnect the fuel pipe.



**OPTION 01**

- If there is a "Y" joint, disconnect the tank breather pipe and when refitting it, place it according to the new standard following the refitting procedure.

**OPTION 02**

- Disconnect the breather pipes from the tank.



- Release the cable harness from the clamps.



- Disconnect the fuel pump connector.
- Remove the tank.

**CAUTION**

**UPON REFITTING THE TANK, FOLLOW THE SAME STEPS BUT IN REVERSE ORDER. CONNECT AGAIN THE FUEL PIPES AND THE FUEL PUMP CONNECTOR. REMEMBER TO SLIDE OFF THE PIN PREVIOUSLY FITTED AND TO DRAW THE TANK BACKWARD AS MUCH AS POSSIBLE IN ORDER TO FIT IT PROPERLY.**

---

**Instrument cluster support**

- Working on both sides, loosen the nuts and screws and remove them.



- Disconnect the connectors of arrow indicators, headlamps, ignition switch assembly and relay.



- Remove the three screws that fix the instrument panel.



- Slide off the instrument panel from its support.



- Disconnect the instrument panel connector.



- Remove the instrument panel.


---

## Radiator cover

- Working from both sides, unscrew and remove the screw.



- Remove the radiator cover.



## Tail guard

- Remove the saddle.
- Remove the rear passenger grab handle (if present).
- Working from both sides, unscrew and remove the external screw.



- Unscrew and remove the three screws.
- Slide off the tail fairing backwards.



## INDEX OF TOPICS

<b>P</b> RE-DELIVERY	<b>PRE DE</b>
----------------------	---------------

Carry out the listed checks before delivering the motorcycle.

**WARNING**

**HANDLE FUEL WITH CARE.**

---

## Aesthetic inspection

- Paintwork
  - Fitting of Plastic Parts
  - Scratches
  - Dirt
- 

## Tightening torques inspection

- Safety fasteners:
    - front and rear suspension unit
    - front and rear brake calliper retainer unit
    - front and rear wheel unit
    - engine - chassis retainers
    - steering assembly
  - Plastic parts fixing screws
- 

## Electrical system

- Main switch
  - Headlamps: high beam lights, low beam lights, tail lights (front and rear) and their warning lights
  - Headlight adjustment according to regulations in force
  - Front and rear stop light switches and their bulbs
  - Turn indicators and their warning lights
  - Instrument panel lights
  - Instrument panel: fuel and temperature indicator (if present)
  - Instrument panel warning lights
  - Horn
  - Electric starter
  - Engine stop via emergency stop switch and side stand
  - Helmet compartment electrical opening switch (if present)
-

- Through the diagnosis tool, check that the last mapping version is present in the control unit/s and, if required, program the control unit/s again: consult the technical service website to know about available upgrades and details regarding the operation.

**CAUTION**

**TO ENSURE MAXIMUM PERFORMANCE, THE BATTERY MUST BE CHARGED BEFORE USE. INADEQUATE CHARGING OF THE BATTERY WITH A LOW LEVEL OF ELECTROLYTE BEFORE IT IS FIRST USED SHORTENS BATTERY LIFE.**

**CAUTION**

**UPON INSTALLING THE BATTERY, ATTACH THE POSITIVE LEAD FIRST AND THEN THE NEGATIVE ONE, AND PERFORM THE REVERSE OPERATION UPON REMOVAL.**

**WARNING**

**THE BATTERY ELECTROLYTE IS POISONOUS AS IT MAY CAUSE SERIOUS BURNS. IT CONTAINS SULPHURIC ACID. AVOID CONTACT WITH YOUR EYES, SKIN AND CLOTHING. IF IT ACCIDENTALLY COMES INTO CONTACT WITH YOUR EYES OR SKIN, WASH WITH ABUNDANT WATER FOR APPROX. 15 MIN. AND SEEK IMMEDIATE MEDICAL ATTENTION. IF ACCIDENTALLY SWALLOWED, IMMEDIATELY DRINK LARGE QUANTITIES OF WATER OR VEGETABLE OIL. SEEK IMMEDIATE MEDICAL ATTENTION. BATTERIES PRODUCE EXPLOSIVE GASES; KEEP CLEAR OF NAKED FLAMES, SPARKS OR CIGARETTES. VENTILATE THE AREA WHEN RECHARGING INDOORS. ALWAYS WEAR EYE PROTECTION WHEN WORKING IN THE PROXIMITY OF BATTERIES. KEEP OUT OF THE REACH OF CHILDREN.**

**CAUTION**

**NEVER USE FUSES WITH A CAPACITY HIGHER THAN THE RECOMMENDED CAPACITY. USING A FUSE OF UNSUITABLE RATING MAY SERIOUSLY DAMAGE THE VEHICLE OR EVEN CAUSE A FIRE.**

---

**Levels check**

- Hydraulic braking system fluid level
- Clutch system fluid level (if present)
- Gearbox oil level (if present)
- Transmission oil level (if present)
- Engine coolant level (if present)
- Engine oil level
- Mixer oil level (if present)

---

**Road test**

- Cold start
- Instrument panel operation

- Response to throttle control
  - Stability when accelerating and braking
  - Front and rear brake efficiency
  - Front and rear suspension efficiency
  - Abnormal noise
- 

## Static test

### Static check after test drive:

- Restarting when warmed up
  - Starter operation (if present)
  - Minimum holding (turning the handlebar)
  - Uniform turning of the steering
  - Possible leaks
  - Radiator electric fan operation (if present)
- 

## Functional inspection

- Hydraulic braking system
- Stroke of brake and clutch levers (if present)
- Clutch - Check for correct operation
- Engine - Check for correct general operation and absence of abnormal noise
- Other
- Documentation check:
- Chassis and engine numbers check
- Supplied tools check
- License plate fitting
- Locks checking
- Tyre pressure check
- Installation of mirrors and any possible accessories



**NEVER EXCEED THE RECOMMENDED INFLATION PRESSURES AS TYRES MAY BURST.**

**CAUTION**

---



**CHECK AND ADJUST TYRE PRESSURE WITH TYRES AT AMBIENT TEMPERATURE.**

---

## Specific operations for the vehicle

**WARNING**

---

---

**OPERATIONS REQUIRED TO RENDER VEHICLE COMPLIANT WITH TWO SEATER TYPE APPROVAL.**

---

**LEFT**


- Remove the left side chain protection



- Fit a left bracket and a left chain protection; fasten then with a TEFL M8x35 mm screw at the top and with a TCEI M8x35 mm screw at the bottom

**NOTE**

FINGER TIGHTEN THE SCREWS AND AFTERWARDS USE THE SPECIFIC WRENCH

**RH**

- Remove the rubber cap.



- Remove the shock absorber protection on the exhaust.



- Fit a right bracket; fasten then with a TEFL M8x35 mm screw at the top and with a TCEI M8x35 mm screw at the bottom.

**NOTE**

**FINGER TIGHTEN THE SCREWS AND AFTERWARDS USE THE SPECIFIC WRENCH**



- Refit the shock absorber protection on the exhaust.



---

**HAND GUARDS**

- Remove the TCEI M6 X 50 screw which fastens the antivibration weight.



- Fit the rubber ring in the hand guards.



- Place the lower spacer on the rear view mirror hole.



- Place the hand guards fastening them on the sides using TCEI M6 X 50 screw being careful when inserting the bushing.





- 
- Place the upper spacer on the rear view mirror hole.



- 
- Fit the rear view mirror screwing the corresponding support column.

**NOTE**

**PERFORM THE SAME PROCEDURE FOR BOTH HAND GUARDS**

---

## A

ABS: 188, 354, 362  
Air filter: 77, 417  
Air temperature sensor: 154

## B

Battery: 129, 136  
Brake: 368–370, 375, 376  
Brake calliper: 368, 369  
Brake fluid: 375  
Brake pads: 369, 370  
Brake pump: 376  
Bulbs:  
Bushings:

## C

CAN line: 190  
Chain: 14, 239–242, 247, 346  
Chain tensioner: 239–242  
Clutch: 176, 218, 221, 222, 225–228, 378  
Coil: 161  
Connecting rods:  
Connectors: 184  
coolant: 381, 391  
Coolant: 381, 391  
Crankcase: 55, 210, 259, 260, 269, 272  
Crankshaft: 55, 259, 268, 270, 272  
Cylinder: 54, 231, 232, 237, 246, 249, 253, 257, 268

## D

Display: 365  
Drive chain: 14, 346

## E

ECU: 184  
Electric fan: 179, 380  
Electrical system: 14, 96, 100, 426  
Engine oil: 75  
Engine temperature sensor: 152  
Exhaust: 349, 351  
Exhaust manifold: 351

## F

Filter box:  
Fork: 299, 302, 304, 308, 319  
Forks:  
Front wheel: 296, 298  
Fuel: 289, 417  
Fuel pump: 289  
Fuses: 133

## G

Gearbox selector: 212

## H

Handlebar: 299

Head cover: 81, 231, 241, 258

Headlight: 399

## I

Identification: 12

Instrument panel:

Intake pressure sensor: 147

## L

License plate holder: 405

## M

Magneto flywheel: 215, 241, 268

Maintenance: 9, 71

Maintenance Table:

Mudguard:

## O

Oil filter: 77

Oil pressure sensor: 173

## R

Radiator: 200, 380, 390, 422

Rear wheel: 338, 340, 346

Recommended products: 59

Ride by wire: 290

Run/Stop switch: 181

## S

Saddle:

Saddle mounting:

Shock absorbers: 342

Side stand: 177

Side stand sensor: 177

Spark plug: 72

Spark plugs:

Speed sensor: 137

Stand: 177, 348

Starter motor: 212, 213

## T

Tank: 391, 417

Throttle body: 163, 292

Transmission: 13

Tyres: 15

## W

Warning lights:

Water pump: 381

Wiring diagram: 118